

[Manuals.plus](#) /

› [Kenneth Cole REACTION](#) /

› Kenneth Cole REACTION Out of Bounds 20-Inch Lightweight Hardshell 4-Wheel Spinner Carry-On Luggage Instruction Manual

Kenneth Cole REACTION 5705048

Kenneth Cole REACTION Out of Bounds 20-Inch Lightweight Hardshell 4-Wheel Spinner Carry-On Luggage Instruction Manual

Model: 5705048

1. INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Kenneth Cole REACTION Out of Bounds 20-Inch Lightweight Hardshell 4-Wheel Spinner Carry-On Luggage. Please read these instructions thoroughly before first use to ensure optimal performance and longevity of your product.

The Kenneth Cole REACTION Out of Bounds luggage is designed for durability and ease of travel. Featuring a lightweight hardshell construction and multi-directional spinner wheels, it offers effortless maneuverability and protection for your belongings.



Image 1: Kenneth Cole REACTION Out of Bounds 20-Inch Lightweight Hardshell 4-Wheel Spinner Carry-On Luggage.

2. KEY FEATURES

- **Durable Hardshell Exterior:** Constructed from ABS and PC material with molded corner guards for enhanced protection against impacts.
- **Lightweight Design:** Engineered to minimize weight for easy lifting and compliance with airline carry-on restrictions.
- **4-Wheel 360-Degree Spinners:** Provides smooth, quiet, and effortless multi-directional mobility.
- **Telescoping Trolley Handle:** Sturdy, user-friendly push-button release handle for simple, one-handed navigation.
- **Top and Side Grab Handles:** Flexible handles facilitate easy lifting and carrying.

- **Spacious Interior:** Features dual-sided packing with tear-resistant polyester lining, compression straps, and a hanging zipper pocket for organized storage.

3. SETUP

Your Kenneth Cole REACTION luggage arrives ready for immediate use. No assembly is required. Before your first trip, familiarize yourself with the following components:

- **Telescoping Handle:** Locate the push-button release on the handle. Press the button and extend the handle to your desired height. Ensure it locks securely into place.
- **Spinner Wheels:** Verify that all four wheels rotate freely in all directions.
- **Zippers:** Test all exterior and interior zippers to ensure smooth operation.
- **Interior Straps:** Unclip and re-clip the interior compression straps to understand their function.

4. OPERATING INSTRUCTIONS

4.1 Packing Your Luggage

The luggage features a dual-sided packing system for efficient organization:

- **Main Compartment:** Place larger items and clothing in the main sections. Use the interior compression straps to secure your belongings and minimize shifting during transit.
- **Zippered Divider:** One side of the luggage features a zippered divider, often with mesh pockets. This is ideal for separating items, such as dirty laundry, shoes, or toiletries, from clean clothes.
- **Hanging Zipper Pocket:** Utilize the smaller hanging zipper pocket for accessories or items requiring quick access.



IT'S WHAT'S INSIDE THAT COUNTS.

Image 2: Interior view of the luggage, highlighting the dual-sided packing and compression straps.

4.2 Maneuvering Your Luggage

- **Using the Telescoping Handle:** Extend the handle to a comfortable height. The 360-degree spinner wheels allow you to push the luggage upright in any direction, reducing strain on your arm and shoulder.
- **Lifting and Carrying:** Use the top and side grab handles when lifting the luggage into overhead compartments, onto luggage racks, or over obstacles.

Your browser does not support the video tag.

Video 1: Demonstration of the Kenneth Cole REACTION Out of Bounds luggage features, including handle extension and wheel maneuverability.

5. MAINTENANCE

- **Cleaning the Exterior:** Wipe the hardshell exterior with a damp cloth and mild soap. Avoid abrasive cleaners that

may damage the finish.

- **Cleaning the Interior:** The polyester lining can be spot cleaned with a damp cloth and mild detergent. Ensure the interior is completely dry before storing.
- **Wheel Care:** Periodically check the wheels for debris. Remove any hair or lint that may impede smooth rolling.
- **Zipper Care:** If zippers become stiff, apply a small amount of zipper lubricant or wax to the teeth.
- **Storage:** Store your luggage in a cool, dry place away from direct sunlight. Avoid placing heavy objects on top of the luggage during storage to prevent deformation.

6. TROUBLESHOOTING

- **Stuck Telescoping Handle:** Ensure the release button is fully depressed. Check for any obstructions or debris in the handle mechanism. Do not force the handle.
- **Wheels Not Rolling Smoothly:** Inspect wheels for trapped debris (hair, lint, dirt). Clean thoroughly. If a wheel is damaged, contact customer support.
- **Stiff or Jammed Zippers:** Apply zipper lubricant or wax. Gently work the zipper back and forth. Avoid excessive force, which can damage the zipper teeth.
- **Exterior Scratches/Scuffs:** Minor scuffs on the hardshell can often be reduced with a magic eraser or a specialized plastic cleaner. Deep scratches may not be fully removable.

7. SPECIFICATIONS

Attribute	Value
Product Dimensions	14 x 8 x 21.75 inches
Item Weight	6 pounds
Capacity	20 Liters
Material	ABS & PC Hardshell
Model Number	5705048
Color	Charcoal





Image 3: Luggage with labeled dimensions.

8. WARRANTY & SUPPORT

This Kenneth Cole REACTION luggage comes with a **manufacturer's limited lifetime warranty** against defects in materials and workmanship. For warranty claims or product support, please refer to the contact information provided with your purchase or visit the official Kenneth Cole REACTION website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B004TNOAXW>

More documents and user manuals: <https://manuals.plus/>