

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Dorman](#) /

› [Dorman 91007 Interior Door Handle Bezel Installation and Maintenance Guide](#)

Dorman 91007

Dorman 91007 Interior Door Handle Bezel Installation and Maintenance Guide

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of the Dorman 91007 Interior Door Handle Bezel. Designed as a direct replacement, this bezel restores the original fit, appearance, and function to your vehicle's interior door handle.

VEHICLE COMPATIBILITY

The Dorman 91007 Interior Door Handle Bezel is compatible with select Toyota models. Please verify fitment for your specific vehicle using the manufacturer's compatibility tools before installation.

Known Compatible Vehicles:

- Toyota Camry: 1997, 1998, 1999, 2000, 2001

INCLUDED COMPONENTS

The package for the Dorman 91007 Interior Door Handle Bezel typically includes:

- One (1) Dorman 91007 Interior Door Handle Right Front/Rear Bezel (Smooth Gray)

Note: Additional tools required for installation are not included.

SETUP AND INSTALLATION

Installation of the interior door handle bezel requires basic automotive repair knowledge and tools. If you are unsure about any step, it is recommended to consult a qualified automotive technician.

Required Tools (Not Included):

- Screwdriver set (Phillips and flathead)
- Panel removal tool (plastic pry tool)

- Small socket wrench set (if applicable for fasteners)

Installation Steps:

1. **Preparation:** Ensure the vehicle is parked on a level surface with the engine off. Gather all necessary tools.
2. **Door Panel Removal:** Carefully remove the interior door panel to access the door handle assembly. This typically involves removing screws hidden under trim pieces, armrests, or door pulls, and then gently prying the panel away from the door frame using a panel removal tool to release clips.
3. **Disconnect Components:** Once the door panel is loose, disconnect any electrical connectors (e.g., for power windows, door locks) and door handle cables or rods attached to the panel. Set the door panel aside in a safe place.
4. **Old Bezel Removal:** Locate the existing interior door handle bezel. It is usually secured by screws or clips. Carefully remove these fasteners and detach the old bezel from the door handle mechanism.
5. **Inspect and Clean:** Inspect the area for any debris or damage. Clean the mounting surface if necessary.
6. **New Bezel Installation:** Position the Dorman 91007 replacement bezel onto the door handle mechanism. Ensure it aligns correctly with the mounting points.
7. **Secure New Bezel:** Secure the new bezel using the original screws or clips. Do not overtighten.
8. **Reconnect Components:** Reconnect any electrical connectors and door handle cables/rods to the door panel. Test the door handle's operation to ensure it functions correctly before reassembling the door panel.
9. **Reinstall Door Panel:** Carefully align the door panel with the door frame and press it firmly into place, ensuring all clips engage. Reinstall any screws or trim pieces that were removed.
10. **Final Check:** Verify that the door opens and closes smoothly from both inside and outside, and that the interior handle operates correctly.



Figure 1: Front view of the Dorman 91007 Interior Door Handle Bezel, showing its gray finish and opening for the handle mechanism.



Figure 2: Rear view of the Dorman 91007 Interior Door Handle Bezel, illustrating the mounting points and internal structure for secure attachment.

OPERATING THE DOOR HANDLE

Once installed, the Dorman 91007 Interior Door Handle Bezel functions identically to the original part. To open the door from the inside, simply pull the interior door handle towards you. Ensure the door is unlocked before attempting to open it.

MAINTENANCE

The Dorman 91007 Interior Door Handle Bezel requires minimal maintenance. To keep it clean and in good condition:

- Wipe the bezel regularly with a soft, damp cloth to remove dust and grime.
- Avoid using harsh chemical cleaners or abrasive materials, as these can damage the finish.
- Periodically check the bezel for any looseness or damage. If any issues are found, inspect the mounting points and fasteners.

TROUBLESHOOTING

If you encounter issues after installing the Dorman 91007 Interior Door Handle Bezel, consider the following:

- **Door Handle Not Opening:**
 - Ensure the door is unlocked.
 - Verify that the door handle cables or rods are correctly connected to both the handle and the latch mechanism.
 - Check for any obstructions preventing the handle from moving freely.
- **Bezel is Loose:**
 - Re-check all mounting screws or clips to ensure they are securely fastened.
 - Ensure the bezel is correctly seated in its designated position on the door panel.

• Poor Fitment:

- Double-check the vehicle compatibility to ensure the correct part was purchased for your specific make, model, and year.
- Ensure no original components were damaged during removal or installation that might affect the fit.

SPECIFICATIONS

Feature	Detail
Brand	Dorman
Model Number	91007
Material	Alloy Steel
Color	Gray
Exterior Finish	Machined
Item Weight	0.8 ounces (22.68 g)
Product Dimensions	6.9 x 3.6 x 2 inches
Hand Orientation	Right (Front/Rear)
UPC	019495295129

WARRANTY INFORMATION

Dorman products are engineered for durability and reliable performance. For specific warranty details, please refer to the official Dorman product warranty statement available on the manufacturer's website or contact Dorman customer support directly. This product is backed by a team of product experts with over a century of automotive experience.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding the Dorman 91007 Interior Door Handle Bezel, please visit the official Dorman website or contact their customer service department. You can find contact information and additional resources on their website:

www.dormanproducts.com

© 2024 Dorman Products. All rights reserved.

This manual is for informational purposes only. Dorman Products is not responsible for any damage or injury resulting from improper installation or use of this product.