

One For All URC2981

URC 2981 Universal Remote Control User Manual

Model: URC2981 | Brand: One For All

1. SETUP

1.1 Battery Installation

The URC 2981 remote control requires 2 AAA batteries for operation. Ensure correct polarity when inserting the batteries.



Figure 1: Battery compartment with AAA batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, matching the positive (+) and negative (-) terminals as indicated inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

1.2 Initial Device Programming

The One For All URC 2981 is a universal remote control designed to operate up to 8 different audio/video devices. Programming can typically be done using direct code entry or an automatic search function. Refer to the included code list for your specific device brands.



Figure 2: Universal remote programming in action.

For detailed programming instructions, please consult the full manual provided with your remote or visit the [One For All website](#) for online support and code lookup.

2. OPERATING INSTRUCTIONS

The URC 2981 remote control features a comprehensive set of buttons for controlling various functions of your programmed devices. Familiarize yourself with the button layout for optimal use.







Figure 3: Overview of URC 2981 buttons.

2.1 Key Button Functions

- **Power Button:** Turns the selected device on or off.
- **Device Select Buttons (TV, VCR, DVD, SAT, AMP, HI-FI, DVB-T, AUX):** Press to select the device you wish to control. The remote will then send commands to that specific device.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used for menu navigation and selection.
- **Volume Up/Down (+/-):** Adjusts the volume of the currently selected audio device.
- **Channel Up/Down (Triangle Up/Down):** Changes channels on TV or set-top box.
- **Mute Button:** Mutes or unmutes the audio.
- **Numeric Keypad (0-9):** For direct channel entry or inputting codes.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Skip):** Controls media playback on DVD/Blu-ray players or VCRs.
- **Guide Button:** Accesses the electronic program guide (if supported by device).
- **Menu Button:** Opens the device's main menu.
- **Colored Buttons (Red, Green, Yellow, Blue):** Often used for specific functions within menus or interactive services (e.g., Teletext, Smart TV features).

For advanced functions or specific device commands, refer to your device's original manual in conjunction with the URC 2981's programming guide.

3. MAINTENANCE

3.1 Cleaning the Remote

To maintain the remote's appearance and functionality, clean it regularly. Use a soft, dry cloth to wipe down the surface. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's finish or internal components.

3.2 Battery Replacement

When the remote's performance degrades (e.g., commands are not registered consistently, or the range decreases), it's likely time to replace the batteries. Follow the instructions in Section 1.1 Battery Installation to replace the two AAA batteries. Always replace both batteries at the same time with new ones.

4. TROUBLESHOOTING

- **Remote not operating your device:**
 - Ensure the remote is pointed directly at the device's IR receiver.
 - Verify that the correct device mode button (e.g., TV, DVD) is selected.
 - Check if the batteries are correctly inserted and not depleted. Replace if necessary.

- Re-program the remote for your device using a different code from the code list, or try the automatic search method.
- **Some buttons not working:**
 - This can occur if the remote is not fully compatible with all functions of your specific device model.
 - Try the learning function (if available on your model) to copy commands from your original remote.
 - Ensure the device mode is correctly selected for the function you are trying to use.
- **Remote LED flashes after pressing a button:**
 - A flashing LED often indicates a low battery level. Replace the batteries.
 - It could also indicate an invalid command for the selected device mode.

If issues persist, visit the One For All support website or contact their customer service for further assistance.

5. SPECIFICATIONS

Feature	Detail
Model Number	URC2981
Product Dimensions	7.17 x 1.99 x 0.94 inches
Item Weight	6.7 ounces
Batteries Required	2 AAA batteries
Max Number of Supported Devices	8
Compatible Devices	TV, VCR, DVD, SAT, AMP, HI-FI, DVB-T, AUX (as per device buttons)
Color	Schwarz (Black)
Manufacturer	One For All

6. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please visit the official One For All website. You can find comprehensive FAQs, troubleshooting guides, and contact information for their helpdesk.

Official Website: www.oneforall.com


For online support and manuals, refer to the resources available on the manufacturer's website.

Related Documents - URC2981

	One For All URC-2981 Remote Control Manual Comprehensive guide to setting up and using the One For All URC-2981 universal remote control, including direct code setup, search method, learning functions, and volume lock features.
	One For All URC-2981 Universal Remote Control User Manual Comprehensive guide to setting up and using the One For All URC-2981 8-device universal remote control, including direct code setup, search method, learning functions, and volume lock features.
	One For All URC-2981 Universal Remote Control User Manual Comprehensive user manual for the One For All URC-2981 universal remote control, detailing setup, programming, learning functions, and volume control features.
	ONE FOR ALL URC-2981 Universal Remote Control Setup Guide Comprehensive guide for setting up and using the ONE FOR ALL URC-2981 universal remote control, including quick setup instructions, key pad layout, volume control features, and information on accessing extensive device code lists for seamless integration with your home entertainment system.

	One For All URC 6810 Universal Remote Setup Guide Learn & Code Programming Comprehensive setup guide for the One For All URC 6810 universal remote. Learn how to program your remote using learning or code methods, control multiple devices, and utilize advanced features.
	ONE FOR ALL URC-7990/URC-7991 Universal Remote Control User Manual This user manual provides comprehensive instructions for setting up and using the ONE FOR ALL URC-7990 and URC-7991 universal remote controls, covering SimpleSet, Direct Code Set, Auto Search, and SmartControl features.


Documents - One For All – URC2981



[One For All URC-2981 Universal Remote Control User Manual](#)

Comprehensive user manual for the One For All URC-2981 universal remote control, detailing setup, programming, learning functions, and volume control features.

lang:en score:26 filesize: 3.36 M page_count: 88 document date: 2024-08-26



[One For All URC-2981 Remote Control Manual](#)


Comprehensive guide to setting up and using the One For All URC-2981 universal remote control, including direct code setup, search method, learning functions, and volume lock features.

lang:en score:26 filesize: 4.66 M page_count: 96 document date: 2023-03-30

[pdf]




ONE FOR ALL URC2981 MANDO UNIVERSAL PARA 8 ONE 8 DISPOSITIVOS OFA Un mando para ocho dispositivos Controla tu televisor TDT decodificador reproductor DVD URC2981 ALLriverint Fitxes ||| ONE FOR ALL **URC2981** MANDO UNIVERSAL PARA 8 DISPOSITIVOS OFA 8 Un mando para ocho dispositivos. Controla tu televisor, TDT decodificador , reproductor DVD/Blu-ray, Aparatos de Audio, Amplificadores, Home Cinema y Reproductores Multimedia. - Nmero de aparatos que controla: 8. - TV/LCD/LED/Plasma/OL... lang:es score:25 filesize: 176.51 K page_count: 1 document date: 2022-02-21




[One For All URC2981 Universal Remote Control User Manual](#)

Comprehensive user manual for the One For All URC2981 universal remote control, providing setup instructions, learning functions, volume control, and troubleshooting tips in multiple languages. lang:en score:25 filesize: 11.31 M page_count: 94 document date: 2019-04-12



[pdf] Specifications Dimension Guide Declaration of Conformity

Document spec sheet EN One For All URC 2981 Universal streaming remote WM OFA URC2981 Datablad doc av connection Products OneForAll ||| **URC2981** Universal remote control OFA 8 Control up to 8 devices Easily control of all your devices with this handy remote Television VCR Sat DVD AMP Hi-Fi DVB-T Aux Consumer benefits Control up to 8 devices Learning feature available Logistical information Version Number R112981A01-00005 Mode... lang:en score:23 filesize: 332.19 K page_count: 2 document date: 2025-02-20



[pdf]

Datenblatt Tehnični podatki 943361 Daljinski upravljalnik OneForAll 8 Device URC2981 primerenza naprav URC 2981 MegaShop spletna trgovina Megashop si tehnicni daljinski oneforall device urc2981 urc asset conrad media10 add 160267 c1 de 890560051DS00 |||

One for All URC 2981 Universalfernbedienung infrarot Gruppe Hersteller Hersteller Art. Nr. EAN/UPC Eingabegerte One for All **URC2981** 8716184045080 Beschreibung One for All URC 2981 - Universalfernbedienung - infrarot Hauptmerkmale Produktbeschreibung Gertetyp Anschlusstechnik Unterstützte Gerte Eingabegert Batterie



One For All URC-2981 Universal Remote Control User Manual

Comprehensive guide to setting up and using the One For All URC-2981 8-device universal remote control, including direct code setup, search method, learning functions, and volume lock features.


lang:en score:19 filesize: 11.35 M page_count: 96 document date: 2021-08-24

TRUEDATA	
One for All URC 2981 - Universal remote control	
Infrared	
Group	Input Devices
Manufacturer	One for All
Manufacturer item no.	URC2981
EAN/UPC	8716184045080
Description	
One for All URC 2981 - Universal remote control - infrared	
Main features	
Product Description	One for All URC 2981 universal remote control
Device Type	Universal remote control
Connectivity Technology	Infrared
Supported Devices	All System, projection TV, VCR, cable box, DVD player, CD player, audio system, satellite receiver, set-top box
Input Device	Keypad
Battery	2 x standard - AAA type
Extended details	
General	
Device Type	Universal remote control
Connectivity Technology	Infrared
Supported Devices	All System, projection TV, VCR, cable box, DVD player, CD player, audio system, satellite receiver, set-top box
Input Device	Keypad
Features	LED indicator
Battery	2 x standard - AAA type
Technical data © 1999 Philips. Subject to technical modifications and errors.	
© 2022 Truedata B.V. Informaticastraat 87 3906BN Amersfoort +31 (0) 223 2742 service@truedata.nl	

[pdf] Datasheet

Datenblatt One for All URC 2981 Universal remote control IT Supplies byProduct Description universal Device Type Connectivity Technology Infrared32201 datasheet 294296itsupplies nl ashx file 32201 294296 |||

One for All URC 2981 - Universal remote control infrared Group Manufacturer Manufacturer item no. EAN/UPC Input Devices One for All **URC2981** 8716184045080 Description One for All URC 2981 - Universal remote control - infrared Main features Product Description Device Type Connectivity Technology S... lang:it score:16 filesize: 63.42 K page_count: 1 document date: 2023-01-12



[pdf] Documentation Declaration of Conformity

Belle Vallejos URC2981 Declaration of Conformity OFA 8 One For All 112981 DoC oneforall sites default files 2021 12 |||

Universal Electronics BV Colosseum 2 7521 PT Enschede The Netherlands EU DECLARATION OF CONFORMITY We, Universal Electronics BV, Colosseum 2, 7521 PT Enschede, Netherlands, hereby declare under sole responsibility that the 112981 ONE FOR ALL 8 UNIVERSAL to which this declaration relates is in conf... lang:en score:14 filesize: 626.51 K page_count: 1 document date: 2021-12-15

711809_OFA_8_21L_URC2981_RDN1240419.qxp_OFA 8 TC 24-04-19 12:53 Pagi



[pdf]

OFA 8 TC Mathijs Voskuil 711809 21L URC2981Press the TV key on ONE FOR ALL for device you wish to Set Up Press and hold down MAGIC until red LED underneath POWER blinks twice URC2981 All Languages Learning Code listoneforall sites default files 2019 11 URC2981 list ||| 711809_OFA_8_21L_URC2981_RDN1240419.qxp_OFA 8 TC 24-04-19 12:53 Pagi 86 page Seite page English . 4 Deutsch . 7 Fran ais . 10 Espa ol . 13 Portugu s . 16 Italiano . 19 Nederlands . 22 Magyar . 25 Polski . 28 esky . 31 Dansk . 34 URC-2981 Norsk . 37 Svensk . 40 Suomi . 43 E . 46... lang:en score:13 filesize: 11.35 M page_count: 96 document date: 2019-04-24

[illegible]

[Universal Remote Control Manuals and Code Lists](#)

A comprehensive list of links to manuals, code lists, and resources for a wide variety of universal remote control models from manufacturers like Universal Remote, Hama, Marmitek, Silvercrest, and more. Accessing these resources can help users set up and operate their devices.

lang:no score:13 filesize: 74.52 K page_count: 3 document date: 2013-03-12




[\[pdf\]](#) User Manual

Mathijs Seite 68 Home One For All AAA x2 4 e 6 8 E10 12 14 B16 18 P 20 22 24 English Dutch French is p n o e I N d M y Codes are listed by device type and brand name The most popular code first Make sure your device switched on not standby 2 Press the TV key ONE FOR ALL for you wish to Set Up 3 hold down MAGIC until red LED underneath POWER blinks twice will blink once then urc2981 manual all languages oneforall sites default files 2018 10 us dl file id 381 co uk

English . 4 Deutsch . 6 Franais . 8 Espaol . 10 Portugus . 12 Italiano . 14 Nederlands . 16 Magyar . 18 Polski . 20 68 page Seite page Cesky . 22 Dansk . 24 URC-2981 Norsk . 26 Svensk . 28 Suomi . 30 E . 32 . 34 Trke . 36 . 38 Romn . 40 Slovensk . 42 Hrvatski . 44 sceotdueps 46 Quic...

lang:en score:12 filesize: 2.06 M page_count: 72 document date: 2016-01-21




[pdf]

OFA 8 TC Seite 68 age Home One For All AAA 2 4 6 10 12 14 16 18 20 22 24 English Deutsch ançais Español ortuguês Italiano s ar olski Český Norsk ensk Suomi ç е и Română enský i Dansk URC2981 Languages NO Learning oneforall sites default files 2019 11

OFA_8_URC2981_710435_OFA 8 TC 06-05-15 14:41 Pagina 1 English . 4 Deutsch . 6 Franais . 8 Espaol . 10 Portugus . 12 Italiano . 14 Nederlands . 16 Magyar . 18 Polski . 20 68 page Seite page Cesky . 22 Dansk . 24 URC-2981 Norsk . 26 Svensk . 28 Suomi . 30 E . 32 . 34 Trke . 36 . 38 Romn...

lang:it score:10 filesize: 1.67 M page_count: 72 document date: 2015-05-06



[pdf]

OFA 8 TC Mathijs Voskuil URC2981 All Languages Learning Code list oneforall sites default files 2019 11 711809_OFA_8_21L_URC2981_RDN1240419.qxp_OFA 8 TC 24-04-19 12:53 Pagi 86 page Seite page English . 4 Deutsch . 7 Franais . 10 Espaol . 13 Portugus . 16 Italiano . 19 Nederlands . 22 Magyar . 25 Polski . 28 Cesky . 31 Dansk . 34 URC-2981 Norsk . 37 Svensk . 40 Suomi . 43 E . 46 . 49 Trke . 52

lang:en score:10 filesize: 11.35 M page_count: 96 document date: 2019-04-24




[\[pdf\]](#)

Mathijs OFA 8 98x220 5m wit RDN 1281210 TC 28 12 10 35Premere il tasto TV sul ONE FOR ALL corrispondente all ap parecchio che si desidera impostare Premere e tenere premuto MAGIC fino a quando LED Ir ofa 98x22 rdn 128121smartstyle bg product public universalno distancionno one for v 1 urc2981 file 5ffd87049a1ed |||

English . 4 Deutsch . 6 Franais . 8 Espaol . 10 Portugus . 12 Italiano . 14 Nederlands . 16 Magyar . 18 Polski . 20 68 page Seite page Cesky . 22 Dansk . 24 URC-2981 Norsk . 26 Svensk . 28 Suomi . 30 E . 32 . 34 Trke . 36 . 38 Romn . 40 Slovensk . 42 Hrvatski . 44 sceotdueps 46 Quic...

lang:en score:10 filesize: 2.06 M page_count: 72 document date: 2011-04-13



[\[pdf\]](#) Catalog

CATALOGO ONE FOR ALL riverint Catalogo |||

ndice MANDOS A DISTANCIA
716184065040 Dun14: 8716184065064 Unidades de embalaje: 6 Cdigo River:
7608321280 20/80

ONEFORALL**URC2981**MANDOUNIVERSALPARA8DISPOSITIVOSOFA8

Unmandoparaochodispositivos. Controla tu televisor, TDT ...

lang:i-klingson score:9 filesize: 4.11 M page_count: 80 document date: 2021-11-03