Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hot Wheels V1983

Hot Wheels Super 6-Lane Raceway Instruction Manual

Model: V1983 | Brand: Hot Wheels

Introduction

Welcome to the ultimate racing experience with the Hot Wheels Super 6-Lane Raceway! This manual provides essential information for setting up, operating, and maintaining your track set. Designed for thrilling 6-car races, this 8-foot track features exciting lights and sounds to enhance the racing action. Please read through these instructions carefully to ensure safe and optimal use of your product.

Safety Information

Warning: Choking Hazard - Small Parts. Not for children under 3 years.
Legal Disclaimer: This product is suitable for ages 5 years and up. Requires 3 AA (LR6) batteries, not included. Dispose of batteries safely. Conforms to the safety requirements of ASTM F963.

What's in the Box

Your Hot Wheels Super 6-Lane Raceway package includes the following components:

- Hot Wheels Super 6-Lane Raceway track assembly
- 6 1:64 Scale Hot Wheels vehicles



Figure 1: Packaging of the Hot Wheels Super 6-Lane Raceway, illustrating the track and included vehicles.

Setup Instructions

1. **Unpack Components:** Carefully remove all track pieces and vehicles from the packaging.
2. **Battery Installation:** Locate the battery compartment on the main starting gate unit. Insert 3 AA (LR6) batteries, ensuring correct polarity. Close the battery compartment securely.
3. **Assemble Track:** Unfold the 8-foot track sections. The track is designed to easily extend and lock into place. Ensure all connections are secure to prevent track separation during play.
4. **Positioning:** Place the assembled track on a flat, stable surface. The track features supports that provide stability for racing.





Figure 2: The fully extended 8-foot Hot Wheels Super 6-Lane Raceway, ready for action.



Figure 3: The track in its folded configuration, demonstrating its compact design for easy storage and portability.

Operating Instructions

1. **Power On:** Ensure batteries are installed and the power switch (if present) is in the ON position.
2. **Load Cars:** Place one Hot Wheels vehicle into each of the six starting lanes at the top of the track. Ensure cars are seated properly in their lanes.
3. **Initiate Race:** Press the fair-start release lever located at the starting gate. This will simultaneously release all six cars down the track.
4. **Observe Race:** Watch as the cars speed towards the finish line. The track features realistic lights and sounds that activate during the race.
5. **Winner Announcement:** Upon reaching the finish line, the system will automatically detect the winner. The announcer will call out the winning lane number, and its corresponding light will illuminate on the display.






Figure 4: Multiple Hot Wheels cars simultaneously racing down the six lanes of the track, highlighting the competitive aspect.


PLAYSET INCLUDES SIX VEHICLES. ADDITIONAL VEHICLES SOLD SEPARATELY.

Figure 5: Two children preparing to race, placing their Hot Wheels vehicles at the starting gate of the raceway.

Maintenance

- **Cleaning:** Wipe the track and vehicles with a soft, dry cloth to remove dust and debris. Do not use harsh chemicals or abrasive cleaners.
- **Battery Replacement:** If lights and sounds become dim or stop working, replace the 3 AA batteries in the main unit. Always use new batteries of the same type.
- **Storage:** When not in use, fold the track as shown in Figure 3 for compact storage. Store in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect all track connections and components for any signs of wear or damage. Discontinue use if any parts are broken or compromised.

Troubleshooting

Problem	Possible Cause	Solution
Lights and sounds not working.	Batteries are dead or incorrectly installed.	Check battery polarity and replace with new AA batteries.
Cars are not racing smoothly.	Track sections are not fully connected or debris is on the track.	Ensure all track connections are secure. Clean the track surface.
Winner detection is inconsistent.	Obstruction at the finish line or low batteries.	Clear any obstructions from the finish line sensor. Replace batteries.

Specifications

Feature	Detail
Product Dimensions	95.5 x 9.25 x 18.75 inches
Item Weight	8.25 pounds
Model Number	V1983
Recommended Age	5 years and up
Batteries Required	3 AA batteries (not included)
Manufacturer	Mattel

Warranty and Support

This product is covered by a manufacturer's warranty. For detailed warranty information, please refer to the documentation included with your purchase or visit the official Hot Wheels website. For technical support, replacement parts, or any other inquiries, please contact Mattel Customer Service.
You can also find additional resources and FAQs on the Hot Wheels Store on Amazon.

© 2024 Hot Wheels. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004U5C392

More documents and user manuals: **https://manuals.plus/**