

[Manuals.plus](#) /

› [Hasbro](#) /

› Bop It XT Electronic Game Instruction Manual

Hasbro 28935

Bop It XT Electronic Game Instruction Manual

Model: 28935 | Brand: Hasbro

INTRODUCTION

The Bop It XT game is an interactive electronic game designed to challenge players with a series of commands requiring quick reactions. Players must perform six actions: Bop it, Twist it, Pull it, Spin it, Flick it, and Shake it, in response to the game's voice commands. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Bop It XT game.



Image: The Bop It XT game unit, featuring a central 'Bop It!' button, a yellow 'Pull It' handle, a green 'Flick It' lever, an orange 'Spin It' wheel, and a blue 'Shake It' end piece. The device is white with gray grip areas.

SETUP

Battery Installation

1. Locate the battery compartment on the back of the Bop It XT unit.
2. Using a Phillips head screwdriver, open the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-). The game unit includes these batteries.
4. Replace the battery compartment cover and secure it with the screw.

Note: The Bop It XT game is recommended for ages 8 years and up.

OPERATING INSTRUCTIONS

The Bop It XT game features fast-paced play with various modes and difficulty settings.

Basic Gameplay

1. Press the central 'Bop It!' button to start the game.
2. The game will issue a command: "Bop it!", "Twist it!", "Pull it!", "Spin it!", "Flick it!", or "Shake it!".

- 3. Perform the commanded action as quickly and accurately as possible.
- 4. A correct response will be followed by a sound and another command. An incorrect or slow response will end your turn.
- 5. Score 100 points to unlock more challenging levels.

Game Modes and Settings

- **Solo Play:** Play by yourself to achieve high scores.
- **Group Play (Party Mode):** Engage with friends. In Party Mode, when a body part is called out, the 'Bop It!' button must be hit with that specific body part.
- **Difficulty Levels:** The game offers Novice, Expert, Master, and Pro levels. Players advance to the next level after completing 100 correct consecutive commands.
- **Volume Control:** Three volume options are available.
- **Headphone Jack:** A headphone jack is included for quiet play.
- **'SHAKE IT!' Feature:** This feature can be toggled on or off to adjust difficulty.

MAINTENANCE

- Keep the Bop It XT unit dry and clean. Wipe with a soft, dry cloth.
- Avoid exposing the game to harsh chemicals, especially those containing acetone or similar solvents, as these can react with the plastic components and cause stickiness or damage.
- When not in use for extended periods, remove the batteries to prevent leakage.

TROUBLESHOOTING

- **Game does not turn on:**
 - Ensure batteries are inserted correctly with the proper polarity.
 - Replace old batteries with new AAA alkaline batteries.
 - Check that the battery compartment cover is securely closed.
- **Commands are unclear or sounds are distorted:**
 - Adjust the volume settings.
 - Ensure the speaker is not obstructed.
 - If using headphones, check the headphone connection and the headphones themselves.
- **Game components (e.g., knobs) feel sticky:**
 - This can occur if the plastic has been exposed to certain chemicals. Clean gently with a damp cloth and mild soap, then dry thoroughly. Avoid strong cleaning agents.

SPECIFICATIONS

Feature	Detail
Item Model Number	28935
Manufacturer	Hasbro

Feature	Detail
Recommended Age	8 years and up
Product Dimensions	10.75 x 2.99 x 10.63 inches
Item Weight	0.01 ounces
Power Source	Battery Powered
Batteries Required	3 AAA batteries (included)
Battery Description	Alkaline
Material	Plastic
Form Factor	Handheld
UPC	053569600563, 698887679237, 653569600565
Release Date	July 19, 2011

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the official Hasbro website or contact Hasbro customer service directly. Warranty terms and conditions may vary by region and purchase date.

You can typically find support contact information on the manufacturer's packaging or their official website.

© 2023 Hasbro. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question