

[Manuals.plus](#) /

› [Beautyrest](#) /

› Beautyrest Hi-Loft Full Size Air Mattress User Manual

Beautyrest Hi-Loft

Beautyrest Hi-Loft Full Size Air Mattress User Manual

Model: Hi-Loft (HDDOD7112DB)

INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Beautyrest Hi-Loft Full Size Air Mattress. Designed for comfort and convenience, this air mattress features vertical beam construction, edge support, and an external electric pump for quick inflation and deflation. Please read these instructions thoroughly before initial use to ensure proper function and longevity of your product.



Image: The Beautyrest Hi-Loft Full Size Air Mattress, showcasing its plush top and blue base.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of injury, fire, or electric shock, always follow these basic safety precautions:

- Do not overinflate the mattress. Overinflation can cause air to leak and potentially damage the product.
- Keep the mattress away from sharp objects, heat sources, and open flames.
- Ensure the pump is disconnected from the power source when not in use.
- This product contains chemicals known to the State of California to cause cancer and reproductive harm. For more information, visit WWW.P65WARNINGS.CA.GOV.

PACKAGE CONTENTS

Verify that all items are present before proceeding with setup:

- Beautyrest Hi-Loft Air Mattress (Full Size)
- Electric Express Pump
- Multi-Use Adapter for pump
- Nylon Carrying Bag

- Instruction Manual (this document)



Image: The included nylon carrying bag, designed for convenient storage and transport of the deflated air mattress.

SETUP: INFLATION INSTRUCTIONS


1. **Unpack:** Remove the air mattress from its carrying bag and unroll it on a clean, flat surface, free from sharp objects.
2. **Connect Pump:** Locate the inflation valve on the mattress. Attach the Electric Express Pump to the valve, ensuring

a secure fit.

3. **Inflate:** Plug the pump into a standard electrical outlet. Turn on the pump to begin inflation. The mattress will inflate hands-free within seconds.
4. **Initial Stretch:** For the first few uses, the vinyl material may stretch, causing the mattress to feel softer. This is normal. Simply add more air to achieve your desired firmness.
5. **Do Not Overinflate:** Monitor the inflation process to prevent overinflation, which can damage the mattress. Stop the pump once the desired firmness is reached.
6. **Seal Valve:** Once inflated, securely close the inflation valve to prevent air leakage.



Image: The Electric Express Pump, used for quick inflation and deflation of the air mattress. A multi-use adapter is also shown.



Video: An instructional video demonstrating the inflation and deflation process of a similar air mattress model.

OPERATING YOUR AIR MATTRESS


Adjusting Firmness

The Beautyrest Hi-Loft air mattress allows for adjustable firmness, from firm to plush, using a one-touch control. This control is typically located on the side of the mattress or integrated with the pump mechanism.

- To increase firmness, add more air using the Electric Express Pump.
- To decrease firmness, slightly open the valve or use the deflate function of the pump to release a small amount of air.

Adjustable Comfort

Adjust from firm to plush with the patented one-touch control.



Powerful Express Pump


Includes express pump that inflates and deflates in seconds, plus bonus adapter for other inflatables.

Image: Detail of the one-touch control for adjusting mattress firmness, allowing users to select between plush and firm settings.

Key Features for Comfort and Stability

- **Vertical Beam Construction:** This design provides stable support and minimizes rocking or swaying motion.
- **Edge Support:** Built-in edge support helps prevent rolling off the mattress during sleep.
- **Plush Velveteen Sleep Surface:** The soft top surface helps keep sheets in place and enhances comfort.
- **Recessed Lower Panel:** A 2-inch recessed lower panel creates a suction effect with the floor, adding stability.

Vertical Beaming



**Upper Angle
Beam Construction**

**Lower Angle
Beam Construction**



**Sturdy
construction**

Supports up to 700 lbs

Image: An illustrative diagram highlighting the vertical beaming and upper/lower angle beam construction for stability and edge support.

CARE AND MAINTENANCE

Cleaning

To clean your Beautyrest Hi-Loft air mattress, use a damp cloth and mild soap to spot clean any soiled areas. Do not use harsh chemicals or abrasive cleaners, as these can damage the vinyl material.

Storage

1. **Deflate Completely:** Use the deflate function of the Electric Express Pump to remove all air from the mattress. Ensure it is fully deflated to prevent damage during storage.
2. **Fold/Roll:** Carefully fold or roll the deflated mattress.
3. **Store in Bag:** Place the folded or rolled mattress into the provided nylon carrying bag.

4. **Location:** Store the mattress in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mattress loses air or feels soft after initial inflation.	Vinyl material stretching (normal for new air mattresses).	Add more air using the Electric Express Pump to reach desired firmness. This may be necessary for the first few uses.
Mattress deflates rapidly.	- Valve not securely closed. - Small puncture or leak. - Pump not properly attached during inflation.	- Ensure the inflation valve is fully sealed after inflation. - Inspect the mattress surface for any punctures. Use a soapy water solution to locate small leaks (bubbles will form). Patch if necessary. - Verify the pump connection is tight during inflation.
Pump not working.	- Not plugged in correctly. - Power outlet issue.	- Ensure the pump is securely plugged into a functional electrical outlet. - Test the outlet with another device.

PRODUCT SPECIFICATIONS

Brand	Beautyrest
Model Name	Hi-Loft
Item Model Number	HDDOD7112DB
Size	Full
Product Dimensions	74"L x 53"W x 16"Th
Item Thickness	16 Inches
Item Weight	13.04 pounds
Capacity	317.51 Kilograms (approx. 700 lbs)
Material	Velveteen (top), Puncture Resistant Vinyl (body)
Special Feature	Heavy Duty, Inflatable, Vertical Beam Construction, Edge Support
Water Resistance Level	Waterproof
UPC	612650551704, 612650120825

WARRANTY AND SUPPORT

For warranty information or customer support regarding your Beautyrest Hi-Loft Air Mattress, please refer to the documentation included with your purchase or visit the official Beautyrest website. You may also contact their customer service department directly for assistance with product inquiries, parts, or service.

Manufacturer: Simmons

Beautyrest Store: [Visit the Beautyrest Store on Amazon](#)

© 2023 Beautyrest. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question