

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Timex](#) /

› [Timex Weekender 38mm Unisex Analog Watch \(Model T2N651\) Instruction Manual](#)

Timex T2N651

Timex Weekender 38mm Unisex Analog Watch (Model T2N651) Instruction Manual

Comprehensive guide for your Timex Weekender watch, including setup, operation, maintenance, and specifications.

1. PRODUCT OVERVIEW

The Timex Weekender 38mm Unisex Analog Watch (Model T2N651) combines classic field-inspired design with practical features for everyday wear. It features a durable brass case, a clear dial with 24-hour military time, and the signature INDIGLO backlight for visibility in low light conditions. The adjustable nylon slip-thru strap ensures a comfortable fit.





Figure 1: Front view of the Timex Weekender 38mm Unisex Analog Watch with a cream dial and green nylon strap.

Key Features:

- **Field-Inspired Design:** Cream dial with full Arabic numerals and 24-hour military time.
- **Polished Case:** Silver-tone 38 mm brass case with mineral glass crystal.
- **Comfort Fit:** Adjustable 20 mm nylon slip-thru strap, fits wrists up to 8 inches.
- **INDIGLO Backlight:** For time visibility in the dark.
- **Water-Resistant:** Safe to 30 m / 100 ft (withstands splashes or brief immersion, not suitable for swimming or bathing).

2. SETUP

Before using your Timex Weekender watch, follow these steps to activate it and set the correct time.

2.1 Initial Activation

Your watch may arrive with a plastic crown guard to preserve battery life during shipping. Remove this guard before first use.

1. Carefully remove the plastic crown guard from under the crown (the small knob on the side of the watch).
2. Push the crown fully inward towards the watch case. The second hand will begin to move, indicating the watch is active.

Your browser does not support the video tag.

Video 1: Instructions on removing the crown guard and activating the watch.

2.2 Setting the Time

1. Pull the crown outward to the time-setting position. The second hand will stop.
2. Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
3. Once the correct time is set, push the crown fully back into the watch case. The second hand will resume movement.

Your browser does not support the video tag.

Video 2: Demonstration of setting the time on a Timex Weekender watch.

3. OPERATING INSTRUCTIONS

3.1 Using the INDIGLO Backlight

The INDIGLO backlight illuminates the watch dial for easy reading in low-light conditions or darkness.

- To activate the INDIGLO backlight, simply press and hold the crown (the same knob used for setting time).
- Release the crown to turn off the backlight.

3.2 Wearing the Watch

The adjustable slip-thru strap allows for a comfortable and secure fit on various wrist sizes.



Figure 2: The Timex Weekender watch worn on a wrist, showcasing its fit.

To adjust the strap, slide the watch through the loops of the strap until it is centered on your wrist. Then, adjust the buckle for a snug yet comfortable fit. The slip-thru design allows for easy interchangeability with other 20mm straps.

Your browser does not support the video tag.

Video 3: Demonstration of the slip-thru strap design and how to wear the watch.

4. MAINTENANCE

4.1 Water Resistance

The Timex Weekender watch is water-resistant to 30 meters (100 feet). This means it is suitable for splashes, rain, or brief immersion in water. It is **not** recommended for swimming, showering, or diving, as prolonged exposure to water pressure or hot water can compromise the seals.

4.2 Strap Care

The nylon strap can be cleaned with mild soap and water. Allow it to air dry completely before reattaching to the watch. For leather straps (if applicable), avoid prolonged exposure to water and direct sunlight to prevent damage and discoloration.

4.3 Battery Replacement

The watch is powered by 1 Lithium Metal battery (included). Battery life can vary, but typically lasts several years. When the watch stops, it indicates the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

5. TROUBLESHOOTING

5.1 Watch Not Ticking

If your watch is not ticking upon arrival, ensure the plastic crown guard has been removed and the crown is fully pushed in. If it still does not tick, the battery may be depleted and require replacement.

5.2 Loud Ticking Sound

Some users may notice a distinct ticking sound from the watch movement. This is a characteristic of certain quartz movements and is generally considered normal for this model. It does not indicate a defect or malfunction.

6. SPECIFICATIONS







Feature	Detail
Model Number	T2N651
Case Diameter	38 mm
Case Material	Brass
Crystal Material	Mineral Glass
Strap Material	Nylon
Strap Width	20 mm
Water Resistance	30 m (100 ft)
Movement	Quartz
Backlight	INDIGLO
Battery Type	1 Lithium Metal battery (included)
Product Dimensions	3.8 x 3 x 3 inches; 1.6 ounces

7. WARRANTY & SUPPORT

For warranty information, product support, or service inquiries, please refer to the official Timex website or contact Timex customer service directly. Specific warranty terms and conditions may apply.

You can visit the official [Timex Store on Amazon](#) for more product information and support resources.

Related Documents - T2N651

	<p>Timex Watch User Manual: Features, Operation, and Care</p> <p>Comprehensive user manual for Timex watches, detailing features like analog and digital time, multiple time zones, alarms, chronographs, timers, water resistance, and bracelet adjustment.</p>
	<p>Timex Combo Watch User Manual and Guide</p> <p>Comprehensive user manual and guide for the Timex Combo Watch, covering features, basic operation, time setting, stopwatch, alarm, INDIGLO night-light, water and shock resistance, battery replacement, and international warranty.</p>
	<p>Timex Analog Watch User Manual - Features, Settings, and Care</p> <p>Comprehensive user guide for Timex Analog watches, covering setup, features like INDIGLO® Night-Light, water resistance, alarms, perpetual calendar, and maintenance. Available in multiple languages.</p>
	<p>Timex Higher-Function Analog Watch User Guide</p> <p>Explore the features and operation of Timex Higher-Function Analog watches with this comprehensive user guide. Learn about time setting, alarms, chronograph functions, Indiglo Night-Light, water resistance, and more. Available in multiple languages.</p>
	<p>Timex W-209 Watch User Manual: Features, Operation, and Warranty</p> <p>Comprehensive guide to operating your Timex W-209 watch, covering time setting, chronograph, timer, alarms, occasions, INDIGLO night-light, water resistance, battery, and international warranty information.</p>
	<p>TIMEX Higher-Function Analog Watch User Guide (991-096572-01)</p> <p>Comprehensive user guide for the TIMEX Higher-Function Analog watch (model 991-096572-01). Learn to operate its features including Indiglo night-light, chronograph, alarms, and water resistance. Includes instructions for analog and digital time settings, bracelet adjustment, and warranty information.</p>