

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Zippo](#) /

› [Zippo 45016 Digital Quartz Watch User Manual](#)

Zippo 45016

Zippo 45016 Digital Quartz Watch

USER MANUAL

Model: 45016

Introduction

Thank you for choosing the Zippo 45016 Digital Quartz Watch. This manual provides detailed instructions to help you understand and operate your new watch effectively. Please read this manual thoroughly before use and keep it for future reference.

Safety Information

- Do not attempt to open the watch case or replace the battery yourself, as this may void the warranty and damage the watch.
- Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- Clean the watch with a soft, dry cloth. Do not use chemical cleaners.
- While the watch is designed for daily wear, avoid direct impact or dropping it.

Setup

Initial Power-On and Time Setting

Your Zippo 45016 watch comes with a pre-installed battery. Upon first use, you may need to set the current time and date.

1. Locate the mode button (usually on the bottom left) and the adjustment buttons (usually on the right side).
2. Press the mode button repeatedly until the time setting mode is displayed. Digits for hours or minutes will typically flash.
3. Use the adjustment buttons (e.g., 'Start/Stop' or 'Reset') to increase or decrease the flashing value.
4. Press the mode button again to move to the next setting (minutes, year, month, day).
5. Once all settings are correct, press the mode button one last time to exit the setting mode.



Image: Zippo 45016 Digital Quartz Watch. This image shows the watch face and strap, illustrating its general appearance and button placement for setup and operation.

Operating Instructions

Basic Time Display

In the default mode, the watch displays the current time (hours, minutes, seconds) and often the day of the week and date.

Light Function

To illuminate the display in low-light conditions:

- Press the 'Light' button (typically located on the top left or top right of the watch).
- The backlight will activate for a few seconds.

Lap Timer (Stopwatch) Function

The lap timer allows you to measure elapsed time.

1. Press the 'Mode' button until the stopwatch display appears (usually indicated by 'STW' or a stopwatch icon).
2. Press the 'Start/Stop' button (often on the top right) to begin timing.
3. To record a lap time without stopping the main timer, press the 'Lap' or 'Reset' button. The lap time will display briefly.
4. Press 'Start/Stop' again to pause the timer.
5. Press 'Reset' (often on the bottom right) while the timer is paused to clear the stopwatch to zero.

Maintenance

Cleaning Your Watch

To maintain the appearance of your watch:

- Wipe the watch case and strap with a soft, slightly damp cloth.
- For stubborn dirt, use a mild soap solution, then wipe clean with a damp cloth and dry thoroughly.
- Avoid using abrasive cleaners or solvents, as these can damage the watch's finish.

Battery Replacement

The Zippo 45016 uses a product-specific battery. When the display becomes dim or the watch stops functioning, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and functionality.

Troubleshooting

Problem	Possible Cause	Solution
Watch display is blank	Low or dead battery	Replace the battery (professional service recommended).
Incorrect time displayed	Time not set correctly or reset after battery change	Refer to the 'Time Setting' section to adjust the time.
Buttons are unresponsive	Dirt or debris under buttons, or internal malfunction	Clean around buttons. If issue persists, contact customer support.

Specifications

- **Model Number:** 45016
- **Brand:** Zippo
- **Movement:** Digital Quartz
- **Battery:** 1 product-specific battery (included)
- **Product Dimensions:** 25.4 x 4.9 x 0.64 cm
- **Weight:** 54.43 g
- **ASIN:** B004WMEY9K

Warranty and Support

For warranty information, please refer to the warranty card included with your purchase or visit the official Zippo website. If you require technical assistance or have questions not covered in this manual, please contact Zippo customer support through their official channels.