

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Craftmade](#) /

> [Craftmade LK406-BN-LED Universal 4-Light Kit Instruction Manual](#)

## Craftmade LK406-BN-LED

# Craftmade LK406-BN-LED Universal 4-Light Kit Instruction Manual

Model: LK406-BN-LED

## IMPORTANT SAFETY INFORMATION

---

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or other hazards that could cause injury or property damage.

- **WARNING:** To avoid possible electric shock, before installing your light kit, disconnect power by turning off the circuit breakers to the outlet box associated with the wall switch location.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Use only with ceiling fans approved for light kit installation.
- Ensure all electrical connections are secure and comply with local codes and ordinances.
- Do not install this light kit in wet or damp locations. This product is rated for dry locations only.
- **Proposition 65 Warning:** Please check your local laws before purchasing this product.

## PRODUCT OVERVIEW

---

The Craftmade LK406-BN-LED is a universal 4-light kit designed to enhance your ceiling fan with efficient LED lighting. Featuring a brushed satin nickel finish and alabaster glass shades, this kit provides a transitional style suitable for various home interiors. It includes four LED light sources, offering a total of 36 watts of illumination.



Image: Craftmade LK406-BN-LED Universal 4-Light Kit. This image displays the light kit featuring a brushed satin nickel base, four arms extending outwards, each holding an alabaster glass shade. The overall design is round and transitional.

### Key Features:

- Universal design for compatibility with various ceiling fans.
- Four integrated LED light sources for energy-efficient illumination.
- Brushed Satin Nickel finish for a modern, elegant appearance.
- Alabaster glass shades provide diffused, warm light.
- Designed for indoor, dry location use.
- Remote control compatibility for convenient operation.

### PACKAGE CONTENTS

---

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not attempt to install the product. Contact customer support for assistance.

- Light Kit Assembly (LK406-BN-LED)
- Alabaster Glass Shades (4 pieces)
- Mounting Hardware (screws, washers, wire nuts)
- Installation Instructions (this manual)

### SPECIFICATIONS

---

Feature	Specification
Model Number	LK406-BN-LED
Brand	Craftmade

Feature	Specification
Finish	Brushed Satin Nickel
Shade Material	Alabaster Glass
Light Source Type	LED
Number of Light Sources	4
Total Wattage	36 Watts (as per product title, with individual bulbs rated at 13 Watts)
Individual Bulb Wattage	13 Watts
Brightness	182 Lumens per bulb
Voltage	120 Volts
Product Dimensions	19"L x 19"W x 7.75"H
Item Weight	13.82 Pounds
Indoor/Outdoor Usage	Indoor
Safety Listing	Dry
Control Method	Remote Control
Bulb Base	E26

## INSTALLATION INSTRUCTIONS

---

This light kit is designed for universal compatibility with most ceiling fans. Specific installation steps may vary slightly depending on your ceiling fan model. Always refer to your ceiling fan's instruction manual for specific wiring and mounting details.

### 1. Prepare for Installation:

- Turn off power at the circuit breaker to avoid electrical shock.
- Ensure the ceiling fan is securely mounted and capable of supporting the additional weight of the light kit.

### 2. Remove Existing Light Kit (if applicable):

- Carefully disconnect any existing light kit from the ceiling fan.
- Remove any mounting brackets or hardware associated with the old light kit.

### 3. Connect Wiring:

- Identify the light kit wires (typically white for neutral, black for hot, and green/bare copper for ground).
- Connect the light kit wires to the corresponding wires from the ceiling fan using the provided wire nuts. Ensure all connections are tight and secure.
- Refer to your ceiling fan's manual for specific wiring color codes if unsure.

### 4. Mount the Light Kit:

- Align the light kit with the mounting holes on the bottom of your ceiling fan.
- Secure the light kit to the fan using the screws provided. Do not overtighten.

### 5. Install Glass Shades:

- Carefully attach each alabaster glass shade to its respective light socket.
- Ensure shades are securely fastened but do not overtighten to prevent cracking.

### 6. Restore Power:

- Once installation is complete and all connections are checked, restore power at the circuit breaker.
- Test the light kit to ensure proper operation.

## OPERATING INSTRUCTIONS

---

The Craftmade LK406-BN-LED light kit is designed for simple operation, typically controlled via a wall switch or a compatible ceiling fan remote control.

- **Wall Switch Operation:** If connected to a dedicated wall switch, simply toggle the switch to turn the lights ON or OFF.
- **Remote Control Operation:** If your ceiling fan system includes a remote control with light functions, use the designated light button(s) to control the light kit. Refer to your ceiling fan's remote control manual for specific button functions.

The integrated LED lights are not dimmable unless explicitly stated by your ceiling fan's control system and compatible dimmer. Using an incompatible dimmer may damage the LED components.

## MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your light kit.

- **Cleaning:**
  - Before cleaning, ensure the power to the light kit is turned off at the circuit breaker.
  - Wipe the metal finish with a soft, dry cloth. Do not use abrasive cleaners or polishes, as they may damage the finish.
  - Clean glass shades with a mild glass cleaner and a soft cloth.
- **Bulb Replacement:**
  - This light kit features integrated LED light sources. These are designed for long operational life and are generally not user-replaceable.
  - If an LED light source fails prematurely, contact Craftmade customer support for assistance. Do not attempt to replace integrated LEDs yourself.

## TROUBLESHOOTING

---

If you experience issues with your Craftmade LK406-BN-LED light kit, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lights do not turn ON.	<ul style="list-style-type: none"><li>• Power is off at the circuit breaker or wall switch.</li><li>• Loose wire connections.</li><li>• Faulty light kit.</li></ul>	<ul style="list-style-type: none"><li>• Ensure power is ON at the circuit breaker and wall switch.</li><li>• Turn off power, then check and tighten all wire connections.</li><li>• Contact customer support if the issue persists after checking power and connections.</li></ul>
Lights flicker or dim.	<ul style="list-style-type: none"><li>• Incompatible dimmer switch.</li><li>• Loose wire connections.</li></ul>	<ul style="list-style-type: none"><li>• Ensure any dimmer switch used is compatible with LED lighting.</li><li>• Turn off power, then check and tighten all wire connections.</li></ul>
Remote control does not operate lights.	<ul style="list-style-type: none"><li>• Remote control batteries are dead.</li><li>• Remote control not paired with the fan/light kit.</li></ul>	<ul style="list-style-type: none"><li>• Replace remote control batteries.</li><li>• Refer to your ceiling fan's manual for remote pairing instructions.</li></ul>

## WARRANTY INFORMATION

---

All products purchased have a 30-day replacement parts policy to ensure a fully working item. All products are covered under a 1-year warranty when purchased on Amazon. The warranty period begins on the day the product is originally shipped. The warranty covers all of the items and conditions identified in the original manufacturer's warranty. Some of the items specifically not covered by the warranty are loss and theft, water damage, customer abuse, and finish deterioration due to UV or coastal exposure.

## CUSTOMER SUPPORT

---

For further assistance, missing parts, or warranty claims, please contact Craftmade customer support. Keep your purchase receipt and model number (LK406-BN-LED) readily available when contacting support.

You can typically find contact information on the manufacturer's official website or through your retailer.

