

[Manuals.plus](#) /

› [Motocaddy](#) /

› Motocaddy Adjustable, Easy-Fit Golf Trolley Device Holder Instruction Manual

Motocaddy ACDC003

Motocaddy Adjustable, Easy-Fit Golf Trolley Device Holder

Model: ACDC003

PRODUCT OVERVIEW

The Motocaddy Adjustable Device Holder is designed to securely attach your smartphone or other compatible devices to your Motocaddy golf trolley. Its robust design ensures your device remains stable during your round, providing easy access to golf apps, GPS, or other essential information.

- Fully adjustable device holder for various device sizes.
- Supports both vertical and horizontal rotation for optimal viewing.
- Features a quick adjustment mechanism for effortless positioning.
- Designed for easy assembly and disassembly.
- Compatible with the Motocaddy accessory station and the M1 Lite push trolley.

SETUP INSTRUCTIONS

Follow these steps to properly install your Motocaddy Device Holder:

1. Identify the accessory station or handlebar on your Motocaddy golf trolley where the holder will be mounted.
2. Align the holder's mounting bracket with the designated attachment point on the trolley.
3. Secure the holder firmly using the quick adjustment mechanism or tightening knob until it is stable and does not wobble.
4. Adjust the cradle arms to fit your smartphone or device. Ensure the device is held securely without excessive pressure.
5. Test the stability of the holder and your device before use on the course.



Image: The Motocaddy Adjustable Device Holder securely mounted on a golf trolley, demonstrating its position and how it holds a smartphone. A water bottle holder is also visible on the trolley.

OPERATING INSTRUCTIONS

Once installed, operating the device holder is straightforward:

- **Inserting Your Device:** Gently expand the adjustable arms of the cradle and place your smartphone or compatible device into the holder. Release the arms to allow them to grip the device securely.
- **Adjusting Orientation:** The holder allows for both vertical (portrait) and horizontal (landscape) rotation. Simply rotate your device within the cradle to achieve your preferred viewing angle.
- **Adjusting Angle:** Use the quick adjustment mechanism (often a ball joint or pivot) to tilt and swivel the device holder to your desired viewing angle. Tighten the mechanism to lock the angle in place.
- **Removing Your Device:** Gently expand the cradle arms to release your device.

MAINTENANCE

To ensure the longevity and optimal performance of your device holder, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the holder with a soft, damp cloth to remove dirt and debris. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic material.
- **Storage:** When not in use, store the device holder in a clean, dry place away from extreme temperatures.

- **Water Exposure:** This product is **not waterproof**. Avoid exposing it to heavy rain or submerging it in water. If it gets wet, dry it thoroughly before storage or next use.
- **Check Connections:** Periodically check that all screws and adjustment mechanisms are tight to prevent loosening during use.

TROUBLESHOOTING

If you encounter any issues with your Motocaddy Device Holder, consider the following common solutions:

- **Device Not Holding Securely:**
 - Ensure the adjustable arms are fully gripping your device.
 - Verify that the device's dimensions are within the holder's compatible range.
- **Holder Feels Loose on Trolley:**
 - Re-tighten the mounting mechanism to ensure it is securely fastened to the trolley's accessory station or handlebar.
 - Check for any obstructions preventing a tight fit.
- **Difficulty Adjusting Angle/Rotation:**
 - Ensure the quick adjustment mechanism is loosened sufficiently before attempting to adjust.
 - Avoid forcing the mechanism; if stiff, check for dirt or debris.

If problems persist, please refer to the warranty and support information.

SPECIFICATIONS

Feature	Detail
Model Number	ACDC003
Product Dimensions (L x W x H)	20 x 12.5 x 16.5 cm
Item Weight	180 g
Color	Black
Material	Plastic
Special Features	Adjustable
Mount Type	Handlebar
Compatible Devices	Smartphones
Compatible Phone Models	Universal
Waterproof Level	Not Waterproof

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the documentation included with your purchase or visit the official Motocaddy website. Motocaddy products typically come with a manufacturer's warranty covering defects in materials and workmanship.

If you require technical support or have questions not covered in this manual, please contact Motocaddy customer service through their official website or the contact details provided with your product.