Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Signature Design by Ashley T719-7

Signature Design by Ashley Cross Island End Table User Manual

Model: T719-7

1. Introduction

This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your Signature Design by Ashley Cross Island Traditional Chair Side End Table. Please read these instructions carefully before assembly and use to ensure proper setup and longevity of your furniture.

The Cross Island End Table features a traditional design with mortise-and-tenon accents and two fixed shelves, offering both style and practical storage. It is constructed from wood with an oak finish.



Image 1.1: The Signature Design by Ashley Cross Island Traditional Chair Side End Table.

2. Setup and Assembly

Your Cross Island End Table requires assembly. Detailed instructions, tools, and hardware are included with the product packaging. It is recommended that **two people** perform the assembly for ease and safety.

2.1. Before You Begin

- Unpack all components and hardware. Verify that all parts are present according to the included parts list.
- Clear a spacious, clean area for assembly to prevent damage to the furniture or flooring.
- Keep children and pets away from the assembly area.

2.2. Assembly Overview

Follow the step-by-step instructions provided in your product's assembly guide. Generally, assembly involves attaching the legs to the top and bottom shelves using the provided hardware. The design incorporates mortise-and-tenon accents for authenticity and stability.




Image 2.1: Diagram showing the dimensions of the end table (Height: 25", Width: 17", Depth: 26").

2.3. Product Video

Watch this video for a visual overview of the product's features and design, which may assist with understanding its construction.

Your browser does not support the video tag.

Video 2.2: A 19-second video showcasing the Signature Design by Ashley Cross Island End Table from various angles.

3. Operating (Usage)

The Cross Island End Table is designed for residential indoor use. Its compact size makes it suitable for small

spaces, such as beside a sofa or chair.

- **Placement:** Position the table on a flat, stable surface. Ensure it does not obstruct walkways or doors.
- **Storage:** Utilize the two fixed shelves for decorative accents, books, remote controls, or other small items. The open concept design allows for easy access and display.
- **Weight Capacity:** Do not exceed the maximum weight recommendation of 50 pounds on the tabletop or shelves.



Image 3.1: Close-up view of the table's leg and shelf construction, highlighting the mortise-and-tenon accents.

4. Maintenance

Proper care will help maintain the appearance and extend the life of your end table.

- **Cleaning:** Wipe surfaces with a soft, dry cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Protection:** The table's finish can be susceptible to scratches and moisture rings. Always use coasters under beverages and placemats or protective pads under decorative items.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Humidity:** Maintain a consistent humidity level in your home to prevent wood from cracking or warping.



Image 4.1: Detail of the table's top surface, showing the wood grain and finish.

5. Troubleshooting

5.1. Table Wobbles

- **Uneven Floor:** If the floor surface is uneven, try repositioning the table. For minor wobbles, a small furniture pad or felt glider can be placed under the shorter leg.
- **Loose Hardware:** Check all assembly screws and bolts. Gently tighten any loose connections. Do not overtighten, as this can damage the wood.

6. Specifications

Brand	Signature Design by Ashley
Model Number	T719-7
Product Dimensions	26"D x 17"W x 25"H
Item Weight	35.3 pounds
Maximum Weight Recommendation	50 pounds
Frame Material	Wood
Furniture Finish	Oak
Color	Brown Oak Stain Finish
Number of Shelves	2

Recommended People for Assembly	2
Indoor/Outdoor Usage	Indoor
GTIN / UPC	024052106817

7. Warranty and Support

This product comes with a **one-year limited manufacturer's warranty**. For specific details regarding warranty coverage or to obtain support, please refer to the documentation included with your purchase or contact Signature Design by Ashley directly.
You can also visit the official Signature Design by Ashley Store for more information and to explore other products.

© 2023 Signature Design by Ashley. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004YMWES6

More documents and user manuals: **https://manuals.plus/**