



[Manuals.plus](#) /

› [Crayola](#) /

› Crayola Model Magic Jewelry Studio Instruction Manual

Crayola 23-2436

Crayola Model Magic Jewelry Studio Instruction Manual

Model: 23-2436

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of the Crayola Model Magic Jewelry Studio. Please read all instructions carefully before use to ensure proper and safe operation.

PACKAGE CONTENTS

Verify that all components listed below are present in your package. If any items are missing or damaged, please contact customer support.



Jewelry Boutique

WITH **MODEL MAGIC**
SOFT, SQUISHY MODELING MATERIAL

The **Crayola Jewelry Boutique** lets you create fun & fabulous accessories such as bracelets, necklaces and much more. The Jewelry Spinner swirls small amounts of Model Magic into unique swirled beads. No two beads are exactly the same!



Model Magic Storage

Jewelry Spinner Plate

Removable Spinner Base

Workstation

Jewelry Storage

It's Easy!



Swirl It!



Dazzle It!



Wear It!

Make one-of-a-kind gifts for friends, host a jewelry-making party or design your own line of colorful and trendy accessories!



Includes Everything for Endless Design Possibilities!


NOTE: Contents Not To Scale




8 Packs Model Magic
Burnt Orange • Pacific Blue
Tropical Rainforest • Razzmatazz
Indigo • Dandelion • Cerulean
Light Yellow Green




5 Bracelet Charms
5 Toggle Sets



3 Pendant Charms
2 Shape Cutters



4 Earring Posts & Ear Wires



1 Elastic Cord - 36"



Bead Punch
Bead Glaze - 1oz.

Design Even More Jewelry with These Other Crayola Jewelry Boutique Styles!

For More Creative Ideas, Visit Crayola.com

Rock Royalty
Expansion Pack



Mock Candy
Expansion Pack



Image: The complete Crayola Model Magic Jewelry Studio kit, including the main unit, Model Magic packs, tools, and accessories, laid out next to its packaging box.



Image: The back of the Crayola Model Magic Jewelry Studio box, detailing the various components included such as Model Magic storage, jewelry spinner plate, removable spinner base, workstation, jewelry storage, pendant charms, shape cutters, bead dryer rack, bracelet charms, toggle sets, earring posts, bead punch, necklace cords, elastic cord, and bead glaze.

- Jewelry Spinner Plate
- Removable Spinner Base
- Workstation
- Model Magic Storage compartments
- Jewelry Storage compartments
- Model Magic packs (various colors)
- Pendant Charms
- Shape Cutters
- Bead Dryer Rack
- Bracelet Charms
- Toggle Sets
- Earring Posts & Earring Wires
- Bead Punch
- Necklace Cords
- Elastic Cord

- Bead Glaze
- Instruction Booklet

SETUP

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Familiarize Yourself:** Identify the main Jewelry Spinner unit, Model Magic packs, and various accessories.
3. **Prepare Work Area:** Ensure a clean, flat, and dry surface for assembly and use.

OPERATING INSTRUCTIONS

Creating Model Magic Beads

1. **Select Model Magic:** Choose one or more colors of Model Magic. For marbled effects, combine small pieces of different colors.
2. **Prepare Model Magic:** Knead the Model Magic until it is soft and pliable.
3. **Place in Spinner:** Open the Jewelry Spinner Plate. Place a small amount of prepared Model Magic into one of the bead molds on the spinner plate.
4. **Spin Beads:** Close the spinner plate and turn the handle to spin the Model Magic. This process shapes the Model Magic into beads and can create marbled patterns.
5. **Remove Beads:** Open the spinner plate and carefully remove the newly formed beads.
6. **Dry Beads:** Place the beads on the Bead Dryer Rack to air dry. Drying time may vary depending on bead size and humidity. Allow beads to dry completely before further handling (typically 24-72 hours).

Decorating and Assembling Jewelry

- **Shape Cutters:** Use the provided shape cutters to create unique Model Magic shapes for pendants or charms.
- **Bead Punch:** Once beads or shapes are partially dry, use the Bead Punch to create holes for stringing.
- **Bead Glaze:** Apply Bead Glaze to dried beads and charms for a shiny, protective finish. Allow glaze to dry completely.
- **Assembly:**
 - **Necklaces/Bracelets:** String dried beads and charms onto the Necklace Cords or Elastic Cord.
 - **Pendants/Charms:** Attach dried Model Magic creations to Pendant Charms or Bracelet Charms using a small amount of Model Magic or adhesive (not included).
 - **Earrings:** Attach small, dried Model Magic creations to the Earring Posts & Earring Wires.
 - **Toggle Sets:** Integrate Toggle Sets into necklaces or bracelets for closures.

MAINTENANCE

- **Cleaning:** After each use, wipe down the Jewelry Spinner Plate and other tools with a damp cloth to remove any Model Magic residue. Do not submerge the main unit in water.
- **Storage:** Store unused Model Magic in its airtight containers to prevent drying out. Store all components in a cool, dry place away from direct sunlight.
- **Model Magic Care:** If Model Magic begins to dry out, try kneading it with a few drops of water to restore pliability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Model Magic beads are not forming correctly.	Model Magic is too dry or too wet; insufficient amount used; spinner not closed properly.	Knead Model Magic with a few drops of water if dry. Ensure spinner plate is securely closed. Use an appropriate amount of Model Magic for the mold.
Beads are cracking after drying.	Too much water added during kneading; drying too quickly in a very dry environment.	Use less water. Allow beads to dry slowly in a less arid environment.
Bead Glaze is sticky after drying.	Not fully dry; applied too thickly.	Allow more drying time. Apply thinner coats.

SPECIFICATIONS

- **Model Number:** 23-2436
- **Brand:** Crayola
- **Material:** Model Magic (clay-like compound), Plastic (spinner unit)
- **Dimensions (L x W x H):** Approximately 2 x 13.5 x 12.13 inches (packaging)
- **Weight:** Approximately 0.01 Ounces (product weight, likely referring to Model Magic)
- **Age Range:** Kid (as per manufacturer recommendation)

WARRANTY AND SUPPORT

This product is guaranteed against manufacturer defects. For warranty claims or technical support, please contact Crayola customer service. Refer to the contact information provided on the product packaging or visit the official Crayola website.

Manufacturer: Crayola

UPC: 071662124366

ASIN: B004Z1JSN0