

Peanuts 165013

Peanuts Snoopy Campfire Flickering Night Light User Manual

Model: 165013

1. PRODUCT OVERVIEW

The Peanuts Snoopy Campfire Flickering Night Light is a decorative and functional lighting accessory. It features Snoopy and Woodstock gathered around a simulated flickering campfire, designed to plug directly into a standard electrical outlet. This night light provides a gentle, ambient glow with a flickering effect.



Figure 1: Peanuts Snoopy Campfire Flickering Night Light. This image shows Snoopy and Woodstock in Santa hats next to a Christmas tree and a flickering campfire, all mounted on a base with a swivel plug.

2. SAFETY INFORMATION

- For indoor use only.
- Do not expose to water or excessive moisture.
- Ensure the night light is securely plugged into a functional electrical outlet.
- Do not attempt to modify or disassemble the unit.
- Keep out of reach of small children and pets.
- Unplug from the outlet before cleaning or if not in use for extended periods.
- This product contains a glass bulb. Handle with care to prevent breakage.

3. PACKAGE CONTENTS

The package includes the following items:

- One (1) Peanuts Snoopy Campfire Flickering Night Light unit.
- One (1) pre-installed flickering bulb.

4. SETUP

1. Carefully remove the night light from its protective packaging.
2. Inspect the unit for any signs of damage. If damaged, do not use and contact customer support.
3. Locate a standard 120V AC electrical outlet.
4. Adjust the swivel plug to ensure the night light is oriented correctly for your outlet (e.g., upright).
5. Plug the night light firmly into the electrical outlet.

5. OPERATING INSTRUCTIONS

The Peanuts Snoopy Campfire Flickering Night Light features an easy-to-use on/off switch located on the front of the unit.

- To turn the night light **ON**: Locate the switch on the front of the unit and slide it to the 'ON' position. The flickering flame effect will illuminate.
- To turn the night light **OFF**: Slide the switch to the 'OFF' position. The light will extinguish.

6. MAINTENANCE

Cleaning

- Always unplug the night light from the electrical outlet before cleaning.
- Wipe the exterior surfaces with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.

Bulb Replacement

The night light uses a specialized flickering bulb. If the bulb needs replacement:

1. Unplug the night light from the electrical outlet.
2. Carefully twist and pull out the old bulb from its socket.
3. Insert a new, compatible flickering night light bulb into the socket and twist to secure. Ensure the replacement bulb is of the correct type and wattage as specified in the product specifications or on the unit itself.
4. Plug the night light back into the outlet and test its operation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Night light does not illuminate.	<ul style="list-style-type: none"> ◦ Not plugged in securely. ◦ Power outlet is not functional. ◦ On/Off switch is in 'OFF' position. ◦ Bulb is burnt out or loose. 	<ul style="list-style-type: none"> ◦ Ensure the night light is firmly plugged into the outlet. ◦ Test the outlet with another device. ◦ Slide the switch to the 'ON' position. ◦ Check the bulb; replace if necessary (refer to Section 6).
Flickering effect is inconsistent or absent.	<ul style="list-style-type: none"> ◦ Bulb is faulty or incorrect type. 	<ul style="list-style-type: none"> ◦ Replace the bulb with a compatible flickering night light bulb.

8. SPECIFICATIONS

Model Number: 165013

ASIN: B004ZBC3HS

Product Dimensions: 4.5 x 2.25 x 4.25 inches

Item Weight: 6.6 ounces

Manufacturer: Peanuts

Material: Quality acrylic materials (Polyresin)

Finish Type: Matted

Power Source: Plug-in (AC 120V)


Batteries Required: No

Included Components: Bulb

9. WARRANTY AND SUPPORT






This product is manufactured by Peanuts. For specific warranty information or customer support inquiries, please refer to the packaging or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

Related Documents - 165013



[Peanuts Two-Slice Toaster User Manual - Safety, Operation, and Care](#)

Official user manual for the Peanuts Two-Slice Toaster (Model TSTE-PEA-SN1) by Uncanny Brands. Includes safety precautions, operating instructions, cleaning guidelines, and product specifications.

	<p>Peanuts Snoopy and Woodstock Waffle Maker WM2-PEA-SN1: User Manual</p> <p>Official user manual and safety instructions for the Peanuts Snoopy and Woodstock Double-Square Waffle Maker (Model WM2-PEA-SN1) by Uncanny Brands. Learn how to operate, clean, and maintain your waffle maker.</p>
	<p>Peanuts PNTS-KM Wireless Karaoke Microphone User Manual & Guide</p> <p>User manual for the Peanuts PNTS-KM Wireless Karaoke Microphone. Features include Bluetooth connectivity, built-in speaker, voice effects, and multiple playback modes. This guide covers setup, operation, specifications, and troubleshooting.</p>
	<p>Peanuts 1-Cup Coffee Maker with 2 Ceramic Mugs - Operating and Safety Instructions</p> <p>Comprehensive operating and safety instructions for the Peanuts 1-Cup Coffee Maker with 2 Ceramic Mugs by Uncanny Brands. Learn how to set up, brew coffee, heat water, clean, and descale your appliance.</p>
	<p>PEANUTS WM5-PEA-SN1 Waffle Maker: Operating and Safety Instructions</p> <p>Comprehensive operating and safety instructions for the PEANUTS WM5-PEA-SN1 Waffle Maker by Uncanny Brands. Learn how to use, clean, and maintain your waffle maker safely.</p>
	<p>Peanuts Wireless Mouse User Manual</p> <p>User manual for the Peanuts Wireless Mouse, including product key, specifications, installation, operation, and troubleshooting.</p>