Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Warner Home Video B004ZELUV0

V - The Complete First and Second Seasons DVD Instruction Manual

Model: B004ZELUV0

Introduction

This manual provides instructions for the proper use and care of your V - The Complete First and Second Seasons DVD set. This collection includes all episodes from the first and second seasons of the science fiction drama series.
The series depicts the arrival of an extraterrestrial race, known as Visitors, who present themselves as benevolent beings offering advanced technology and medical knowledge. However, their true intentions are gradually revealed to be far more sinister, leading to a resistance movement on Earth.



Image: Front cover of the V - The Complete First and Second Seasons DVD set. It features two central characters, one with dark hair and a reptilian eye, and another with blonde hair, against a backdrop of alien spacecraft over a city skyline. The title "V" is prominently displayed in red, along with "The Complete First & Second Seasons".

Setup

To begin watching your V DVD set, follow these steps:

1. **Unpack the DVD Set:** Carefully remove the DVD case from its packaging.
2. **Open the Case:** Open the DVD case to access the discs. This set contains 5 discs.
3. **Select a Disc:** Choose the desired disc from the set. Ensure the disc is clean and free of smudges or scratches.
4. **Insert into Player:** Insert the disc into a compatible DVD player or computer DVD drive with the label side facing up.
5. **Connect Player to Display:** Ensure your DVD player is properly connected to your television or monitor using appropriate audio/video cables (e.g., HDMI, RCA).
6. **Power On:** Turn on your television/monitor and DVD player. Select the correct input source on your television/monitor.

Operating Instructions

Once the DVD is loaded, the player should automatically begin playback or display a main menu. If not, refer to your DVD player's manual.

- **Main Menu:** From the main menu, you can typically select "Play All," "Episode Selection," "Scene Selection," "Audio Options," or "Subtitles."
- **Episode Selection:** Navigate to the "Episode Selection" menu to choose a specific episode to watch.
- **Audio Options:** The DVD supports English (Dolby Digital 5.1), French (Dolby Digital 2.0), and Spanish (Dolby Digital 2.0) audio tracks. Select your preferred language from the audio menu.
- **Subtitles:** English subtitles are available. Activate or deactivate subtitles from the subtitle menu.
- **Playback Controls:** Use your DVD player's remote control for standard functions such as Play, Pause, Stop, Fast Forward, Rewind, and Skip (chapter/episode).

Note: This DVD set uses the PAL format. Ensure your DVD player and television are compatible with PAL discs for proper playback. Some regions may require a multi-region DVD player.

Maintenance and Care

Proper care will extend the life of your DVDs and ensure optimal playback quality.

- **Handling:** Always hold discs by their edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If a disc becomes dirty, gently wipe it with a soft, lint-free cloth from the center outwards. Do not use abrasive materials or harsh cleaning chemicals.
- **Storage:** Store discs in their original case, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Scratches:** Do not stack discs without their cases or place them on rough surfaces.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Disc does not play or loads slowly.	Disc is dirty or scratched; player is incompatible with PAL format; player lens is dirty.	Clean the disc carefully. Check if your player supports PAL. Try the disc in another player. Clean your DVD player's lens if possible.
No audio or incorrect audio language.	Incorrect audio track selected; player audio settings are incorrect; cables are loose.	Select the desired audio track from the DVD menu. Check your DVD player's audio output settings. Ensure audio cables are securely connected.
No subtitles or incorrect subtitle language.	Subtitles are turned off; incorrect subtitle track selected.	Activate subtitles from the DVD menu. Select the English subtitle track.
Picture is distorted or pixelated.	Disc is damaged; video cables are loose or faulty; TV input settings are incorrect.	Inspect the disc for damage. Check video cable connections. Ensure your TV is on the correct input and aspect ratio.

Specifications

Product Title: V - Season 1-2 [DVD] [2011]

Model Number (ASIN): B004ZELUV0

Brand/Studio: Warner Home Video

Format: DVD, PAL, Subtitled

Number of Discs: 5

Run Time: Approximately 15 hours and 7 minutes

Release Date: October 24, 2011

Audio Languages: English (Dolby Digital 5.1), French (Dolby Digital 2.0), Spanish (Dolby Digital 2.0)

Subtitles: English

Aspect Ratio: Unknown (as per product data)

Package Dimensions: 7.6 x 5.43 x 1.22 inches

Package Weight: 8.36 ounces

Warranty and Support

For information regarding warranty coverage or technical support for your DVD player, please refer to the documentation provided with your specific DVD player model. This DVD set is a media product and typically does not come with a separate manufacturer's warranty beyond standard consumer rights for defective goods.
If you encounter a manufacturing defect with a disc in this set, please contact the retailer from whom it was purchased for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004ZELUV0

More documents and user manuals: **https://manuals.plus/**