

Fallsbrook

Project Source Fallsbrook 5 Light Brushed Nickel Chandelier User Manual

Model: Fallsbrook | Brand: Generic

1. INTRODUCTION

Thank you for choosing the Project Source Fallsbrook 5-Light Chandelier. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new lighting fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.

This elegant 5-light chandelier features a brushed nickel finish and frosted glass shades, designed to enhance the ambiance of your space. It is hardwired and uses medium base (E-26) A19 type light bulbs.



Figure 1.1: The Project Source Fallsbrook 5-Light Chandelier, showcasing its brushed nickel finish and five frosted glass shades.

2. IMPORTANT SAFETY INFORMATION

- **WARNING:** To avoid electric shock, ensure power is turned off at the circuit breaker or fuse box before installation, servicing, or changing bulbs.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with installing electrical wiring.
- This fixture is intended for indoor use only. Do not expose to water or moisture.
- Use only the specified bulb type and wattage. Refer to the "Specifications" section for details.
- Do not exceed the maximum wattage rating for each bulb socket.
- Always handle the fixture and bulbs with care. Allow bulbs to cool before touching.
- Keep flammable materials away from the light fixture.

3. SETUP AND INSTALLATION

3.1 Tools Required (Not Included)

- Phillips Head Screwdriver
- Flathead Screwdriver
- Wire Strippers
- Electrical Tape
- Ladder
- Safety Glasses

3.2 Installation Steps

1. **Turn Off Power:** Locate the circuit breaker or fuse box that supplies power to the light fixture location. Turn off the power completely. Verify power is off using a voltage tester.
2. **Prepare for Installation:** Carefully unpack all components from the packaging. Lay them out on a clean, flat surface to ensure all parts are present and undamaged.
3. **Assemble Fixture Body:** Attach the arms to the central body of the chandelier if they are not pre-assembled. Ensure all connections are secure.
4. **Adjust Chain Length:** The chandelier comes with an adjustable chain. Determine the desired hanging height for your fixture. Use pliers to open and remove excess chain links as needed. Ensure enough chain remains to support the fixture and allow for electrical wiring.



Figure 3.1: The chandelier installed, demonstrating its hanging chain and overall appearance in a room setting.

5. **Mounting Bracket Installation:** Secure the mounting bracket to the electrical junction box in the ceiling using the provided screws. Ensure the bracket is firmly attached and can support the weight of the chandelier.
6. **Electrical Connections:**
 - Connect the bare copper ground wire from the fixture to the bare copper or green ground wire from the junction box. Secure with a wire nut.
 - Connect the ribbed (or white) wire from the fixture to the white (neutral) wire from the junction box. Secure with a wire nut.
 - Connect the smooth (or black) wire from the fixture to the black (hot) wire from the junction box. Secure with a wire nut.
 - Wrap all wire nut connections with electrical tape for added security.
7. **Secure Canopy:** Carefully push the wired fixture up towards the ceiling, tucking all wires into the junction box. Slide the canopy (ceiling plate) up the chain and secure it to the mounting bracket using the provided screws or nuts.
8. **Install Glass Shades:** Carefully place each frosted glass shade onto its respective socket. Ensure they are seated properly and securely.



Figure 3.2: A close-up view of one of the frosted glass shades, showing the detail of the fixture's arm and bulb socket.

9. **Install Light Bulbs:** Screw in five (5) A19 type medium base (E-26) light bulbs (not included) into each socket. Do not exceed the maximum wattage specified in the "Specifications" section.



Figure 3.3: An alternative perspective of the chandelier, highlighting its full form and the arrangement of its five lights.

10. **Restore Power:** Once installation is complete and all connections are secure, return to the circuit breaker or fuse box and restore power. Test the light fixture.

4. OPERATING INSTRUCTIONS

The Project Source Fallsbrook Chandelier is designed for simple operation via a standard wall switch (not included). Once

properly installed and wired, simply toggle the wall switch to turn the light fixture ON or OFF.

Note: This fixture is not dimmable. Using dimmable bulbs with a non-dimmable fixture or a dimmer switch may cause damage to the bulbs or the fixture, or result in improper operation.

5. CARE AND MAINTENANCE

- **Cleaning:** To clean the fixture, ensure power is turned off and the fixture is cool. Wipe the brushed nickel finish with a soft, dry cloth. Do not use abrasive cleaners, polishes, or solvents as they may damage the finish.
- **Glass Shades:** The frosted glass shades can be gently wiped with a damp cloth. For stubborn spots, a mild glass cleaner can be used, applied to the cloth first, not directly to the shade. Ensure shades are completely dry before restoring power.
- **Bulb Replacement:** Always turn off power at the circuit breaker before replacing bulbs. Allow old bulbs to cool before removing. Replace with the same type and wattage bulbs as specified.
- **Regular Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Faulty bulb. Faulty wall switch.	Check circuit breaker/fuse. Verify all wire connections are secure (ensure power is off first). Replace bulb with a new, known-good bulb. Consult a qualified electrician to check the switch.
Light flickers or dims.	Loose bulb. Incorrect bulb type/wattage. Loose wire connections. Fixture connected to a dimmer switch (fixture is not dimmable).	Tighten bulb securely. Ensure correct bulb type and wattage are used. Check wire connections (power off first). Remove dimmer switch and replace with a standard ON/OFF switch.
Fixture hums.	Loose components. Incompatible bulb.	Check all screws and connections for tightness. Try a different brand or type of bulb.

7. SPECIFICATIONS

Collection Name	Fallsbrook
Number of Tiers	1
Width	22.44 Inches
Height	16.54 Inches
Weight	9.96 lbs.
Light Bulb Base Type	Medium base (E-26)
Recommended Light Bulb Shape	A19

Type of Hanging Device	Chain
Mounting Hardware Included	Yes
UL Safety Listing	Yes
CSA Safety Listing	No
ETL Safety Listing	No
Hardwired or Plug-In	Hardwired
ENERGY STAR Qualified	No
Manufacturer Color/Finish	Brushed nickel
Dimmable	No
Style	Traditional
Number of Light Sources	5
UPC	841796002294
ASIN	B0050DVG1E

8. WARRANTY AND SUPPORT

8.1 Limited Warranty

This Project Source Fallsbrook Chandelier is covered by a limited warranty against defects in materials and workmanship. The duration and terms of the warranty may vary. Please retain your proof of purchase for warranty claims. For specific warranty details, refer to the documentation included with your purchase or contact the manufacturer directly.

8.2 Customer Support

If you have any questions regarding the installation, operation, or maintenance of your chandelier, or if you require technical assistance, please contact the manufacturer's customer support. Contact information is typically found on the product packaging or the manufacturer's official website.

For general inquiries, you may also refer to the product page on Amazon.com for additional resources or frequently asked questions related to ASIN: [B0050DVG1E](#).

