

[Manuals.plus](#) /

› [Babycakes](#) /

› Babycakes CP-12 Cake Pop Maker Instruction Manual

Babycakes CP-12

Babycakes CP-12 Cake Pop Maker Instruction Manual

Model: CP-12 | Brand: Babycakes

INTRODUCTION

Welcome to the world of easy and fun baking with your new Babycakes CP-12 Cake Pop Maker. This appliance is designed to help you create delicious cake pops quickly and efficiently, perfect for parties, family treats, or any occasion. Its non-stick coating and user-friendly design make baking a breeze.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your Babycakes Cake Pop Maker. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always unplug the appliance from the outlet when not in use and before cleaning.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Do not touch hot surfaces. Use handles or knobs.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- For household use only.

WHAT'S INCLUDED

Your Babycakes CP-12 Cake Pop Maker package includes the following items:

- 1 x Babycakes CP-12 Cake Pop Maker
- 50 x Paper Cake Pop Sticks
- 1 x Fork Tool
- 1 x Cooling Stand (doubles as decorating stand)

Power Light

Locking Lid Latch

Nonskid Feet

Easy-Release Cooking Surface To Prevent Sticking

What's In The Box

Cake Pop Stand
Cool and decorate cake pops using this bonus stand.

Recipes Included
Tips & recipes are included in the owner's manual.

Cake Pop Sticks
Includes 50 heavy-gauge paper treat sticks.

Two-Pronged Fork
Retrieve cooked pops with the two-pronged fork.

GINGERBRE
1 cup all-pu
1 teaspoon bakin
1 teaspoon gro
1/2 teaspoon masarp

babycakes
THE ORIGINAL

Image: The Babycakes Cake Pop Maker and its included accessories: 50 paper sticks, a fork tool, and a cooling stand.

SETUP

1. Before first use, wipe down the non-stick cooking plates with a damp cloth and dry thoroughly.
2. Place the Cake Pop Maker on a stable, heat-resistant surface.
3. Close the lid and plug the appliance into a 120V electrical outlet. The red "Power" light will illuminate, indicating the unit is heating.
4. Allow the Cake Pop Maker to preheat until the green "Ready" light illuminates (approximately 3-5 minutes).



Image: The Babycakes Cake Pop Maker in its open position, revealing the non-stick cooking surface with 12 circular molds.

OPERATING INSTRUCTIONS

Once the green "Ready" light is on, your Cake Pop Maker is ready for use.

1. Prepare your cake pop batter according to your chosen recipe. For best results, use a piping bag or a squeeze bottle to fill the reservoirs.
2. Carefully fill each cooking reservoir with batter, ensuring not to overfill. Fill just below the top edge of each mold.
3. Close the lid and latch the handle. The green "Ready" light may turn off during baking.
4. Bake for approximately 3-5 minutes, or until the cake pops are golden brown and cooked through. Cooking time may vary based on batter consistency and desired doneness.
5. Use the included fork tool or a non-metallic utensil to carefully remove the cooked cake pops from the non-stick surface.
6. Place the hot cake pops on the cooling stand to cool before decorating.



Easy-
Release
Cooking
Surface

Easy Cake Pops For Every Occasion

- 1 Simply preheat the device
- 2 Pour the batter
- 3 Close the lid
- 4 Bake for a few minutes
- 5 Pop them out with ease, then wipe down to clean

Image: A visual guide showing the five simple steps to make cake pops: preheating, pouring batter, closing the lid, baking, and removing the finished cake pops.

Your browser does not support the video tag.

Video: Official demonstration of the Babycakes CP-12 Cake Pop Maker in use, showing the process of making cake pops.

RECIPES

The Babycakes Cake Pop Maker comes with a manual that includes delicious cake pop recipes to help you get started. Experiment with different flavors and decorations to create unique treats.

• THE ORIGINAL •
babycakes™

Cake Pop Maker

Whip Up Trendy Cake Pops in Your Own Kitchen!

Bake 12 pops at a time.
Add sticks, decorate, and serve
adorable treats the whole family
will love.

makes
12
cake pops or
donut holes

Image: A batch of freshly baked cake pops cooling on a rack, alongside several decorated cake pops on sticks, showcasing potential creations.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity of your appliance.

1. Always unplug the Cake Pop Maker and allow it to cool completely before cleaning.
2. Wipe the non-stick cooking plates with a damp cloth or sponge. Do not use abrasive cleaners or scouring pads, as this may damage the non-stick surface.
3. Wipe the exterior of the appliance with a damp cloth.
4. Do not immerse the appliance in water or any other liquid.
5. The cooling stand and fork tool can be washed with warm, soapy water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in or power outlet issue.	Ensure the appliance is securely plugged into a working 120V outlet. Check the circuit breaker.
Cake pops are not cooking evenly.	Uneven batter distribution or insufficient preheating.	Ensure the unit is fully preheated (green light on). Distribute batter evenly in each reservoir.
Cake pops stick to the plates.	Plates not properly seasoned or damaged non-stick coating.	Ensure plates are clean and dry. For initial use, a light coating of cooking spray can be applied (though generally not needed for non-stick). Avoid using metal utensils.

SPECIFICATIONS

Brand: Babycakes

Model: CP-12

Color: Purple

Material: Plastic with Non-stick coating (PTFE Free)

Product Dimensions: 8.07"D x 9.84"W x 4.72"H

Wattage: 760 watts

Voltage: 120V

Item Weight: 3.6 Pounds

Capacity: 12 Cake Pops

Special Feature: Manual operation, Electric

Product Information



Wattage: 760



Item Weight: 3.6 lbs.



Voltage: 120 Volts



Image: Diagram showing the dimensions (height, width, depth) and electrical specifications (wattage, voltage, item weight) of the Babycakes Cake Pop Maker.

WARRANTY AND SUPPORT

The Babycakes CP-12 Cake Pop Maker comes with a Limited Warranty. For detailed information regarding warranty coverage, claims, and product support, please refer to the official user manual PDF or contact Babycakes customer service. You can find the full User Manual (PDF) [here](#).