

[Manuals.plus](#) /

> [Venture Horizon](#) /

> [Venture Horizon Revolving Media Tower 600 White User Manual](#)

Venture Horizon 2385-60LW

Venture Horizon Revolving Media Tower 600 White

Model: 2385-60LW | Brand: Venture Horizon

[Introduction](#)

[Safety](#)

[Contents](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Venture Horizon Revolving Media Tower 600 in White. This 4-sided media storage unit is designed to organize and display your collection of CDs, DVDs, Blu-rays, and games efficiently. Its revolving design allows for easy access to all stored items while occupying a minimal footprint.





Image 1.1: The Venture Horizon Revolving Media Tower 600 in White, showcasing its capacity when filled with various media.

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Failure to follow these guidelines may result in injury or damage to the product.

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the unit on a soft, clean surface to prevent scratching.
- Ensure all fasteners are securely tightened before use. Periodically check and retighten as necessary.
- Do not overload the shelves. Distribute weight evenly to maintain stability.
- Do not climb on or stand on the unit.
- Place the media tower on a level surface to ensure proper rotation and stability.
- Maintain a minimum clearance of 3.5 inches from any wall or object to allow for full 360-degree rotation.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Main structural panels (top, bottom, side panels)

- Adjustable shelves
- Swivel base mechanism
- Mounting hardware (screws, shelf pins, connectors)
- Casters (optional, if included with your model)
- Assembly instructions

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this media tower. It is recommended to have two people for easier and safer assembly. Follow the included step-by-step instructions provided in the packaging. The process is generally straightforward and takes approximately one hour.

4.1 Key Assembly Considerations

- **Swivel Base:** The unit features a 16" x 16" swivel base. Ensure it is correctly installed for smooth rotation.
- **Wall Clearance:** A minimum distance of 3.5 inches from any wall or obstruction is required for the tower to rotate freely.
- **Shelf Pins:** If shelf pins are too tight, use pliers to gently twist them into place. Avoid hammering, which can damage the unit.
- **Level Surface:** Assemble and place the tower on a level surface to prevent wobbling and ensure proper function of the revolving mechanism.




Image 4.1: Diagram illustrating the 16" x 16" swivel base and the necessary 3.5" wall clearance for optimal rotation.

5. OPERATING INSTRUCTIONS

5.1 Loading Media

The Venture Horizon Revolving Media Tower is designed to hold a variety of media formats. Utilize the adjustable shelves to customize the spacing according to your collection's needs. Distribute media evenly across the shelves to maintain balance and stability.

5.2 Rotating the Tower

Gently push or pull on one of the sides of the tower to initiate rotation. The swivel base is designed for smooth, quiet movement, allowing easy access to all four sides of your media collection.

6. MAINTENANCE

6.1 Cleaning

Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish. Dry immediately with a clean cloth.

6.2 Stability Check

Periodically check all screws and fasteners to ensure they remain tight. Retighten as needed to maintain the structural integrity and stability of the tower.

6.3 Swivel Base Care

The plastic swivel base is durable under normal use. Avoid excessive force or rapid spinning. If rotation becomes stiff, ensure the base is free of debris. Do not apply lubricants unless specifically recommended by the manufacturer.

7. TROUBLESHOOTING

- **Tower is wobbly:** Ensure the unit is placed on a level surface. Check and tighten all assembly screws. Redistribute media weight evenly.
- **Tower does not rotate smoothly:** Verify that the tower has adequate clearance from walls or other objects (minimum 3.5 inches). Check the swivel base for any obstructions or damage. Ensure the unit is on a level surface.
- **Missing or damaged parts:** Do not proceed with assembly. Contact Venture Horizon customer support immediately for replacement parts.

8. SPECIFICATIONS

Model Number	2385-60LW
Color	White
Product Dimensions (D x W x H)	16" x 16" x 56"
Item Weight	56 Pounds
Material	Wood composite with laminate finish
Number of Shelves	4 (adjustable)
Shelf Type	Tiered Shelf
Total Shelf Weight Capacity	180 Pounds
Assembly Required	Yes

Mounting Type	Floor Mount
UPC	654775238610

8.1 Media Storage Capacity

Media Storage Capacity



Model 2385
(all colors)

Cd's	612
DVD's	288
Blu-ray	312
Disney	126
VHS	168

Venture Horizon Media Storage

Image 8.1: Detailed media storage capacity for Model 2385 (all colors).

- **CDs:** 612
- **DVDs:** 288
- **Blu-rays:** 312
- **Wii Games:** 288
- **Xbox Games:** 288
- **PS4/PS5 Games:** 288

9. WARRANTY AND SUPPORT

For warranty information, specific product inquiries, or to report missing/damaged parts, please contact Venture Horizon directly. You can often find contact details on the product packaging or through their official website.

You may also visit the official [Venture Horizon Store on Amazon](#) for additional product information and support resources.

