



Manuals.plus /

› MRI /

› Epic Epic Audio CD User Manual

MRI B0051OJDEE

Epic Epic Audio CD User Manual

Model: B0051OJDEE | Brand: MRI

INTRODUCTION

This user manual provides essential information for the proper use, care, and maintenance of your Epic Epic Audio CD by Lisa Jaeggi. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



This image displays the album cover for 'Epic Epic' by Lisa Jaeggi. The central illustration features a stylized deer head with prominent antlers, wearing a small crown and adorned with decorative feathers. A lush wreath of various colored roses and green leaves encircles the deer's head. Around the main illustration, several shark teeth and additional feathers are scattered, creating a unique border. Below the artwork, the artist's name 'lisa jaeggi' is printed, followed by the album title 'EPIC EPIC' in large, bold letters.

The Epic Epic Audio CD features a blend of folk, hip hop, soul, and pop, showcasing Lisa Jaeggi's talent as a lyricist and poet. The album explores themes ranging from melancholic narratives to observations on city life, accompanied by acoustic guitar.

SETUP

Unpacking

- Carefully remove the Audio CD from its packaging.
- Inspect the CD for any visible damage, such as scratches or cracks. If damage is present, do not attempt to play the CD and contact customer support.

Initial Playback

- Ensure your CD player or compatible device is clean and free of dust.
- Gently hold the CD by its edges to avoid touching the playing surface.
- Insert the CD into the disc tray or slot of your audio player with the label side facing up.
- Close the disc tray or ensure the CD is fully inserted.

OPERATING

Playing the Audio CD

- Press the 'Play' button on your CD player or remote control.
- Adjust the volume to a comfortable listening level.
- The CD will typically begin playing from the first track.

Track Navigation

- To skip to the next track, press the 'Next Track' or 'Forward' button.
- To go back to the previous track, press the 'Previous Track' or 'Rewind' button.
- To fast-forward or rewind within a track, hold down the 'Forward' or 'Rewind' button.
- To pause playback, press the 'Pause' button. Press 'Play' again to resume.
- To stop playback, press the 'Stop' button.

MAINTENANCE

Cleaning the CD

- If the CD surface becomes dirty or smudged, gently wipe it with a soft, lint-free cloth.
- Wipe from the center of the CD outwards in a straight line, not in a circular motion.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the disc.
- For stubborn dirt, a slightly dampened cloth with water can be used, followed by immediate drying with a dry, lint-free cloth.

Storage

- Always store the Audio CD in its original jewel case or a protective sleeve when not in use.
- Store CDs in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- Avoid placing heavy objects on top of CD cases, which can cause damage to the case or disc.

TROUBLESHOOTING

Problem	Possible Cause	Solution
CD skips or stutters during playback.	Dust or smudges on the disc surface; Scratches on the disc; Dirty CD player lens.	Clean the CD as described in the Maintenance section. Inspect for deep scratches. Try playing another CD to check if the issue is with the player.
CD does not play or is not recognized.	CD inserted incorrectly; Disc is damaged; CD player malfunction.	Ensure the CD is inserted correctly (label side up). Check for severe damage. Try the CD in another player.
No sound during playback.	Volume too low or muted; Audio cables disconnected; Speaker issues.	Increase volume. Check all audio connections between the CD player and amplifier/speakers. Ensure speakers are powered on.

SPECIFICATIONS

Specification	Detail
Language	English
Product Dimensions	5.51 x 4.88 x 0.27 inches; 1.44 ounces
Manufacturer	MRI
Original Release Date	2011
Run time	46 minutes
Date First Available	May 20, 2011
Label	MRI
ASIN	B0051OJDEE
Country of Origin	USA
Number of discs	1

WARRANTY AND SUPPORT

Specific warranty information for the Epic Epic Audio CD is not provided in the product details. For any inquiries regarding warranty, returns, or technical support, please refer to the retailer or the record label (MRI) directly.

It is recommended to retain your proof of purchase for any potential support needs.