

Moen CA84440SRN

Moen CA84440SRN Caldwell Collection Widespread Bathroom Faucet User Manual

Model: CA84440SRN

1. INTRODUCTION

Thank you for choosing the Moen CA84440SRN Caldwell Collection Widespread Bathroom Faucet. This manual provides essential information for the safe and proper installation, operation, maintenance, and troubleshooting of your new faucet. Please read these instructions thoroughly before beginning installation or use, and retain them for future reference.

2. SAFETY INFORMATION

- Always turn off the main water supply to the bathroom before attempting any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Ensure all connections are secure to prevent leaks.
- Do not overtighten connections, as this may damage the faucet or plumbing.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation. While specific contents may vary, typical components for the Moen CA84440SRN faucet include:

- Faucet Spout Assembly
- Hot and Cold Handle Assemblies
- Mounting Hardware (washers, nuts)
- Supply Lines (often integrated or included)
- Drain Assembly (if included with your model)

4. SETUP AND INSTALLATION

This section outlines the general steps for installing your widespread bathroom faucet. Specific details may vary based on

your sink and plumbing configuration.

4.1 Tools Required (Not Included)

- Adjustable Wrench
- Phillips Head Screwdriver
- Plumber's Putty or Silicone Sealant
- Flashlight (optional)

4.2 Installation Steps

1. **Prepare the Sink:** Ensure the sink deck is clean and free of debris. The Moen CA84440SRN is a widespread faucet, requiring three holes in the sink deck.
2. **Install the Faucet Spout:** Apply a thin bead of plumber's putty or silicone sealant around the base of the faucet spout. Insert the spout through the center hole in the sink deck. From underneath, secure it with the provided washer and mounting nut. Hand-tighten, then use a wrench for a final snug turn.
3. **Install the Handles:** Apply plumber's putty or silicone sealant to the bases of the hot and cold handle assemblies. Insert each handle through its respective side hole in the sink deck. Secure from underneath with washers and mounting nuts.
4. **Connect Water Supply Lines:** Connect the hot and cold water supply lines from your wall stops to the corresponding inlets on the faucet handles. Ensure connections are tight but do not overtighten.
5. **Connect Handle to Spout:** Connect the flexible supply lines from the handle assemblies to the main spout assembly. Refer to the diagram for correct hot and cold connections.
6. **Install Drain Assembly (if applicable):** Follow the separate instructions provided with your drain assembly. Ensure a watertight seal with plumber's putty or silicone sealant.
7. **Test for Leaks:** Once all connections are made, slowly turn on the main water supply. Check all connections for leaks. Run the faucet for a few minutes to flush out any debris and recheck for leaks.



Figure 1: Overview of the Moen CA84440SRN widespread bathroom faucet, showcasing its spout and two handle design in Spot Resist Brushed Nickel finish.



Figure 2: The Moen CA84440SRN faucet installed on a bathroom sink, demonstrating its aesthetic integration and functional placement.

5. OPERATING INSTRUCTIONS

Your Moen CA84440SRN faucet features a double-handle design for precise control over water temperature and flow.

- **Cold Water:** Turn the right handle counter-clockwise to activate cold water.
- **Hot Water:** Turn the left handle counter-clockwise to activate hot water.
- **Temperature Control:** Adjust the handles simultaneously to achieve your desired water temperature.
- **Flow Control:** The further you turn the handles, the greater the water flow.
- **Shut Off:** Turn both handles clockwise until they stop to turn off the water flow completely.

6. MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your Moen CA84440SRN faucet, especially its

Spot Resist Brushed Nickel finish.

6.1 Cleaning the Finish

- Clean the faucet regularly with a soft, damp cloth and mild soap.
- Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots. The Spot Resist Brushed Nickel finish is designed to resist fingerprints and water spots, but regular cleaning is still recommended.
- Avoid abrasive cleaners, harsh chemicals, polishes, or scouring pads, as these can damage the finish.

6.2 Aerator Maintenance

If water flow decreases, the aerator may be clogged. Unscrew the aerator from the end of the spout, clean any debris, and rinse it before reattaching.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your faucet.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valve; debris in supply line.	Clean aerator; ensure shut-off valves are fully open; flush supply lines.
Leaking from Spout	Worn cartridge; debris in cartridge.	Replace cartridge; clean cartridge.
Leaking at Base of Faucet/Handles	Loose mounting nuts; improper sealant application.	Tighten mounting nuts; reapply plumber's putty or silicone sealant.
Handles Stiff or Hard to Turn	Worn cartridge; mineral buildup.	Replace cartridge; clean around handle base.

8. SPECIFICATIONS

Model Number	CA84440SRN
Brand	Moen
Mounting Type	Deck Mount
Finish Type	Spot Resist Brushed Nickel
Material	Metal
Number of Handles	2
Installation Type	Widespread
Spout Height	8.5 Inches
Spout Reach	4.88 Inches

Item Weight	6.3 Pounds
Product Dimensions	3 x 4 x 5 inches
UPC	026508199879, 026508209554

9. WARRANTY AND SUPPORT

Moen products are manufactured to the highest standards of quality and workmanship. For detailed warranty information, product registration, replacement parts, or technical assistance, please refer to the documentation included with your product or visit the official Moen website. You can typically find support contact information, FAQs, and warranty details on their customer service pages.

Please have your model number (CA84440SRN) and date of purchase available when contacting customer support.

© 2023 Moen Incorporated. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question