De'Longhi 5513290061

De'Longhi 5513290061 500g Vacuum Coffee Canister Instruction Manual

Introduction

This manual provides essential information for the proper use and maintenance of your De'Longhi 5513290061 500g Vacuum Coffee Canister. Designed to preserve the freshness and aroma of your coffee, this canister utilizes a motorized vacuum sealing system. Please read these instructions carefully before first use.

Key Features:

- Vacuum Sealed for freshness
- Capacity: 1.2l / 500g of beans or 800g of coffee grounds
- One-step sealing operation
- Battery-powered motorized unit creates a vacuum seal in 1-2 minutes
- Dishwasher Safe inner container



The De'Longhi 500g Vacuum Coffee Canister in silver, designed to preserve coffee freshness.

Setup

Unpacking

Carefully remove all components from the packaging. Ensure all packing materials are discarded responsibly. Inspect the canister for any signs of damage. Do not use if damaged.

Battery Installation and Initial Charge

The motorized vacuum unit requires 1 Lithium Ion battery. Ensure the battery is correctly installed according to the polarity markings. For optimal performance, fully charge the unit before first use. Refer to the charging port location on the unit for

connection.



Illustrates the process of filling the canister with fresh coffee beans.

Operating Instructions

Filling the Canister

1. Open the canister by releasing the side clips and lifting the lid.
2. Place your coffee beans or grounds into the clear inner container. Do not overfill; leave sufficient space for the vacuum lid.
3. Close the lid, ensuring it is properly aligned and the side clips are securely fastened.



A close-up view of the canister's interior, showcasing its capacity for coffee beans.

Activating the Vacuum Seal

Once the lid is securely closed, the motorized unit will automatically begin to create a vacuum seal. This one-step sealing process typically takes 1-2 minutes. The unit will stop automatically once the vacuum is achieved.

Opening the Canister

To open the canister, press the release button located on the lid. You will hear a hiss as air re-enters the canister, releasing the vacuum seal. Once the vacuum is released, unfasten the side clips and lift the lid.



Demonstrates the removable inner container, which holds the coffee and is dishwasher safe.

Product Overview Video

Your browser does not support the video tag.

This video provides an overview of the De'Longhi Vacuum Coffee Canister, demonstrating its key features and how it operates to keep coffee fresh.

Maintenance

Cleaning

- The clear inner container is dishwasher safe for convenient cleaning.
- The main canister, which houses the electronic components, should be wiped clean with a damp cloth. Do not immerse the main canister in water or place it in a dishwasher.
- Ensure all parts are completely dry before reassembling and using the canister.

Troubleshooting

Common Issues

- **Vacuum Seal Not Forming:** Ensure the lid is properly aligned and the side clips are securely fastened. Check if the battery is charged.
- **Lid Difficult to Open:** Ensure the release button has been fully pressed to allow air to re-enter the canister before attempting to open.
- **Motor Not Operating:** Check the battery charge level. Recharge if necessary.

Specifications

Brand	De'Longhi
Model Name	5513290061
Color	Silver
Capacity	1.2l / 500g of beans or 800g of coffee grounds
Product Dimensions	7.09"D x 6.3"W x 1.18"H
Item Weight	1.94 pounds
Operation Mode	Fully Automatic
Special Feature	Dishwasher Safe (inner container)
Batteries	1 Lithium Ion battery required

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the documentation included with your product or visit the official De'Longhi website. Keep your purchase receipt as proof of purchase for any warranty claims.

De'Longhi Customer Service: Please consult your regional De'Longhi contact information for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question