Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Invicta /
- > Invicta 6106 Reserve Excursion Multi-Function Dual Time Men's Watch Instruction Manual

Invicta 6106

Invicta 6106 Reserve Excursion Multi-Function Dual Time Men's Watch Instruction Manual

This manual provides detailed instructions for the setup, operation, and maintenance of your Invicta 6106 Reserve Excursion Multi-Function Dual Time Men's Watch. Please read thoroughly to ensure proper use and longevity of your timepiece.

1. INITIAL SETUP

1.1 Unpacking and Inspection

Upon opening the packaging, carefully remove your watch and inspect it for any visible damage. Ensure all protective films are removed from the crystal, case back, and bracelet.

1.2 Time and Date Setting

To set the time and date on your Invicta 6106 watch:

- 1. Pull the crown (A) out to the first click position to set the date. Rotate the crown clockwise or counterclockwise until the correct date is displayed in the date window.
- 2. Pull the crown (A) out to the second click position to set the time. Rotate the crown to move the hour and minute hands to the desired time. Pay attention to the 24-hour sub-dial to distinguish between AM and PM for accurate date change.
- 3. Once the time and date are set, push the crown (A) back into its normal operating position to engage the movement.



Image: Front view of the Invicta 6106 watch, showing the main dial, sub-dials, date window, and crown (A) on the right side.



Image: Close-up view of the watch crown and the unidirectional rotating bezel, highlighting the detailed craftsmanship.

1.3 Bracelet Adjustment

The stainless steel bracelet of your Invicta 6106 watch can be adjusted for a comfortable fit. It is recommended to have this procedure performed by a professional watchmaker or jeweler to avoid damaging the links or pins.



Image: Side and back view of the Invicta 6106 watch, illustrating the bracelet construction and the engraved case back.

2. OPERATING YOUR WATCH

2.1 Main Time Display

The central hour, minute, and second hands indicate the primary time. The luminous markers and hands ensure readability in low-light conditions.

2.2 Multi-Function Sub-dials

Your Invicta 6106 features multiple sub-dials for enhanced functionality:

- **24-Hour Indicator:** Located at the 12 o'clock position, this sub-dial displays the time in a 24-hour format, assisting in AM/PM differentiation for the main time.
- **Dual Time Zone:** The sub-dial at the 6 o'clock position is designed to display a second time zone. This can be independently set to track time in another location.
- Date Window: A dedicated window typically located at the 4 o'clock position displays the current date.



Image: Front view of the Invicta 6106 watch, highlighting the main hands, sub-dials, and date display.

2.3 Dual Time Feature

To set the dual time zone, refer to the specific instructions for your watch's movement, typically involving a dedicated pusher or a specific crown position. Once set, the sub-dial will continuously display the second time zone.

2.4 Bezel Functionality

The Invicta 6106 features a unidirectional rotating bezel. This bezel can be used to measure elapsed time. Align the zero marker on the bezel with the minute hand at the start of an event. The minute hand's position against the bezel's scale will then indicate the elapsed time.



Image: Close-up view of the watch bezel, showing the minute markers and the unidirectional rotation mechanism.

3. CARE AND MAINTENANCE

3.1 Cleaning

To clean your watch, wipe the case and bracelet with a soft, damp cloth. For stainless steel, a mild soap solution can be used, followed by thorough rinsing and drying. Avoid using harsh chemicals or abrasive materials.

3.2 Water Resistance

Your Invicta 6106 watch is designed with a certain level of water resistance. Always ensure the crown is fully pushed in before any contact with water. Do not operate the crown or pushers while the watch is wet or submerged, as this can compromise the water resistance. Refer to the case back for the specific water resistance rating.

3.3 Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the battery runs low, the second hand may start to jump in two-second intervals (End-of-Life indicator). Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

3.4 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. Keeping it in its original box or a watch case can protect it from dust and scratches.

4. TROUBLESHOOTING COMMON ISSUES

4.1 Watch Not Running

- Ensure the crown is fully pushed in.
- If the watch is quartz, the battery may need replacement. Consult a professional watchmaker.

4.2 Incorrect Time/Date

• Refer to Section 1.2 for instructions on how to correctly set the time and date.

4.3 Condensation Inside Crystal

Small amounts of condensation may appear temporarily with sudden temperature changes. If condensation
persists or appears as large droplets, it indicates a breach in water resistance. Seek immediate professional
service to prevent internal damage.

5. PRODUCT SPECIFICATIONS

· Brand: Invicta

• Model Number: 6106

• Movement: Quartz (Assumed for multi-function)

• Case Material: Stainless Steel (Visual confirmation)

• Band Material: Stainless Steel (Visual confirmation)

• Functions: Multi-Function, Dual Time, Date, 24-Hour Indicator, Luminous Hands/Markers, Unidirectional Rotating Bezel

ASIN: B0052TMEL2Manufacturer: Invicta

Package Dimensions: 15.49 x 14.73 x 11.94 cm

• Package Weight: 703.07 g



Image: Detailed view of the watch's case back, often containing model number and water resistance information.

6. WARRANTY AND SUPPORT

Your Invicta 6106 watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. For technical support, service, or warranty claims, please contact Invicta customer service directly or visit their official website for authorized service centers. Keep your proof of purchase and warranty card in a safe place, as they will be required for any warranty-related services.

Related Documents - 6106



Invicta Watch Warranty and Service Guide

Comprehensive guide to Invicta watch warranties, including registration, service procedures, repair pricing, shipping requirements, and policies. Learn how to maintain your Invicta timepiece for optimal performance and longevity.



Invicta Watch Instruction Manual and Warranty

A comprehensive guide to understanding and operating your Invicta timepiece, including instructions for setting time, date, day, and alarm functions, as well as chronograph operations and warranty information.



Invicta 19289 S1 Rally Watch: Installation and User Guide

This document provides installation and operational guidance for the Invicta Men's 19289 S1 Rally Analog Display Japanese Quartz Black Watch. It covers essential setup, features, and maintenance to ensure proper use of the timepiece.



Invicta Watch Manual and Warranty Guide

Explore the official Invicta watch manual and warranty details. This guide covers your 3-year limited warranty, service center information, watch care, and explanations of various watch features and movements.



Invicta Watch Manual and Warranty Guide: Care, Service, and Features

Official manual and warranty guide for Invicta watches. Learn about the 3-year warranty, service procedures, watch care, water resistance, and types of movements (Quartz, Automatic, Manual Wind).



Invicta VD53 Movement Caliber: User Manual and Functions

Detailed guide to the Invicta VD53 watch movement, covering its display elements, setting procedures, and stopwatch functions including standard, accumulated elapsed time, and split time measurements.