

Moen 150259

Moen 150259 Pulldown Kitchen Faucet Replacement Hose Service Kit

User Instruction Manual

1. INTRODUCTION

This manual provides instructions for the installation and maintenance of the Moen 150259 Replacement Hose Service Kit. This kit is designed to restore the functionality of compatible Moen pulldown kitchen faucets by replacing the internal hose.

2. SAFETY INFORMATION

- Always turn off the water supply to the faucet before beginning any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any step, consult a qualified plumber.

3. PACKAGE CONTENTS

The Moen 150259 Replacement Hose Service Kit typically includes:

- One (1) Moen Pulldown Kitchen Faucet Replacement Hose (68 inches long)




Image 1: Moen 150259 Replacement Hose Service Kit. This image shows the braided gray hose with metal connectors at both ends.

4. COMPATIBILITY

This replacement hose kit is specifically designed for Moen pulldown kitchen faucets that utilize **abuilt-in quick connect** mechanism. It is essential to verify that your existing faucet connection matches the type shown in the diagram below before proceeding with installation.

**THIS REPLACEMENT HOSE KIT ONLY WORKS WITH
MOEN BUILT-IN QUICK CONNECT PULL DOWN
FAUCET CONNECTIONS. CHECK TO MAKE SURE
YOUR FAUCET CONNECTION MATCHES THIS IMAGE**



An Integrated Single Quick Connect is a plastic connector that is permanently attached to a flexible tube that extends from the faucet body. It will have only one black or white release tab.

Image 2: Diagram illustrating the Moen built-in quick connect. This diagram shows a flexible tube extending from the faucet body with a single black or white release tab, indicating an integrated single quick connect.

An integrated single quick connect is a plastic connector permanently attached to a flexible tube that extends from the faucet body. It will have only one black or white release tab.

5. SETUP (INSTALLATION)

Follow these steps to replace the hose in your Moen pulldown kitchen faucet:

1. **Prepare the Work Area:** Clear the area under your sink. Place a towel or small bucket to catch any residual water.
2. **Turn Off Water Supply:** Locate and turn off the hot and cold water supply valves under the sink. Turn on the faucet to drain any remaining water and relieve pressure.
3. **Disconnect the Old Hose:**
 - Under the sink, locate the quick connect fitting where the pulldown hose connects to the water supply line. Squeeze the two white or black tabs on the quick connect and pull to release the hose.

- If present, remove the counterweight from the old hose.
- Above the sink, unscrew the sprayer head from the end of the old hose. This can usually be done by hand; if not, use a wrench on the flat sides of the attachment, being careful not to overtighten or damage plastic components.

4. **Remove the Old Hose:** Pull the old hose completely out through the top of the faucet spout.
5. **Attach New Hose to Sprayer Head:** Screw the sprayer head onto the new replacement hose. Hand-tighten first, then use a wrench for a snug fit, but do not overtighten.
6. **Feed New Hose Through Faucet:** Carefully feed the new hose down through the faucet spout. It may be easier if you align the curve of the hose with the curve of the faucet.
7. **Connect Quick Connect:** Under the sink, push the quick connect end of the new hose firmly into the water supply line connection until it clicks into place. Gently tug on the hose to ensure it is securely seated.
8. **Reattach Counterweight:** Reattach the counterweight to the new hose in the same position as it was on the old hose. This ensures proper retraction of the pulldown sprayer.
9. **Restore Water Supply:** Slowly turn on the hot and cold water supply valves under the sink.
10. **Check for Leaks:** Inspect all connections for any signs of leaks. If leaks are present, tighten connections as needed.

6. OPERATING

Once properly installed, the Moen 150259 Replacement Hose allows your pulldown kitchen faucet to operate as originally designed. The hose facilitates the extension and retraction of the sprayer head for various kitchen tasks.

7. MAINTENANCE

- Regularly inspect the hose and connections under the sink for any signs of wear, kinks, or leaks.
- Keep the area around the hose under the sink clear of obstructions to allow for smooth operation of the pulldown mechanism.
- Clean the exterior of the hose as needed with a soft cloth and mild soap and water. Avoid abrasive cleaners.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Water leak at connections	Loose quick connect or sprayer head connection. Damaged O-rings.	Ensure quick connect is fully seated. Tighten sprayer head. Check and replace O-rings if damaged.
Hose does not retract smoothly	Counterweight improperly positioned or missing. Obstruction under sink.	Verify counterweight is correctly installed and positioned. Clear any obstructions under the sink.
Low water flow from sprayer	Clogged sprayer head. Kink in hose.	Remove and clean sprayer head. Check hose for kinks and straighten if necessary.

9. SPECIFICATIONS

- **Model Number:** 150259
- **Brand:** Moen
- **Material:** Plastic, Rubber

- **Color:** Gray
- **Hose Length:** 68 inches
- **Outside Diameter:** 0.5 inches
- **Nominal Wall Thickness:** 0.5 inches

10. WARRANTY

This Moen product is covered by a **1 Year Limited Manufacturer Warranty**. For specific details regarding warranty coverage and claims, please refer to the official Moen warranty documentation or contact Moen customer support.

11. SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact Moen customer service through their official website or the contact information provided with your original faucet purchase. You can visit the official Moen website for more information:www.moen.com

© 2026 Moen Incorporated. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

