

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Intex](#) /

› [Intex Double Quick III Hand Air Pump \(Model 68615E\) Instruction Manual](#)

Intex 68615E

Intex Double Quick III Hand Air Pump (Model 68615E) Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Intex Double Quick III Hand Air Pump. Please read these instructions carefully before operation to ensure proper functionality and longevity of your product.

SAFETY INFORMATION

- This product is not a toy. Adult supervision is required, especially when children are present.
- Do not operate the pump near open flames, heat sources, or in explosive atmospheres.
- Do not leave the pump unattended during use.
- Ensure proper nozzle fit to prevent air leakage and ensure efficient inflation.
- Avoid over-inflating items, as this can cause damage to the item or the pump.

PACKAGE CONTENTS

The Intex Double Quick III Hand Air Pump package includes:

- 1 x Intex Double Quick III Hand Air Pump (Model 68615E)
- 1 x Accordion Hose
- 3 x Interconnecting Nozzles (various sizes)
- 1 x Needle Nozzle (for sports balls)

The Intex logo, consisting of the word "INTEX" in a bold, sans-serif font with a registered trademark symbol (®) at the end, all contained within a dark rectangular box.

Double Quick III
Hi-Output Hand Pump

Doble Rapido III

Inflador Manual



± 19in (48cm)

One Pump
Un Inflador



WARNING:
THIS IS NOT A TOY.
USE BY ADULTS ONLY.



ADVERTENCIA:
ESTE PRODUCTO NO ES JUGUETE.
PARA USO DE ADULTOS SOLAMENTE.

Image: The Intex Double Quick III Hand Air Pump, showcasing its main body, accordion hose, and the assortment of nozzles for different valve types.

SETUP

1. Attaching the Hose

To attach the accordion hose, firmly push one end of the hose onto the inflation port (marked "Inflate") or deflation port (marked "Deflate") located on the pump body. Ensure a snug fit to prevent air leakage.

2. Selecting the Nozzle

Choose the appropriate interconnecting nozzle for the valve of the item you wish to inflate or deflate. The pump includes multiple sizes to fit common inflatable valves. For sports balls, use the needle nozzle.

3. Attaching the Nozzle to the Hose

Firmly insert the selected nozzle into the free end of the accordion hose.

OPERATING INSTRUCTIONS

The Intex Double Quick III Hand Air Pump features a double-action design, meaning it pumps air on both the upstroke and downstroke, providing maximum efficiency for both inflation and deflation.

1. Inflation

1. Connect the hose to the "Inflate" port on the pump.
2. Attach the correct nozzle to the item's valve.
3. Place your feet on the footrests at the base of the pump for stability.
4. Hold the handle firmly and move it up and down in a steady motion. Air will be pumped into the item during both movements.
5. Continue pumping until the item is firm. Do not over-inflate.



Image: A person actively using the Intex Double Quick III Hand Air Pump to inflate a pink pool float, demonstrating the pumping motion.



Image: A father and son inflating a large green inflatable toy with the Intex Double Quick III Hand Air Pump, highlighting its user-friendly design for all ages.

2. Deflation

1. Connect the hose to the "Deflate" port on the pump.
2. Attach the correct nozzle to the item's valve.

3. Place your feet on the footrests for stability.
4. Hold the handle firmly and move it up and down. Air will be drawn out of the item during both movements.
5. Continue pumping until the item is fully deflated.

MAINTENANCE

- Keep the pump clean and free from dirt, sand, and debris. Wipe it down with a damp cloth if necessary.
- Store the pump in a dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- Inspect the hose and nozzles regularly for any signs of wear, cracks, or damage. Replace components if necessary to maintain optimal performance.

TROUBLESHOOTING

Slow Inflation/Deflation

- Check that the hose is securely attached to the correct port ("Inflate" for inflation, "Deflate" for deflation) and to the nozzle.
- Ensure the nozzle is properly inserted into the item's valve and that there are no air leaks around the connection.
- Verify that the item's valve is fully open.

Pump Not Working

- Ensure the pump's piston moves freely. If stiff, check for obstructions inside the pump cylinder.
- Confirm that the hose is not kinked or blocked.

SPECIFICATIONS

Feature	Detail
Model	68615E
Brand	Intex
Type	Manual Hand Air Pump
Action	Double Quick (pumps on up & down strokes)
Height	19 inches (48 cm)
Material	Plastic
Weight	987 Grams
Includes	Accordion hose, 3 interconnecting nozzles, 1 needle nozzle

WARRANTY & SUPPORT

This product comes with a manufacturer's warranty. Please refer to the warranty documentation included in your package for specific terms and conditions regarding coverage and duration. For customer support, product registration, or to purchase replacement parts, please visit the official Intex website or contact their customer service department directly.