Whirlpool 8193918

Whirlpool 8193918 Accumulator User Manual

Model: 8193918

Product Overview

The Whirlpool 8193918 Accumulator is a genuine replacement part designed for specific Whirlpool and KitchenAid dishwasher models. This component is crucial for the proper functioning of your dishwasher's cleaning system.



Image: The Whirlpool 8193918 Accumulator. This image displays the gray plastic accumulator, which is a circular component with a serrated outer edge resembling a gear. The center features various structural supports and openings for installation. A smaller, flat circular piece, likely a cover or filter, is shown detached in the foreground.

This accumulator is compatible with the following Whirlpool dishwasher models:

- DU1010XTXQ
- DU1055XTSQ2
- DU1055XTSS0
- DU1010XTXT
- DU1030XTXQ
- DU1030XTXS
- DU1055XTSQ0
- DU1055XTSQ1

Setup and Installation

The Whirlpool 8193918 Accumulator is designed for built-in installation within compatible dishwasher models. Installation typically involves accessing the internal components of the dishwasher. Due to the nature of appliance repair, it is recommended that installation be performed by a qualified technician or an individual with experience in appliance maintenance.

General Installation Guidelines:

1. **Safety First:** Always disconnect power to the dishwasher at the circuit breaker before attempting any repair or installation. Turn off the water supply to the dishwasher.
2. **Access:** Depending on your dishwasher model, you may need to remove the lower spray arm, filter assembly, or other components to gain access to the accumulator. Refer to your specific dishwasher's service manual for detailed disassembly instructions.
3. **Removal of Old Part:** Carefully detach the old accumulator. Note its orientation and how it connects to other parts.
4. **Installation of New Part:** Position the new Whirlpool 8193918 Accumulator in the same manner as the old one. Ensure all connections are secure and properly seated.
5. **Reassembly:** Reassemble any components that were removed, ensuring all parts are correctly aligned and fastened.
6. **Testing:** Restore water and power to the dishwasher. Run a short cycle to check for leaks and proper operation.

Note: This manual provides general guidance. Always consult your specific dishwasher's service manual or a professional technician for precise installation steps.

Operating Instructions

The Whirlpool 8193918 Accumulator is an internal component that functions automatically as part of your dishwasher's wash system. It does not require direct user operation. Once correctly installed, it contributes to the dishwasher's ability to clean dishes effectively by managing water flow and filtration.
Ensure your dishwasher is operated according to its primary user manual. Proper loading, detergent usage, and cycle selection will maximize the performance of all internal components, including the accumulator.

Maintenance

As an internal component, the Whirlpool 8193918 Accumulator generally requires minimal direct maintenance. However, its longevity and performance are directly linked to the overall cleanliness and maintenance of your dishwasher's filtration system.

Recommended Maintenance Practices:

- **Regular Filter Cleaning:** Frequently clean your dishwasher's main filter and any associated screens. Food particles and debris can accumulate and potentially affect the accumulator's function over time.
- **Avoid Overloading:** Do not overload the dishwasher, as this can impede water circulation and lead to inefficient cleaning, potentially stressing internal components.
- **Use Appropriate Detergent:** Use only dishwasher-safe detergents and rinse aids as recommended by your dishwasher manufacturer.
- **Inspect for Debris:** Periodically inspect the area around the accumulator (if accessible) for any large debris that might have bypassed the main filter.

If the accumulator itself becomes clogged or damaged, it typically requires replacement rather than repair.

Troubleshooting

Problems related to the accumulator often manifest as issues with water circulation or cleaning performance. If you experience the following symptoms, the accumulator may be a contributing factor, though other components could also be responsible.

Common Symptoms of Accumulator Issues:

- **Poor Cleaning Performance:** Dishes not getting clean, especially in certain areas of the dishwasher.
- **Food Particles Remaining:** Food debris left on dishes after a wash cycle.
- **Unusual Noises:** While less common for this specific part, any new or unusual noises during the wash cycle could indicate an issue with internal components.

Troubleshooting Steps:

1. **Check Filters:** Ensure all dishwasher filters are clean and free of debris. A clogged filter can mimic accumulator issues.
2. **Inspect Spray Arms:** Verify that spray arm nozzles are not clogged and that the spray arms rotate freely.
3. **Verify Water Supply:** Ensure adequate water pressure is reaching the dishwasher.
4. **Professional Diagnosis:** If symptoms persist after basic checks, it is advisable to consult a qualified appliance technician. Diagnosing and replacing internal dishwasher components like the accumulator often requires specialized knowledge and tools.

Specifications

Attribute	Detail
Manufacturer	Whirlpool
Part Number	8193918
Item Model Number	8193918
Item Weight	14.4 ounces
Product Dimensions	9 x 6.5 x 9.5 inches
Installation Method	Built-in
Item Package Quantity	1
Batteries Required?	No
Certification	Certified Frustration-Free

Warranty and Support

This Whirlpool 8193918 Accumulator is typically covered by a return policy and a limited defective returns period. Please refer to the specific terms of purchase for the most accurate and up-to-date warranty information.

- **Returns:** Generally, a 30-day return policy applies from the date of purchase.

- **Defective Returns:** A 90-day defective returns period is typically offered for parts found to be faulty.

For technical support or further assistance with installation and troubleshooting, it is recommended to contact Whirlpool customer service or a certified appliance repair professional.
For official Whirlpool support, visit the Whirlpool Store on Amazon or their official website.

© 2025 Whirlpool Corporation. All rights reserved.
This manual is for informational purposes only. Whirlpool is a registered trademark.