

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Janome](#) /

› [Janome Center Guide Foot 795819108 Instruction Manual for 1000CPX CoverPro Coverstitch Machine](#)

## Janome 795819108

# Janome Center Guide Foot 795819108 Instruction Manual

For Janome 1000CP, 1000CPX, and 2000CPX CoverPro Coverstitch Machines

## 1. INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of the Janome Center Guide Foot, part number 795819108. This accessory is designed to enhance precision and ease of use when performing coverstitch operations on compatible Janome machines.

The Center Guide Foot assists in creating perfectly straight and evenly spaced coverstitches, particularly useful for hemming and decorative stitching. Please read these instructions carefully before using the foot to ensure optimal performance and safety.

## 2. COMPATIBILITY

The Janome Center Guide Foot (Part # 795819108) is specifically designed for use with the following Janome CoverPro Coverstitch Machine models:

- Janome 1000CP
- Janome 1000CPX
- Janome 2000CPX

Using this foot with incompatible machine models may result in damage to the machine or the foot itself, and may affect stitch quality.

## 3. SETUP AND INSTALLATION

Follow these steps to correctly install the Center Guide Foot on your Janome CoverPro machine:

1. **Power Off:** Ensure your Janome CoverPro machine is turned off and unplugged from the power source before installing or removing any accessories.
2. **Raise Presser Foot:** Lift the presser foot lever to raise the existing presser foot.
3. **Remove Current Foot:** Locate the presser foot holder screw. Loosen this screw to release the standard presser foot. Carefully remove the standard foot.
4. **Attach Center Guide Foot:** Position the Janome Center Guide Foot under the presser foot holder, aligning the pin on the foot with the hole in the holder. Ensure the guide is facing the front of the machine.
5. **Secure Foot:** Tighten the presser foot holder screw firmly to secure the Center Guide Foot in place. Do not overtighten.

6. **Lower Presser Foot:** Lower the presser foot lever to ensure the foot is properly seated and stable.



Figure 1: The Janome Center Guide Foot 795819108. This image shows the metal construction of the foot with its central guide, designed for precise fabric feeding during coverstitch operations.

## 4. OPERATING INSTRUCTIONS

---

The Center Guide Foot is designed to help maintain a consistent seam allowance and straight stitching. Here's how to use it effectively:

1. **Prepare Fabric:** Press your fabric as needed. For hemming, fold and press the hem allowance.
2. **Position Fabric:** Place the edge of your fabric (or the folded edge for a hem) against the central guide of the foot. The guide acts as a fence, ensuring the fabric feeds straight.
3. **Start Stitching:** Lower the presser foot and begin stitching. Guide the fabric gently, keeping its edge consistently against the foot's guide.
4. **Maintain Alignment:** The guide will help you maintain a straight line and consistent distance from the fabric edge, resulting in professional-looking coverstitches.

### Tips for Best Results:

- Always test on a scrap piece of fabric before stitching your final project.
- Adjust your machine's differential feed and stitch length as necessary for your specific fabric type.
- Ensure your needles are sharp and correctly installed.

## 5. MAINTENANCE

---

To ensure the longevity and optimal performance of your Janome Center Guide Foot, follow these simple maintenance guidelines:

- **Cleaning:** Periodically wipe the foot with a soft, dry cloth to remove lint and dust. Avoid using harsh chemicals or abrasive materials.

- **Storage:** Store the foot in a dry, clean place, preferably in its original packaging or a dedicated accessory box, to prevent damage or loss.
- **Inspection:** Before each use, inspect the foot for any signs of damage, bending, or wear. If the foot appears damaged, replace it to prevent potential issues with your machine or stitching.

## 6. TROUBLESHOOTING

If you encounter issues while using the Center Guide Foot, consider the following common solutions:

- **Uneven Stitching:**
  - Ensure the fabric edge is consistently against the guide.
  - Check your machine's tension settings and differential feed.
  - Verify that the foot is securely attached and not loose.
- **Fabric Not Feeding Smoothly:**
  - Ensure the presser foot pressure is correctly set for your fabric type.
  - Clean any lint or debris from under the foot and around the feed dogs.
  - Check for any burrs or rough spots on the foot that might snag fabric.
- **Foot Appears Loose:**
  - Re-tighten the presser foot holder screw.
  - Ensure the foot's pin is correctly seated in the holder.

If problems persist, consult your Janome CoverPro machine's main instruction manual or contact Janome customer support.

## 7. SPECIFICATIONS

<b>Product Name</b>	Janome Center Guide Foot
<b>Part Number</b>	795819108
<b>Compatible Models</b>	Janome 1000CP, 1000CPX, 2000CPX CoverPro Coverstitch Machines
<b>Material</b>	Metal
<b>Approximate Weight</b>	4 ounces (113 grams)
<b>UPC</b>	747465164471
<b>ASIN</b>	B0053G3LLG

## 8. WARRANTY AND SUPPORT

This instruction manual does not contain specific warranty information for the Janome Center Guide Foot 795819108. For details regarding warranty coverage, please refer to the documentation provided with your original Janome CoverPro machine or contact Janome directly.

For technical support, parts, or service inquiries, please visit the official Janome website or contact your authorized Janome dealer. You can often find contact information and support resources on the Janome website:

[Visit Janome Official Website](#)

