

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Prym](#) /
- › [Prym Knitting Loom Model 225161, Medium Size Instruction Manual](#)

Prym 225161

Prym Knitting Loom Model 225161, Medium Size Instruction Manual

Model: 225161 | Brand: Prym

1. INTRODUCTION TO THE PRYM KNITTING LOOM

The Prym Knitting Loom is an innovative tool designed for creating socks, cuffs, and wristlets with ease. This oval knitting ring allows users, including beginners, to produce items with a consistent stitch structure. The loom features sequential numbering and specific markings for right and left stockings, simplifying the sock-making process. This medium-sized loom is suitable for shoe sizes 32-38.



Figure 1: The Prym Knitting Loom, Medium Size, with the included cast-off needle.

2. SAFETY INFORMATION

Warning: Keep this product and its components out of reach of children. The cast-off needle has a pointed tip.

3. PACKAGE CONTENTS

The Prym Knitting Loom package includes the following items:

- 1 x Prym Knitting Loom (Medium Size)
- 1 x Cast-off needle with soft handle
- 1 x Instruction manual

4. INITIAL SETUP

Before beginning your knitting project, ensure you have the loom, the cast-off needle, your chosen yarn, and a pair of scissors. No other specialized tools are required. The loom is ready for use directly out of the package.



Figure 2: Preparing the loom by wrapping yarn around the pegs. Note the 'R' and 'L' markings for right and left sock guidance.

5. OPERATING INSTRUCTIONS

This section outlines the basic steps for knitting with your Prym Loom. For detailed patterns and advanced techniques, refer to the included instruction manual or online resources.

5.1. Casting On

1. Hold the loom with the pegs facing upwards.
2. Take your yarn and make a slip knot. Place the slip knot onto one of the pegs, typically starting from the 'R' or 'L' marked pegs for socks.
3. Wrap the yarn around each peg in a clockwise direction, creating a loop on each peg. Ensure the yarn is snug but not overly tight.
4. Continue wrapping until all desired pegs have a single loop.



Figure 3: Yarn wrapped around multiple pegs, forming the initial loops for knitting.

5.2. Knitting Stitches

1. After casting on, wrap the yarn around the pegs again, creating a second loop above the first on each peg.
2. Using the cast-off needle, lift the bottom loop over the top loop and off the peg. This creates a stitch.
3. Repeat this process for each peg around the loom.
4. Push the newly formed stitches down the pegs to make room for the next row.
5. Continue wrapping and lifting loops to create rows of knitted fabric. The fabric will begin to form and hang down through the center of the loom.



Figure 4: The cast-off needle is used to lift the lower loop over the upper loop and off the peg, forming a stitch.



Figure 5: As knitting progresses, the fabric grows downwards through the center of the loom.

5.3. Casting Off

Once your project reaches the desired length, you will need to cast off the stitches to secure your work. There are various methods for casting off, depending on the desired finish. A common method involves cutting the yarn, leaving a long tail, and using the cast-off needle to thread the tail through each loop on the pegs, then pulling tight to remove the work from the loom. Refer to the included instructions for specific casting off techniques for socks, cuffs, or wristlets.



Figure 6: An example of a finished knitted sock still on the loom, ready for final casting off.

6. CARE AND MAINTENANCE

To ensure the longevity of your Prym Knitting Loom:

- Clean the loom periodically with a soft, damp cloth to remove any dust or yarn fibers.

- Avoid using harsh chemicals or abrasive cleaners, as these may damage the plastic or metal components.
- Store the loom in a dry place, away from direct sunlight and extreme temperatures.
- Keep the cast-off needle protected to prevent bending or dulling of the tip.

7. TROUBLESHOOTING

If you encounter difficulties while using your knitting loom, consider the following:

- **Loose Stitches:** Ensure your yarn is wrapped snugly around the pegs. Consistent tension is key for even stitches.
- **Dropped Stitches:** If a loop falls off a peg, carefully pick it up with the cast-off needle and place it back on the peg before continuing.
- **Difficulty Lifting Loops:** If loops are too tight, try using a slightly thinner yarn or ensure you are not wrapping the yarn too tightly.
- **Uneven Fabric:** Practice maintaining consistent yarn tension throughout your project.

For further assistance, consult the detailed instructions included with your loom or search for online tutorials specific to loom knitting.

8. PRODUCT SPECIFICATIONS

Brand	Prym
Model Name	Knitting Loom
Item Model Number	225161
Size	Medium (suitable for shoe sizes 32-38)
Color	Dark Violet
Material	Plastic, Stainless Steel
Item Dimensions (L x W x H)	1.97 x 1.57 x 5.51 inches
Item Weight	3.36 ounces (0.21 Pounds)
Included Components	Knitting Loom, Cast-off Needle
Manufacturer	ToyMarket
ASIN	B0054D71B2

9. WARRANTY AND SUPPORT

For information regarding warranty coverage or product support, please refer to the documentation included with your purchase or contact Prym customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

