

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

IKEA RAST 753.057.09

IKEA RAST Dresser Instruction Manual

MODEL: RAST 753.057.09

Important Safety Information

This furniture must be secured to the wall with the safety device provided to help prevent it from tipping over if a child climbs or hangs on it. Different wall materials require different types of fasteners. Always use fasteners suitable for the walls in your home to ensure stability and safety.

Always follow the assembly instructions carefully to ensure the dresser is built correctly and securely. Do not modify the product in any way that could compromise its structural integrity or safety features.

Product Overview

The IKEA RAST dresser is a versatile and durable piece of furniture made primarily from solid pine wood. Its untreated surface allows for customization, such as oiling, waxing, lacquering, or staining, to enhance its durability and ease of care.

The dresser features three drawers, providing practical storage. The main parts, drawer sides, and drawer back are constructed from solid pine, while the back panel and drawer bottoms are made of fiberboard with an acrylic paint finish.



Figure 1: Front view of the IKEA RAST dresser, showcasing its natural wood finish and three drawers.



Figure 2: The RAST dresser integrated into a bedroom setting, demonstrating its compact size and utility as a nightstand or small storage unit.



Figure 3: A drawer of the RAST dresser pulled open, illustrating the internal storage capacity.




Figure 4: Detailed view of a wooden drawer knob, highlighting the natural wood texture.

Setup and Assembly

The IKEA RAST dresser requires assembly. All necessary components and a detailed pictorial instruction manual are included in the packaging. Please ensure you have adequate space and the recommended tools before beginning assembly.

1. Unpack all components and verify against the parts list in the included manual.
2. Follow the step-by-step instructions provided in the assembly manual carefully.
3. Once assembled, secure the dresser to the wall using the provided safety device and appropriate fasteners for your wall type. This step is crucial for preventing tip-over accidents.

For optimal stability, ensure all screws and fittings are tightened securely, but do not overtighten.

Operation

The RAST dresser is designed for storing various items within its three drawers. To operate, simply pull the wooden knobs to open the drawers and push them to close. Ensure drawers are closed completely to maintain a tidy appearance and prevent accidental opening.

Avoid overloading the drawers, as this can affect their smooth operation and potentially damage the drawer runners or the dresser structure.

Care and Maintenance

Proper care will extend the life and appearance of your RAST dresser.

- **Cleaning:** Wipe clean with a damp cloth. For best results, wipe dry immediately with a clean cloth.
- **Stain Removal:** Stains can often be removed using an eraser, fine sandpaper, soap, dishwashing detergent, or paint thinner, depending on the type of stain. Always test on an inconspicuous area first.
- **Wood Treatment:** If you oil, wax, lacquer, or stain the untreated solid wood surface, it will become more durable and easier to care for. Follow the instructions of the specific wood treatment product you choose.
- **Avoid Moisture:** Protect the dresser from excessive moisture and direct sunlight to prevent warping or discoloration of the wood.

Troubleshooting

If you encounter issues with your RAST dresser, consider the following common solutions:

- **Wobbly Dresser:** Ensure all assembly screws and wall fasteners are securely tightened. Check that the dresser is placed on a level surface. Adjust glides if present.
- **Drawers Sticking or Not Closing Smoothly:** Verify that the drawer runners are correctly installed and free from obstructions. Ensure drawers are not overloaded. Check that the dresser frame is square and not warped.
- **Damaged Surface:** Minor scratches or dents on the untreated pine can often be sanded lightly with fine-grit sandpaper and then re-treated with oil, wax, lacquer, or stain to match the surrounding area.

For persistent issues not resolved by these steps, refer to the original assembly manual or contact IKEA customer support.

Product Specifications

Feature	Specification
Brand	IKEA
Model Name	RAST 753.057.09

Feature	Specification
Product Dimensions (D x W x H)	11.75"D x 24.38"W x 27.5"H
Color	Wood Color (Untreated Pine)
Mounting Type	Wall Mount (Safety Device Included)
Room Type	Living Room, Bedroom
Special Feature	Durable, Customizable Surface
Furniture Finish	Pine
Product Care Instructions	Wipe with Damp Cloth
Assembly Required	Yes
Item Weight	0.01 Ounces (Note: This weight seems incorrect and likely refers to packaging weight or a placeholder. Actual product weight will be significantly higher.)
Number of Pieces	1 (Dresser Unit)
UPC	608938304476

Warranty and Support

For information regarding product warranty, please refer to your original purchase receipt or the official IKEA website. Warranty terms and conditions may vary by region and purchase date.

If you require further assistance, have questions about assembly, or need to report a missing part, please contact IKEA customer service. You can find contact details on the official IKEA website or through your local IKEA store.

Online Resources: For additional support, assembly videos, and product information, visit the official IKEA website: www.ikea.com