Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tvilum 7417749

Tvilum Napoli TV Unit Model 7417749 User Manual

Comprehensive instructions for assembly, use, and maintenance.

1. Introduction

Thank you for purchasing the Tvilum Napoli TV Unit. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

2. Safety Information

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not use damaged parts.
- Follow assembly steps in the order provided. Do not skip steps.
- Use only the hardware supplied with the unit.
- Do not overtighten screws, as this may damage the material.
- This unit is designed for indoor use only.
- Do not exceed the maximum weight capacity for each shelf or the top surface. Refer to the specifications section for details.
- For safety, it is recommended to secure the TV unit to a wall using an anti-tip kit (if provided or purchased separately) to prevent tipping, especially in households with children.
- Keep small parts and packaging materials away from children and pets.

3. Package Contents

Before starting assembly, verify that all components and hardware are present. If any parts are missing or damaged, please contact customer support.
Note: A detailed list of parts and hardware is typically included in a separate diagram sheet within the packaging.

- Wooden panels (top, bottom, sides, shelves, drawer components)
- Hardware pack (screws, dowels, cam locks, drawer slides, handle)
- Back panel

4. Setup and Assembly Instructions

Assembly of the Tvilum Napoli TV Unit requires basic household tools. It is recommended that two adults assemble this unit.

Tools Required:

- Phillips head screwdriver
- Hammer (for dowels and back panel nails)
- Measuring tape (optional, for placement)

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface. Refer to the parts diagram to identify each piece.
2. **Assemble Drawer:** Follow the specific instructions for assembling the drawer components, including attaching the drawer slides and handle.
3. **Construct Main Frame:** Attach the side panels to the bottom panel using dowels and cam locks/screws. Ensure all connections are secure.
4. **Install Shelves:** Insert the fixed or adjustable shelves into the designated slots or attach them with hardware.
5. **Attach Top Panel:** Secure the top panel to the assembled frame.
6. **Install Back Panel:** Carefully align and nail or screw the back panel to the unit. Ensure it is square to add stability.
7. **Insert Drawer:** Slide the assembled drawer into its designated compartment.
8. **Final Check:** Verify that all screws are tightened and the unit is stable.



Image 1: Front view of the Tvilum Napoli TV Unit, showcasing its design with two open compartments and a lower drawer.

5. Operating Instructions

The Tvilum Napoli TV Unit is designed to hold a television and media accessories. Follow these guidelines for optimal use:

- **Placement:** Place the TV unit on a flat, level surface to ensure stability.
- **Weight Capacity:** Do not exceed the recommended weight limits for the top surface and shelves. Overloading can cause damage or instability.
- **Cable Management:** Utilize the open compartments for media devices and route cables neatly to prevent tangles and improve airflow.
- **Drawer Use:** The drawer is suitable for storing remote controls, DVDs, or other small accessories. Avoid placing heavy items in the drawer that could affect its smooth operation.



Image 2: Side view of the Tvilum Napoli TV Unit, illustrating its profile and depth.

6. Maintenance

Proper care will extend the life and appearance of your TV unit.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or polishes that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

7. Troubleshooting

If you encounter issues with your TV unit, refer to the following common solutions:

- **Unit is Wobbly:**
  - Ensure the unit is on a flat, level surface.
  - Check all assembly hardware (screws, cam locks) are fully tightened.
  - Verify the back panel is correctly installed and square.
- **Drawer Does Not Slide Smoothly:**
  - Check that the drawer slides are correctly installed and aligned on both the drawer and the unit frame.
  - Ensure no obstructions are in the drawer tracks.
  - Do not overload the drawer.
- **Missing or Damaged Parts:**
  - Do not attempt to force assembly with incorrect or damaged parts.
  - Contact Tvilum customer support immediately for replacement parts.

8. Specifications

Brand	Tvilum
Model Number	7417749
Product Dimensions (L x W x H)	94.7 x 48.8 x 41.7 cm
Item Weight	28.2 Kilograms
Assembly Required	Yes
Number of Drawers	1
Color	White

9. Warranty and Support

Tvilum products are manufactured to high-quality standards. For information regarding warranty coverage, replacement parts, or technical support, please refer to the warranty card included with your purchase or visit the official Tvilum website.
Please have your model number (7417749) and purchase date available when contacting support.

© 2024 Tvilum. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0055YYMAA

More documents and user manuals: **https://manuals.plus/**