Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fagor 3FC-67 NFXD

Fagor 3FC-67 NFXD Fridge and Freezer User Manual

Model: 3FC-67 NFXD

1. Introduction

This user manual provides essential information for the safe and efficient operation, installation, and maintenance of your Fagor 3FC-67 NFXD Freestanding Fridge and Freezer. Please read this manual thoroughly before using the appliance and keep it for future reference.
Your Fagor 3FC-67 NFXD is a high-quality, freestanding fridge freezer designed to provide reliable food storage. It features a stainless steel finish and incorporates advanced technologies for optimal performance.

2. Safety Information

Always adhere to the following safety precautions to prevent personal injury or damage to the appliance.

2.1. General Safety

- This appliance is intended for household use only.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Ensure proper ventilation around the appliance. Do not block ventilation openings.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

2.2. Electrical Safety

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not pull the power cord to disconnect the appliance. Always grasp the plug firmly.
- Do not operate the appliance with wet hands.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

3. Product Features

The Fagor 3FC-67 NFXD Fridge and Freezer is equipped with several features designed for convenience and optimal food preservation.





This image displays the Fagor 3FC-67 NFXD freestanding fridge freezer in stainless steel. The upper refrigerator door is partially open, revealing glass shelves, a bottle rack with a green bottle, and a fresh zone compartment with green produce. The lower freezer door is also slightly open, showing clear freezer drawers. The appliance features a sleek design with integrated handles.

- **Multi-Airflow System:** Ensures even cooling throughout the refrigerator compartment, maintaining consistent temperatures for better food preservation.
- **Defrosting System:** Features an efficient defrosting mechanism to minimize ice build-up and simplify maintenance.
- **Fresh Zone Compartment:** A dedicated drawer designed to keep fruits and vegetables fresher for longer.
- **Bottle Rack:** A convenient rack for securely storing bottles horizontally, optimizing space.
- **Ice Cube Tray:** Included for easy preparation of ice cubes.
- **Egg Cup:** A specialized holder for safely storing eggs.
- **Stainless Steel Finish:** Durable and easy-to-clean exterior.
- **Glass Shelves:** Robust and easy to clean shelves in the refrigerator compartment.

4. Setup

4.1. Unpacking

Carefully remove all packaging materials. Inspect the appliance for any transit damage. Report any damage to your retailer immediately. Keep packaging materials out of reach of children.

4.2. Placement

- Place the appliance on a firm, level surface to ensure stability and proper operation.
- Allow adequate space around the appliance for proper ventilation (minimum 10 cm at the back and sides, 30 cm above).
- Avoid placing the appliance in direct sunlight or near heat sources such as radiators, ovens, or cookers, as this will increase energy consumption.
- Ensure the ambient temperature is within the appliance's climate class (SN-T for this model, meaning it operates efficiently in temperatures from 10°C to 43°C).

4.3. Initial Cleaning

Before first use, clean the interior and all internal accessories with lukewarm water and a mild detergent. Dry thoroughly. Do not use abrasive cleaners or solvents.

4.4. First Power-On

After positioning and cleaning, wait at least 2-4 hours before plugging the appliance into the power outlet. This allows the refrigerant to settle. Once plugged in, set the temperature control to the desired setting. Allow the appliance to run for several hours (e.g., 4-6 hours) before loading it with food to ensure it reaches the correct operating temperature.

5. Operating

5.1. Temperature Control

The temperature of the refrigerator and freezer compartments can be adjusted using the control panel, typically located inside the refrigerator compartment or on the top panel. Refer to the specific markings on your appliance for precise temperature settings. Lower numbers usually indicate warmer temperatures, and higher numbers indicate colder temperatures.

5.2. Using Compartments

- **Refrigerator Compartment (88 litres):** Ideal for fresh foods, dairy products, cooked meals, and beverages. Utilize the glass shelves and door bins for organized storage.
- **Fresh Zone Compartment:** Use this dedicated drawer for storing fruits and vegetables to maintain their freshness and crispness.
- **Freezer Compartment (69 litres):** Suitable for long-term storage of frozen foods. Ensure food is properly sealed to prevent freezer burn.

5.3. Multi-Airflow System

The Multi-Airflow System circulates cold air evenly throughout the refrigerator compartment, minimizing temperature fluctuations and ensuring consistent cooling for all items, regardless of their position.

5.4. Defrosting System

Your Fagor 3FC-67 NFXD features an automatic defrosting system in the refrigerator compartment. Frost will periodically melt and drain away. The freezer compartment may require manual defrosting if excessive ice builds up. Refer to the maintenance section for manual defrosting instructions.

6. Maintenance

Regular cleaning and maintenance will ensure the longevity and efficient operation of your appliance.

6.1. Cleaning the Interior

- Unplug the appliance before cleaning.
- Remove all food and removable parts (shelves, drawers).
- Wash the interior with a solution of lukewarm water and a mild, non-abrasive detergent.
- Rinse with clean water and dry thoroughly.
- Clean door seals regularly with clean water to ensure they remain flexible and seal properly.

6.2. Cleaning the Exterior

Wipe the exterior surfaces with a soft cloth dampened with water and a mild detergent. For the stainless steel finish, use a specialized stainless steel cleaner and polish in the direction of the grain to avoid streaks. Do not use abrasive pads or cleaners.

6.3. Defrosting the Freezer (if necessary)

If ice build-up in the freezer compartment exceeds 5mm, manual defrosting is recommended to maintain efficiency. Unplug the appliance, remove all frozen food (store in a cool place), and leave the freezer door open. Place towels at the bottom to absorb melting ice. Do not use sharp objects to remove ice. Once defrosted, clean and dry the interior before restarting.

7. Troubleshooting

Before contacting service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate.	No power supply.	Check if the plug is properly inserted and the fuse/circuit breaker is not tripped.
Temperature is not cold enough.	Door not closed properly; frequent door opening; large amount of warm food added; temperature setting too high.	Ensure door is fully closed; avoid frequent opening; allow warm food to cool before placing inside; adjust temperature setting lower.
Excessive frost build-up in freezer.	Door left open too long; door seal damaged; high humidity.	Ensure door is closed tightly; check and clean door seal; defrost the freezer.
Unusual noises.	Appliance not level; components vibrating; normal operating sounds.	Adjust leveling feet; ensure internal components are secure; gurgling/hissing sounds are normal refrigerant flow.

If the problem persists after performing these checks, please contact a qualified service technician.

8. Specifications

Detailed technical specifications for the Fagor 3FC-67 NFXD Fridge and Freezer:

Brand: Fagor

Model Number: 3FC-67 NFXD

Colour: Stainless Steel

Product Dimensions (H x W x D): 185 cm x 59.8 cm x 61 cm

Refrigerator Capacity: 88 litres

Freezer Capacity: 69 litres

Material: Stainless Steel

Energy Efficiency Class: A

Annual Energy Consumption: 365 Kilowatt Hours

Installation Type: Freestanding

Shelf Type: Glass

Special Features: Multi-Airflow System, Defrosting System, Fresh Zone Compartment, Bottle Rack, Ice Cube Tray, Egg Cup

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your appliance or contact your local Fagor service center. Specific warranty terms may vary by region and retailer.
Please have your model number (3FC-67 NFXD) and serial number ready when contacting support.

© 2023 Fagor. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0055ZITVM

More documents and user manuals: **https://manuals.plus/**