

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sunstech](#) /

› [Sunstech XD TH-20 Home Cinema 5.1 Subwoofer System User Manual](#)

Sunstech TH-XD 20

Sunstech XD TH-20 Home Cinema 5.1 Subwoofer System User Manual

Model: TH-XD 20

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Sunstech XD TH-20 Home Cinema 5.1 Subwoofer System. Please read this manual thoroughly before using the product and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- **Power Source:** Ensure the power supply matches the voltage specified on the unit.
- **Ventilation:** Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- **Water and Moisture:** Do not expose this apparatus to rain or moisture. Do not use near water.
- **Heat:** Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Clean only with a dry cloth.
- **Servicing:** Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x Sunstech XD TH-20 Subwoofer Unit
- 5 x Satellite Speakers
- 1 x Remote Control (with batteries)
- Speaker Cables
- Audio Input Cables

- User Manual (this document)



Image: Sunstech XD TH-20 Home Cinema 5.1 Subwoofer System components.

SETUP INSTRUCTIONS

1. Speaker Placement

For optimal 5.1 surround sound experience, position the speakers as follows:

1. **Center Speaker:** Place directly above or below your TV/monitor.
2. **Front Left/Right Speakers:** Position to the left and right of your TV, equidistant from the listening position.
3. **Rear Left/Right Speakers:** Place behind the main listening position, slightly to the sides.
4. **Subwoofer:** Can be placed anywhere in the room, typically near the front speakers. Experiment with placement for best bass response.

2. Connecting the Speakers

1. Connect each satellite speaker to the corresponding output terminals on the subwoofer unit using the provided speaker cables. Ensure correct polarity (+ to + and - to -).
2. Connect the subwoofer to your audio source (e.g., TV, DVD player, PC) using the appropriate audio input cables. The system supports MP3 playback.

3. Power Connection

1. Ensure all audio connections are secure.
2. Plug the subwoofer's power cord into a wall outlet.
3. Turn on the power switch on the subwoofer unit.

OPERATING INSTRUCTIONS

Basic Operation

- **Power On/Off:** Use the power button on the front panel of the subwoofer or the remote control.
- **Volume Control:** Adjust the master volume using the knob on the subwoofer or the VOL+/- buttons on the remote.
- **Input Selection:** Press the "Input" or "Source" button on the remote or front panel to cycle through available audio inputs (e.g., AUX, MP3).
- **Bass/Treble Control:** Use the dedicated controls on the remote or subwoofer to adjust bass and treble levels to your preference.

MP3 Playback

The Sunstech XD TH-20 supports MP3 audio playback. Connect your MP3 device to the designated MP3 input port on the subwoofer unit. Select the MP3 input source using the input selection button.

MAINTENANCE AND CARE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surfaces of the speakers and subwoofer. Do not use liquid cleaners or aerosol sprays.
- **Placement:** Avoid placing the unit in direct sunlight, near heat sources, or in areas with high humidity or dust.
- **Ventilation:** Ensure adequate airflow around the subwoofer to prevent overheating. Do not cover ventilation openings.
- **Cables:** Periodically check all cable connections for security and damage.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
No sound from speakers	Power not connected Incorrect input selected Speaker cables loose Volume too low	Check power connection and switch Select correct audio input Ensure all speaker cables are securely connected Increase volume
Distorted sound	Volume too high Poor cable connection Audio source issue	Reduce volume Check all audio cables Test with a different audio source
Remote control not working	Batteries depleted Obstruction between remote and unit	Replace batteries Remove any obstructions

SPECIFICATIONS

Model Name	TH-XD 20
Brand	Sunstech
Surround Sound Channel Configuration	5 + Subwoofer (5.1)
Special Feature	MP3 playback
Item Weight	5.2 Kilograms
ASIN	B0055ZKOYW

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or contact Sunstech customer service directly. Keep your purchase receipt as proof of purchase.
For further assistance, visit the official Sunstech website or contact their support channels.

© 2023 Sunstech. All rights reserved.