

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Orbegozo](#) /

› [Orbegozo MIG 2325 Built-in Microwave with Grill 23L 900W Stainless Steel User Manual](#)

Orbegozo MIG 2325

Orbegozo MIG 2325 Built-in Microwave with Grill User Manual

Model: MIG 2325 | Brand: Orbegozo


INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Orbegozo MIG 2325 Built-in Microwave with Grill. Please read it thoroughly before use and keep it for future reference.

The Orbegozo MIG 2325 is a 900W microwave with a 23-liter capacity, featuring a 1000W grill. It is designed for seamless integration into your kitchen cabinetry.

Key Features:

- Stainless steel microwave with 900W power and 23-liter capacity.
- Grill power: 1000W.
- Features 8 power levels, a digital timer up to 95 minutes, a defrost program, and an end-of-cooking sound signal.
- Includes a child safety mechanism.
- Comes with 9 quick cooking menus.



Front view of the Orbegozo MIG 2325 Built-in Microwave with Grill, showcasing its stainless steel finish and digital control panel.

SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your built-in microwave. Ensure the appliance is installed by a qualified technician in accordance with local regulations and the provided installation diagram.

Installation Requirements:

- The microwave is designed for built-in installation.
- Ensure adequate ventilation around the appliance.
- Connect to a grounded electrical outlet with the correct voltage (2.2E+2 Volts).

1. Place food in a microwave-safe container on the turntable.
2. Close the door securely.
3. Select desired power level (8 available).
4. Set cooking time using the digital timer (up to 95 minutes).
5. Press 'Start' to begin cooking. The microwave will emit a sound signal when cooking is complete.

Grill Function:

Use the grill function for browning and crisping food. Ensure food is placed on the grill rack (if included) and not directly on the turntable for best results.

Defrost Program:

The defrost program allows for efficient thawing of frozen foods. Select the defrost function and input the weight of the food for automatic time calculation.

Quick Cooking Menus:

Utilize the 9 pre-set quick cooking menus for common food items. Refer to the control panel or the full manual for specific menu options and their usage.

Child Safety Lock:

To prevent accidental operation, activate the child safety lock. Consult the full manual for instructions on how to engage and disengage this feature.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave.

Cleaning the Interior:

- After each use, wipe the interior with a damp cloth to remove food splatters.
- For stubborn stains, place a bowl of water with lemon slices inside and microwave for a few minutes to create steam, then wipe clean.
- The turntable and support ring can be removed and washed with mild soap and water.

Cleaning the Exterior:

- Wipe the exterior stainless steel surfaces with a soft, damp cloth.
- Avoid abrasive cleaners or scouring pads, as they can damage the finish.

General Maintenance:

- Ensure the microwave door seals are clean and free from food debris to maintain proper sealing.
- Do not operate the microwave if the door or seals are damaged.

TROUBLESHOOTING

If you encounter issues with your Orbegozo MIG 2325, refer to the following common problems and solutions before

contacting service.

Problem	Possible Cause	Solution
Microwave does not start.	Door not closed properly; power cord unplugged; circuit breaker tripped; child lock activated.	Ensure door is fully closed; check power connection; reset circuit breaker; deactivate child lock.
Food not heating.	Incorrect power level or cooking time set; microwave-safe dish not used.	Adjust power level and cooking time; use only microwave-safe cookware.
Unusual noise during operation.	Turntable not correctly placed; foreign object inside.	Ensure turntable is seated correctly; check for and remove any foreign objects.
Display not working.	Power interruption.	Unplug and re-plug the microwave after a few minutes.

For problems not listed here or if solutions do not resolve the issue, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Orbegozo
Model Number	MIG 2325
Capacity	23 Liters
Microwave Power	900 Watts
Grill Power	1000 Watts
Installation Type	Built-in
Material	Stainless Steel
Product Dimensions (L x W x H)	48.3 x 35.7 x 30.5 cm (15.17 kg)
Control Type	Tactile
Special Features	Defrost, Timer, Programmable, Control Panel Safety (Child Lock)

WARRANTY AND SUPPORT

Warranty Information:

Specific warranty details for the Orbegozo MIG 2325 are not available in this document. Please refer to the warranty card included with your product or visit the official Orbegozo website for comprehensive warranty terms and conditions.

Customer Support:

For technical assistance, spare parts, or any inquiries regarding your Orbegozo MIG 2325 microwave, please contact Orbegozo customer service. Contact information can typically be found on the manufacturer's website or in the product packaging.

When contacting support, please have your model number (MIG 2325) and serial number (if applicable) ready.

© 2024 Orbegozo. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.