

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Skuttle](#) /

› [Skuttle Humidifier Evaporator Pad A04-1725-034 Instruction Manual](#)

Skuttle A04-1725-034

Skuttle Humidifier Evaporator Pad A04-1725-034 Instruction Manual

INTRODUCTION

This document provides instructions for the installation, operation, and maintenance of the Skuttle Humidifier Evaporator Pad, model A04-1725-034. This aftermarket humidifier filter belt (evaporator pad) is designed for optimal performance in compatible humidifier models.

PRODUCT OVERVIEW

Key Features

- High performance and output.
- Designed for efficient water evaporation.

Compatibility

This evaporator pad is compatible with the following humidifier models:

- Skuttle models: 81, 90, 90-S, 90-SH, 90-SH1, 109, 190, 190-SH, 190-SH1, H90, H90S, H100, H100-S
- White-Rodgers model: HDT2600



Image of the Skuttle Humidifier Evaporator Pad, showing its rectangular shape and fibrous material.

SETUP AND INSTALLATION

The evaporator pad measures approximately 7 1/2 inches (H) x 26 1/2 inches (L) x 1 inch (W). Ensure these dimensions match the requirements of your humidifier model before installation.

1. **Power Off:** Before beginning any installation or maintenance, ensure your humidifier unit and HVAC system are powered off to prevent accidental operation.
2. **Access Humidifier:** Open the humidifier housing to access the existing evaporator pad. Refer to your humidifier's specific manual for instructions on how to open the unit and remove the old pad.
3. **Remove Old Pad:** Carefully remove the old evaporator pad. In some models, this may involve detaching clips or a rotating rod mechanism. Note how the old pad was secured for easier installation of the new one.
4. **Install New Pad:** Position the new Skuttle Humidifier Evaporator Pad A04-1725-034 into the humidifier unit. Ensure it is seated correctly and securely within its designated holder or frame. If clips were present, reattach them to secure the new pad.
5. **Close Humidifier:** Close the humidifier housing securely.
6. **Restore Power:** Restore power to your humidifier unit and HVAC system.

OPERATING PRINCIPLE

The evaporator pad functions as the core component of your humidifier, facilitating the transfer of moisture into the air. Water from the humidifier's reservoir or water supply flows over or through the pad. As air from your HVAC system passes through the moistened pad, it absorbs water vapor, increasing the humidity level in your home. The fibrous material of the pad maximizes the surface area for efficient evaporation.

MAINTENANCE

Regular replacement of the evaporator pad is crucial for maintaining optimal humidifier performance and air quality.

- For optimum performance, replace the evaporator pad every 6 months or twice per heating season.
- Replacement frequency may vary based on water hardness and humidifier usage. Hard water can lead to mineral buildup, reducing the pad's efficiency.

TROUBLESHOOTING

- **Reduced Humidification:** If your humidifier is not producing sufficient humidity, check if the evaporator pad is heavily encrusted with mineral deposits. A clogged pad will reduce water absorption and evaporation. Replace the pad if necessary.
- **Improper Fit:** Ensure the pad is correctly sized and securely installed in the humidifier unit. An improperly fitted pad may not allow for efficient water flow or air passage.
- **Water Leaks:** Verify that the pad is installed correctly and not obstructing any water drainage paths. Check for any damage to the humidifier unit itself.

SPECIFICATIONS

Brand	Skuttle
Special Feature	Evaporator Pad
Color	Black
Operation Mode	Manual (referring to humidifier operation)
Item Weight	1.6 ounces
Product Dimensions	12 x 2 x 10 inches (packaging dimensions); Pad: 7 1/2" H x 26 1/2" L x 1" W
Model Name (Manufacturer)	CECOMINOD023967
Included Components	Evaporator Pad
UPC	076252004431
ASIN	B00564VO64
Date First Available	March 2, 2007

WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct support contacts for the Skuttle Humidifier Evaporator Pad A04-1725-034 is not provided in the available product data. Please refer to the documentation provided with your humidifier unit or contact the manufacturer of your humidifier for warranty and support inquiries related to compatible models.

