

Gillette LVD21494

Gillette Blue II Disposable Razor Blade User Manual

Model: LVD21494

1. INTRODUCTION

Thank you for choosing the Gillette Blue II Disposable Razor Blade. This manual provides essential information for the safe and effective use of your razor. Designed for a convenient and smooth shaving experience, the Gillette Blue II features two chromium-coated blades and a water-activated Lubrastrip for enhanced glide. Please read this manual thoroughly before first use and retain it for future reference.

2. PRODUCT OVERVIEW AND FEATURES

The Gillette Blue II Disposable Razor is engineered for a comfortable and efficient shave. Key features include:

- **Twin Blades:** Equipped with two high-quality chromium-coated blades for a close shave.
- **Water-Activated Lubrastrip:** Provides smooth glide and helps reduce friction during shaving.
- **Fixed Head:** Designed for stability and control during shaving.
- **Easy Grip Handle:** Ergonomically designed for comfortable and secure handling, enhancing maneuverability.
- **Disposable Design:** Convenient for travel and single-use applications.



Figure 2.1: Packaging of Gillette Blue II Disposable Razor Blades, showing a pack of five razors.

Gillette

2 CHROMIUM COATED BLADES





Figure 2.2: Detail of the razor head, highlighting the two chromium-coated blades for durability and sharpness.

Gillette

WATER-ACTIVATED LUBRASTRIP FOR
SMOOTH GLIDE




Blue II[™]
PLUS

Figure 2.3: The water-activated Lubrastrip, designed to provide a smooth glide during shaving.

Gillette

FIXED HEAD



Blue II[™]
PLUS

Figure 2.4: Illustration of the fixed head design, ensuring consistent blade angle for control.

Gillette



EASY GRIP HANDLE FOR
GREAT
MANOEUVRABILITY

Blue II[™]
PLUS

Figure 2.5: The easy-grip handle, designed for comfortable and effective maneuverability.

Gillette

LESS RAZOR BURN*



*VS SENSOR2
WITHOUT LUBRASTRIP

Blue II[™]
PLUS

Figure 2.6: The Lubrastrip's contribution to reducing razor burn, providing a smoother experience.

Gillette

USE WITH GILLETTE SERIES GEL



Blue II[™]
PLUS

Figure 2.7: Recommendation to use the razor with Gillette Series shaving gel for optimal results.

3. SETUP

The Gillette Blue II is a disposable razor and requires minimal setup. It is ready for use directly from its packaging.

1. **Unpack:** Carefully remove the razor from its protective packaging.
2. **Inspect:** Before use, visually inspect the razor for any signs of damage or dullness. Do not use if blades appear damaged or bent.

4. OPERATING INSTRUCTIONS

Follow these steps for an optimal shaving experience:

1. **Prepare Skin:** Wet your face or body area to be shaved with warm water. This helps to soften the hair and

open pores.

2. **Apply Shaving Cream/Gel:** Apply a generous amount of shaving cream or gel (such as Gillette Series Gel) to the area. This creates a protective layer and helps the razor glide smoothly.
3. **Shave:** Hold the razor at a comfortable angle. Shave in the direction of hair growth using light, gentle strokes. Avoid applying excessive pressure.
4. **Rinse Razor:** Frequently rinse the razor blades under running water during shaving to clear away hair and shaving cream buildup.
5. **Rinse Skin:** After shaving, rinse your skin thoroughly with cool water to close pores.
6. **Moisturize:** Apply an aftershave balm or moisturizer to soothe and hydrate your skin.

5. MAINTENANCE

Proper maintenance ensures hygiene and extends the effective life of your disposable razor:

- **Cleaning:** After each use, rinse the razor thoroughly under running water to remove all hair and shaving cream. Do not tap the razor against a hard surface, as this can damage the blades.
- **Drying:** Shake off excess water and allow the razor to air dry. Do not wipe the blades, as this can dull them or cause injury.
- **Storage:** Store the razor in a dry place, away from excessive humidity, to prevent corrosion. Keep it out of reach of children.
- **Disposal:** When the Lubrastrip fades to white or the blades feel dull, it's time to dispose of the razor. Dispose of used razors safely in a designated waste bin.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Razor pulling hair or feeling rough	Blades are dull or clogged.	Rinse blades thoroughly. If still dull, replace the razor.
Skin irritation or razor burn	Insufficient lubrication, dry shaving, or shaving against the grain.	Ensure skin is well-lubricated with shaving cream/gel. Shave with the grain. Use a fresh razor.
Nicks or cuts	Applying too much pressure, dull blades, or uneven skin surface.	Use light strokes. Replace dull razors. Be extra careful around contours.

7. SPECIFICATIONS

Attribute	Detail
Brand	Gillette
Model Number	LVD21494

Attribute	Detail
Number of Blades	2
Special Feature	Double Edge, Fixed Head, Lubrastrip
Unit Count	5 Count (as per typical packaging)
Product Dimensions	3.94 x 4.33 x 4.72 inches (packaging); 0.71 ounces
Manufacturer	Minevra Trading.
Skin Type	All

8. SAFETY INFORMATION

WARNING: Razor blades are extremely sharp. Handle with extreme care.

- Keep out of reach of children.
- Do not touch the blades directly.
- Do not use if the razor or blades appear damaged.
- For external use only.
- Ingredients: PLASTIC (for the razor body).
- If irritation occurs, discontinue use.

9. WARRANTY AND SUPPORT

As a disposable product, the Gillette Blue II Razor does not typically come with a long-term warranty. However, Gillette is committed to product quality.

- **Quality Assurance:** If you experience any issues with the product's quality upon purchase, please retain the packaging and contact Gillette customer service.
- **Contact Information:** For support, questions, or feedback, please visit the official Gillette website or refer to the contact details provided on the product packaging.
- [Visit the Gillette Store on Amazon](#) for more products and information.