

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Quicent](#) /

> [Quicent 10x30 Party Tent Instruction Manual](#)

Quicent 1402

Quicent 10x30 Party Tent Instruction Manual

Model: 1402
Brand: Quicent

INTRODUCTION

This instruction manual provides comprehensive guidance for the assembly, operation, maintenance, and troubleshooting of your Quicent 10x30 Party Tent. Designed for outdoor events, this canopy tent offers a versatile and reliable shelter solution. Please read this manual thoroughly before setup to ensure safe and proper use.



Image: The Quicent 10x30 Party Tent, showcasing its spacious interior and elegant design, suitable for various outdoor gatherings.

SAFETY INFORMATION

Your safety is paramount. Adhere to the following guidelines to prevent injury or damage to the tent.

- **Provisional Use Only:** This product is intended for provisional use and should not be left outside overnight in windy or rainy conditions.
- **Weather Conditions:** Avoid using the tent in high winds or heavy rain. Severe weather can compromise the tent's stability and lead to collapse.

- **Securing the Tent:** Always secure each leg with adequate weight, approximately 44 lbs (20 kg) per leg, and utilize all provided ground stakes and tie-down ropes for maximum stability.
- **Heat Sources:** Keep the canopy away from open flames or high heat sources to prevent fire hazards.
- **Assembly Personnel:** Assembly requires a minimum of two people for safe and efficient setup.
- **Level Surface:** Ensure the tent is set up on a reasonably level surface for optimal stability.


PARTS LIST

Before beginning assembly, verify that all components listed below are present and undamaged. All parts are clearly labeled for easy identification.

- Heavy-duty waterproof 120g polyethylene tent cover
- 32mm white powder-coated metal poles (various lengths for roof and legs)
- High-quality PE connectors and extra-base plates
- Ground stakes
- Tie-down ropes
- 6 windowed sidewalls
- 2 zippered doors
- White duct tape (for reinforcing joints)
- Additional accessories (nails, etc.)

Reinforced Structure

Provided to increase the stability of the party tent



Pole Sleeve



Durable PE Connector

High-quality PE connectors and extra-base plates make the whole structure more stable and beautiful.

Image: An illustration detailing the reinforced structure of the tent, highlighting the pole sleeves and durable PE connectors for enhanced stability.

SETUP AND ASSEMBLY

Assembly is tool-free and designed to be straightforward. Follow these steps for a successful setup.



1. **Unpack and Organize:** Lay out all components and organize them by type. Refer to the parts list and ensure all pieces are accounted for.
2. **Assemble the Roof Frame:** Begin by connecting the metal poles and PE connectors to form the entire roof structure on the ground. Ensure all connections are secure.
3. **Reinforce Joints:** Use the provided white duct tape to reinforce each joint in the roof frame. This is a critical step for stability, especially in mild wind conditions. For easier disassembly, fold the end of each tape piece onto itself.
4. **Drape the Canopy:** Carefully drape the polyethylene tent cover over the assembled roof frame while it is still on the ground. Stretch it evenly and secure it to the frame.
5. **Attach Legs and Raise:** With the help of at least two people, lift the assembled roof and canopy structure. Insert the vertical leg poles into the designated connectors. Gradually raise the tent to its full height, ensuring all legs are properly seated.
6. **Secure the Base:** Once the tent is upright, secure each leg to the ground. If on grass or bare ground, use the provided ground

stakes. For paved surfaces, use weights (approx. 44 lbs per leg) to prevent shifting.

7. **Install Sidewalls and Doors:** Attach the 6 windowed sidewalls and 2 zippered doors as desired. These panels can be removed or repositioned to suit your event's needs.
8. **Utilize Tie-Down Ropes:** For additional stability, especially in outdoor settings, use the tie-down ropes to anchor the tent securely.

Multiple Uses

8 Removable Sidewalls



DIY Combination



1 x Zippered Door



5 x Side Walls



7 x Side Walls

Image: A visual guide demonstrating the modularity of the tent, showing how the 8 removable panels (6 windowed sidewalls and 2 zippered doors) can be configured for various setups.

OPERATING INSTRUCTIONS

The QuicTent 10x30 Party Tent is designed for flexibility and ease of use in various outdoor scenarios.

- **Capacity:** The tent comfortably accommodates 40-50 guests, making it suitable for medium to large gatherings.
- **Panel Configuration:** Utilize the removable sidewalls and zippered doors to adjust light, ventilation, and access. You can create an open-air canopy or a more enclosed space as needed.
- **Recommended Uses:** This tent is ideal for a wide range of outdoor activities including weddings, parties, BBQ events,

camping, carports, and outdoor markets.

Various Scenes

Perfect for both commercial
and recreational use



Barbecue

Weddings



Gathering

Stalls



Image: Examples of various scenes where the QuicTent party tent can be used, including barbecues, weddings, family gatherings, and market stalls.

MAINTENANCE

Proper maintenance will extend the lifespan of your QuicTent party tent.

- **Cleaning:** Clean the polyethylene cover with mild soap and water. Avoid harsh chemicals or abrasive cleaners that could damage the material. Ensure the cover is completely dry before storage to prevent mildew.
- **Storage:** When not in use, disassemble the tent carefully and store all components in a dry, cool place, away from direct sunlight. Proper dismantling will allow for repeated use.
- **Inspection:** Periodically inspect all poles, connectors, and the tent cover for any signs of wear, damage, or corrosion. Address minor issues promptly to prevent further deterioration.

TROUBLESHOOTING

Refer to this section for solutions to common issues you might encounter.

- **Tent is Unstable/Wobbly:**

- Ensure all legs are properly secured with adequate weight (44 lbs per leg) or ground stakes.
- Verify that all tie-down ropes are correctly anchored and taut.
- Confirm that the tent cover is stretched tightly and attached to the bottom of the legs, as this significantly adds stability.
- Check if the tent is on a level surface. Adjust as necessary.

- **Poles or Joints Come Apart During Assembly:**

- Ensure all connections are fully inserted.
- Use the provided white duct tape to reinforce every joint after assembly of the roof frame.

- **Damage to Poles or Cover:**

- If poles are kinked or split, or the cover tears, contact Quictent customer service immediately for replacement parts. Do not attempt to use a damaged tent in adverse weather conditions.

- **Water Accumulation on Roof:**

- Ensure the tent cover is taut and properly stretched over the frame to prevent pooling.
- This tent is designed to withstand light rain; however, it should not be used in heavy rain.

SPECIFICATIONS

Feature	Detail
Brand	Quictent
Model Number	1402
Material	Alloy Steel, Plastic, Polyethylene (PE)
Color	White
Product Dimensions	360"L x 120"W x 103.3"H (10'x30' footprint)
Ultraviolet Light Protection	UV Protection
Water Resistance Level	Waterproof
Assembly Required	Yes
Item Weight	67 pounds
Capacity	40-50 guests

Product Size



Capacity
15-30 people



Package Size
44x8.7x13 in



Image: A visual representation of the tent's dimensions, indicating its 10ft width, 30ft length, and 8.6ft height.

WARRANTY AND SUPPORT

QuicTent is committed to providing quality products and excellent customer service.

- **Warranty Coverage:** We offer a 6-month coverage on the tent cover and poles from the date of purchase.
- **Lifetime Replacement:** Connectors, nails, ropes, and other accessories are covered by a lifetime replacement policy.
- **Customer Service:** If any parts are damaged or you require assistance, please contact our after-sales service team. We aim to respond within 12 hours.
- **Contact Information:** For support, please refer to the contact details provided on your purchase receipt or visit the official QuicTent website.

