



[Manuals.plus](#) /

› [BaByliss](#) /

› BaByliss Travel Folding Hair Dryer 5344U User Manual

## BaByliss 5344U

# BaByliss Travel Folding Hair Dryer User Manual

MODEL: 5344U

## Introduction

This manual provides essential instructions for the safe and effective use of your BaByliss Travel Folding Hair Dryer, Model 5344U. Please read all instructions carefully before use and retain this manual for future reference.



Image: The BaByliss Travel Folding Hair Dryer, black in color, shown alongside its orange and white retail packaging. The dryer is unfolded, displaying its compact design.

## Important Safety Instructions

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep away from water. Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Keep the power cord away from heated surfaces.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being

administered.

- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- The appliance is hot when in use. Do not let eyes or bare skin touch heated surfaces.
- Do not place the appliance on any surface while it is operating.
- Clean the air filter regularly to prevent overheating.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

## Product Features

---

The BaByliss Travel Folding Hair Dryer is designed for convenience and performance, featuring:

- **Powerful 2000W Motor:** Provides fast drying results.
- **Dual Voltage:** Suitable for worldwide use (125V/240V).
- **2 Heat/Speed Settings:** Offers flexibility for different hair types and styling needs.
- **Folding Handle:** Compact design for easy storage and travel.
- **Concentrator Nozzle:** For precise styling.



Image: A close-up view of the front grille of the BaByliss hair dryer, highlighting its 2000W power rating printed on the side.



# 2 heats/ speeds

Image: A detailed view of the orange heat and speed selector switch on the handle of the BaByliss hair dryer, showing settings for '0' (off), 'I' (low), and 'II' (high).

## Setup

1. **Unpacking:** Carefully remove the hair dryer and all accessories from the packaging. Ensure all components are present and undamaged.
2. **Voltage Selection:** Before plugging in, verify the voltage selector switch on the handle is set to the correct voltage for your region (125V or 240V). Use a small flat-head screwdriver or a similar tool to adjust the switch if necessary.

# Worldwide use



Image: A close-up of the voltage selector switch located on the handle of the hair dryer, clearly marked with '125' and '240' for dual voltage operation.

3. **Unfolding the Handle:** Gently unfold the handle until it clicks securely into place.



Image: A person's hand holding the BaByliss Travel Folding Hair Dryer in its unfolded, ready-to-use position, demonstrating its ergonomic design.

4. **Attaching the Concentrator Nozzle:** If desired, firmly push the concentrator nozzle onto the front of the hair dryer until it is secure.

## Operating Instructions

1. **Plug In:** Insert the power plug into an appropriate electrical outlet.
2. **Select Heat/Speed:** Use the switch on the handle to select your desired heat and speed setting:
  - **0:** Off
  - **I:** Low heat/speed
  - **II:** High heat/speed
3. **Drying Hair:** Direct the airflow towards your hair, keeping the dryer moving to prevent concentrating heat in one

area. For best results, use the concentrator nozzle for precise styling.

4. **Finishing:** Once drying is complete, switch the dryer to '0' (off) and unplug it from the power outlet.

## Maintenance

- **Cleaning the Air Filter:** Regularly check the rear filter for dust and lint buildup. To clean, ensure the dryer is unplugged and cool. Gently twist or pull off the rear filter cover (if removable) and brush away any debris. Replace the filter cover securely. A clogged filter can reduce performance and lead to overheating.
- **Storage:** When not in use, ensure the dryer is cool and unplugged. Fold the handle for compact storage. Store in a dry, safe place, out of reach of children. Do not wrap the power cord around the dryer, as this can damage the cord.



Image: The BaByliss Travel Folding Hair Dryer shown with its handle folded, illustrating its compact form factor for easy storage or travel.

## Troubleshooting

Problem	Possible Cause	Solution
Dryer does not turn on.	Not plugged in; power outlet issue; voltage switch incorrect; internal fuse/thermal cut-out activated.	Ensure plug is fully inserted. Test outlet with another appliance. Verify voltage switch setting. Allow dryer to cool down if thermal cut-out activated.
Low airflow or overheating.	Clogged air filter.	Unplug the dryer and clean the rear air filter as described in the Maintenance section.
Unusual smell during first use.	Normal for new appliances due to manufacturing residues.	The smell should dissipate after a few minutes of use. Ensure good ventilation.

If the problem persists after attempting these solutions, please contact customer support.

## Specifications

- **Model:** 5344U
- **Power:** 2000W
- **Voltage:** Dual Voltage (125V / 240V)
- **Settings:** 2 Heat / 2 Speed
- **Material:** Plastic
- **Color:** Black
- **Dimensions (folded):** Approximately 21 x 16 x 8 cm
- **Weight:** Approximately 750 g
- **Manufacturer:** The Conair Group Ltd
- **Country of Origin:** China

## Warranty and Support

This BaByliss appliance is guaranteed for a period of *[Insert Warranty Period Here, e.g., 3 years]* against defects in materials and workmanship. During this period, BaByliss will repair or replace the product, at its discretion, free of charge for parts or labor.

This warranty does not cover damage caused by misuse, abuse, accidental damage, or use with unauthorized attachments. It also does not cover normal wear and tear.

For warranty claims or technical support, please contact your local BaByliss customer service department or visit the official BaByliss website for contact information.

