

[Manuals.plus](#) /

› [GLI PRO](#) /

› GLI PRO BLUE8DVD Bluetooth Line Array Speaker User Manual

GLI PRO BLUE8DVD

GLI PRO BLUE8DVD Bluetooth Line Array Speaker User Manual

Model: BLUE8DVD

INTRODUCTION

Thank you for choosing the GLI PRO BLUE8DVD Bluetooth Line Array Speaker. This manual provides essential information for the safe and efficient operation of your speaker system. Please read it thoroughly before use and retain it for future reference.

SAFETY INSTRUCTIONS

- **Power Source:** Connect the speaker only to a power supply specified in this manual or marked on the unit.
- **Ventilation:** Ensure proper ventilation. Do not block any ventilation openings.
- **Water and Moisture:** Do not expose the unit to rain or moisture. Do not place objects filled with liquids on the unit.
- **Heat:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Clean only with a dry cloth.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Placement:** Use the standard size pole mount hole on the bottom or the rubber feet for stable floor standing.

PACKAGE CONTENTS

Verify that all items are present in the package:

- GLI PRO BLUE8DVD Bluetooth Line Array Speaker
- Power Cord
- User Manual (this document)
- CAR SPEAKER

PRODUCT FEATURES

The GLI PRO BLUE8DVD speaker system offers a range of features for versatile audio playback and visual effects:

- Integrated crossover with four drivers: two 8-inch woofers, one 8-inch midrange, and one high-frequency driver.

- Four tuned ports for enhanced bass response.
- Integrated MP3 Media player supporting USB, SD, and Bluetooth connectivity.
- Full-feature LED light show with multiple control modes.
- Standard pole mount hole and rubber feet for flexible placement.
- Multiple audio inputs: XLR (Mic/Line 1), RCA (Line 2), and 3.5mm Jack (Line 2).
- Treble and Bass tone controls.
- Link output for connecting to other audio devices.

CONTROLS AND CONNECTIONS

Familiarize yourself with the various controls and connection points on your speaker.



Image: Front view of the GLI PRO BLUE8DVD Bluetooth Line Array Speaker, showing the speaker grille and LED light panel.

Audio Inputs and Outputs:

- **MIC / Line 1 Input (XLR Jack):** For connecting a microphone or an audio source with line level output (e.g., mixer, CD player).
- **RCA Line 2 Input:** For connecting an audio source with line level output (e.g., mixer, CD player).
- **3.5mm Line 2 Input:** For connecting portable audio devices.
- **Link Output:** For connecting the audio signal to another speaker or audio device.

Controls:

- **Level Mic / Line 1:** Volume control for the microphone or Line 1 input.
- **Level Player / Line 2:** Volume control for the integrated media player and Line 2 inputs.
- **Treble Control:** Adjusts high-frequency tones.
- **Bass Control:** Adjusts low-frequency tones.
- **LED Show Mode Control Knob:** Selects various light show modes.
- **Color Select Knob:** Adjusts color patterns in certain LED modes.
- **Light Brightness Control:** Adjusts the intensity of the LED lights.

SETUP

1. **Placement:** Position the speaker on a stable, flat surface using its rubber feet, or mount it on a standard speaker pole. Ensure adequate ventilation around the unit.
2. **Power Connection:** Connect the power cord to the speaker's power input and then to a suitable electrical outlet.
3. **Initial Power On:** Turn on the speaker using the power switch. The LED lights may illuminate.
4. **Audio Source Connection:** Connect your desired audio source (e.g., smartphone via Bluetooth, microphone via XLR, CD player via RCA) to the appropriate input.
5. **Volume Adjustment:** Start with all volume controls (Level Mic/Line 1, Level Player/Line 2) at their minimum settings before playing audio.

OPERATING INSTRUCTIONS

Using the Integrated Media Player (USB/SD/Bluetooth):

1. **USB/SD Playback:** Insert a USB drive or SD card containing MP3 files into the respective slot on the speaker. The player should automatically detect and begin playback.
2. **Bluetooth Pairing:**
 - Activate Bluetooth on your audio device (e.g., smartphone, tablet).
 - Select "Bluetooth" mode on the speaker's media player.
 - Search for available devices on your audio device. The speaker should appear as "GLI PRO" or a similar identifier.
 - Select the speaker to pair. Once paired, you can stream audio wirelessly.
3. **Volume Control:** Adjust the "Level Player/Line 2" knob for the overall volume of the media player.

LED Show Mode Control:

The LED Show Mode control knob offers several visual effects:

- **OFF:** Turns the LED lights off.
- **Mood:** Lights illuminate solidly.
- **Meter:** The column of lights simulates a digital volume meter.
- **Mix:** Lights illuminate according to the frequency spectrum of the audio signal. Bass frequencies produce more red light, mid-range more green, and treble more blue.
- **Pulse:** The audio signal causes the lights to pulse with one color (determined by the Color Select knob), with brightness determined by the Light Brightness knob.
- **Party:**
 - When the Color Select knob is fully counter-clockwise, LEDs cycle rapidly through a pre-programmed dynamic

show of colors and meter levels.

- Turning the Color Select knob clockwise from this position changes to a slower continuous cycle of solid colors.
- Turning the Color Select knob further clockwise slows down how quickly the colors change.

Use the **Light Brightness Control** to adjust the intensity of the LED lights.

MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the exterior surfaces. Do not use liquid cleaners or aerosol cleaners.
- **Storage:** If storing the speaker for an extended period, ensure it is clean, dry, and stored in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically check the power cord for any damage. If damaged, have it replaced by qualified personnel.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; outlet not active.	Ensure power cord is securely connected to speaker and a live outlet. Check power switch.
No sound output	Volume too low; incorrect input selected; audio source issue; cables loose.	Increase volume controls. Verify correct input source. Check audio source playback. Ensure all audio cables are securely connected.
Bluetooth not connecting	Speaker not in Bluetooth mode; device too far; interference; previously paired device.	Ensure speaker is in Bluetooth mode. Move device closer. Turn off other Bluetooth devices. Forget speaker from device's Bluetooth list and re-pair.
LED lights not working	LED Show Mode set to OFF; brightness too low.	Check LED Show Mode knob is not set to OFF. Increase Light Brightness Control.

SPECIFICATIONS

Model Name	GLIPRO
Item Model Number	BLUE8DVD
Speaker Type	Subwoofer
Speaker Size	8 Inches
Wireless Communication Technology	Bluetooth
Connectivity Technology	Bluetooth, Wired (XLR, RCA, 3.5mm)
Power Source	Corded Electric
Control Method	Touch

Product Dimensions	1"D x 1"W x 1"H (Note: This dimension may refer to a component, not the full speaker unit.)
Item Weight	19 Pounds
Color	Black
Manufacturer	GLI PRO
Country of Origin	China

WARRANTY AND SUPPORT

This product comes with a limited warranty from GLI PRO. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or contact GLI PRO customer support.

For technical support, troubleshooting assistance, or service inquiries, please contact GLI PRO customer service through their official website or the contact information provided with your product documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0056L32LC>

More documents and user manuals: <https://manuals.plus/>