Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Homecraft /
- > Homecraft Two-Handled Mug User Manual

Homecraft 091165422

Homecraft Two-Handled Mug User Manual

Model: 091165422

1. PRODUCT OVERVIEW

The Homecraft Two-Handled Mug is designed to provide a secure and comfortable drinking experience, particularly for individuals who may have difficulty gripping standard cups. Its robust design, dual handles, and choice of lids make it a versatile aid for daily hydration.



Image 1.1: The Homecraft Two-Handled Mug, featuring a clear body, two large handles, and a white spout lid.

Key Features:

- **Dual Handles:** Two wide handles for easy and comfortable gripping, enhancing stability and reducing spills.
- 300 ml Capacity: An ideal volume for various beverages, assisting users who find it challenging to drink from conventional cups.
- Interchangeable Lids: Includes two lids, one with a small opening and one with a large opening, to control liquid flow.
- Microwave Safe: Convenient for reheating beverages.
- Dishwasher Safe: Easy to clean, washable up to 85°C.

2. SAFETY INFORMATION

- Always inspect the mug and lids for any damage before each use. Do not use if cracks or damage are present.
- Ensure the lid is securely fastened before drinking to prevent spills.
- When using in a microwave, ensure the lid is not sealed tightly to allow steam to escape. Do not overheat liquids.
- Exercise caution when handling hot liquids. The mug itself may become warm.

- Keep out of reach of children when filled with hot liquids.
- This product is intended for drinking liquids. Do not use for purposes other than its intended use.

3. SETUP AND ASSEMBLY

The Homecraft Two-Handled Mug comes pre-assembled. Before first use, it is recommended to wash all components thoroughly.

3.1. Initial Cleaning:

- 1. Disassemble the mug by removing the lid from the main body.
- 2. Wash the mug body and both lids with warm soapy water, or place them in a dishwasher (top rack recommended) up to 85°C.
- 3. Rinse all components thoroughly to remove any soap residue.
- 4. Allow all parts to air dry completely before reassembly or storage.

3.2. Attaching the Lid:

- 1. Choose the desired lid (small spout or large spout) based on the user's preference and liquid consistency.
- 2. Align the lid with the top rim of the mug.
- 3. Press down firmly and twist clockwise until the lid is securely seated and forms a tight seal. Ensure there are no gaps.



Image 3.1: The two interchangeable lids provided with the mug, illustrating the small spout opening and the large spout opening options.

4. OPERATING INSTRUCTIONS

Using the Homecraft Two-Handled Mug is straightforward, designed for ease of use and spill prevention.

- 1. **Fill the Mug:** Pour your desired beverage into the mug. Do not overfill; leave some space at the top to prevent overflow when the lid is attached. The mug has a capacity of 300 ml.
- 2. Attach the Lid: Securely attach one of the provided lids as described in Section 3.2.
- 3. **Grip the Handles:** Use both large handles for a stable and comfortable grip. The design allows for easy lifting and control.
- 4. **Drinking:** Tilt the mug to allow liquid to flow through the chosen spout opening. The spouts are designed to control the flow rate, reducing the risk of choking or spills.
- 5. **Microwave Use:** If reheating, ensure the lid is loosely placed or slightly ajar to allow steam to escape. Heat in short intervals and check temperature before consumption.



Image 4.1: The Homecraft Two-Handled Mug filled with orange juice, demonstrating its use for various beverages.

5. MAINTENANCE AND CLEANING

Proper care and cleaning will ensure the longevity and hygiene of your Homecraft Two-Handled Mug.

- **Daily Cleaning:** After each use, disassemble the mug and wash all parts with warm, soapy water. Use a brush if necessary to clean inside the spouts.
- **Dishwasher Cleaning:** The mug and lids are dishwasher safe up to 85°C (185°F). Place components on the top rack for best results.
- Drying: Allow all components to air dry completely before storing to prevent mold or mildew growth.
- **Storage:** Store the mug and lids in a clean, dry place away from direct sunlight or extreme temperatures.
- **Avoid Abrasives:** Do not use abrasive cleaners, scourers, or harsh chemicals, as these can scratch or damage the plastic.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lid leaks or is not secure.	Lid not aligned correctly; debris on rim; lid or mug damaged.	Ensure lid is properly aligned and twisted until secure. Check for and remove any debris. Inspect lid and mug for cracks or damage; replace if necessary.
Liquid flow is too fast/slow.	Incorrect lid chosen; spout blocked.	Ensure you are using the appropriate lid (small or large spout) for desired flow. Clean the spout thoroughly to remove any blockages.

Problem	Possible Cause	Solution
Mug retains odor or stains.	Incomplete cleaning; prolonged exposure to staining liquids.	Clean immediately after use. For stubborn stains, soak in a solution of warm water and baking soda, then scrub. Ensure thorough drying.

7. SPECIFICATIONS

Feature	Detail
Brand	Homecraft
Model Number	091165422
Color	Clear
Material	Plastic
Capacity	300 Milliliters
Dimensions (L x W x H)	15.5 x 8.5 x 11 cm (6.1 x 3.3 x 4.3 inches)
Item Weight	0.2 g (0.007 oz) - Note: This weight seems unusually low and might be a typo in the source data.
Microwave Safe	Yes
Dishwasher Safe	Yes (up to 85°C)




Image 7.1: Dimensional diagram of the Homecraft Two-Handled Mug, indicating a height of 12 cm (4.8 inches).

8. WARRANTY AND SUPPORT

Homecraft products are designed for durability and reliability. For any questions, concerns, or support regarding your Homecraft Two-Handled Mug, please contact Homecraft customer service. Please refer to the product packaging or the official Homecraft website for the most up-to-date warranty information and contact details.

Note: Information regarding spare parts availability is not provided.

© 2024 Homecraft. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

Related Documents - 091165422



Homecraft Revive Sauna Heater Installation Manual

Installation guide for Homecraft Revive sauna heaters (6kw, 7.5kw, 9kw). Covers electrical specifications, safety guidelines, sauna rock usage, control installation, and warranty. ETL approved.



Homecraft Apex Sauna Heater Installation and User Guide

Comprehensive guide for installing and using the Homecraft Apex sauna heater, covering safety, electrical specifications, installation steps, and warranty information for models 10kW, 12kW, 15kW, and 18kW.



HomeCraft 30-Cup Stainless Steel Coffee Urn: Operation and Maintenance Guide

A comprehensive guide on how to operate and maintain the HomeCraft 30-Cup Stainless Steel Coffee Urn, including brewing coffee and heating water, along with cleaning instructions and helpful tips.



Homecraft Revive Slim Sauna Heater Installation Manual - 4kW, 5kW, 6kW

Comprehensive installation manual for the Homecraft Revive Slim sauna heater (4kW, 5kW, 6kW). Covers safety, specifications, sauna rock requirements, installation procedures for the heater and control system, and warranty information.



Homecraft Sauna Touchpad Operating Instructions

Detailed operating instructions for the Homecraft sauna touchpad, covering temperature and time settings, display functions, and basic operation.

HomeCraft.



HomeCraft CU30SS 30-Cup Stainless Steel Coffee Urn Instruction Manual

Instruction manual for the HomeCraft CU30SS 30-Cup Stainless Steel Coffee Urn. Learn how to safely operate, clean, and maintain your coffee urn for optimal performance. Includes safety precautions, features, and warranty information.