

TRIXIE 4011905437873

Trixie 39451 Metal Dog Gate Instruction Manual

INTRODUCTION

Thank you for choosing the Trixie 39451 Metal Dog Gate. This instruction manual provides essential information for the safe and correct installation, operation, and maintenance of your new pet gate. Please read this manual thoroughly before installation and keep it for future reference. This gate is designed to restrict access for pets and can also be used for children, providing a secure barrier in doorways or at the top/bottom of stairs.

PRODUCT OVERVIEW

The Trixie 39451 Metal Dog Gate is a pressure-mounted safety gate designed for versatile use within your home. Its robust metal construction and white lacquered finish ensure durability and blend seamlessly with most home decors. Key features include:

- **Safety Lock:** Designed for convenient one-hand opening and closing.
- **Easy Attachment:** Utilizes 4 clamping devices for secure, screw-free, and drill-free installation.
- **Versatile Use:** Ideal for closing off rooms, doorways, and staircases.
- **Durable Construction:** Made from metal with a white lacquered finish.
- **Adjustable Width:** Fits openings between 75 cm and 85 cm.
- **Height:** Approximately 76 cm.
- **Closure Type:** Magnetic.

SAFETY INSTRUCTIONS

Please adhere to the following safety guidelines to prevent injury or damage:

- **Read All Instructions:** Ensure you understand all installation and operating instructions before use.
- **Secure Installation:** Always ensure the gate is securely installed and properly tensioned before use.
- **Regular Checks:** Periodically check all locking and mounting mechanisms to ensure they are functioning correctly and securely fastened.

- **Gate Placement:** Do not use this gate at the top of stairs without additional safety measures if it is not explicitly designed for such use. This gate is primarily designed for doorways and bottom of stairs.
- **Adult Supervision:** This gate is a deterrent, not a substitute for adult supervision. Never leave children or pets unattended.
- **Damage:** Do not use the gate if any components are damaged or missing. Contact customer support for replacement parts.
- **Cleaning:** Clean only with a damp cloth and mild soap. Avoid abrasive cleaners.

PACKAGE CONTENTS

Before beginning installation, please verify that all parts are present:

- 1x Trixie 39451 Metal Dog Gate frame with integrated door
- 4x Pressure mounting bolts with wall cups
- 1x Instruction Manual (this document)

If any parts are missing or damaged, please do not proceed with installation. Contact Trixie customer support immediately.

SETUP (INSTALLATION)

The Trixie 39451 Metal Dog Gate is designed for pressure mounting, requiring no drilling or screws. Follow these steps for a secure installation:

1. **Unpack the Gate:** Carefully remove all components from the packaging.
2. **Initial Placement:** Position the gate frame within the desired opening (doorway or staircase). The gate will initially appear slightly misaligned or open at the latch side; this is normal for pressure-mounted gates and will correct upon tensioning.
3. **Attach Mounting Bolts:** Screw the four pressure mounting bolts into the corners of the gate frame. Ensure the wall cups are attached to the ends of the bolts.
4. **Adjust Tension:** Hand-tighten each mounting bolt until the wall cups make contact with the wall or door frame.
5. **Fine-Tune Alignment:** Gradually tighten each bolt, alternating between top and bottom, and left and right, until the gate frame is firmly secured and the latch mechanism aligns and closes smoothly. The gap at the latch side should close to a minimal, consistent distance. Do not overtighten, as this can damage the wall or frame.
6. **Test Security:** Once installed, push and pull on the gate to ensure it is firmly in place and cannot be easily dislodged. Test the opening and closing mechanism multiple times.



Image: The Trixie 39451 Metal Dog Gate securely installed in a doorway, demonstrating its pressure-mounted design.



Image: A detailed view of the pressure mounting bolt and wall cup, showing how the gate is secured without drilling.

OPERATING INSTRUCTIONS

The Trixie 39451 Metal Dog Gate features a safety lock designed for easy one-hand operation by adults.

- **To Open:** Locate the safety lock mechanism, typically at the top of the gate door. Simultaneously press the release button (if present) and lift the gate door slightly, then swing it open in the desired direction.
- **To Close:** Gently swing the gate door back into the closed position. The magnetic closure will engage, and the safety lock should automatically click into place, securing the gate. Always ensure the gate is fully latched before walking away.

MAINTENANCE

Regular maintenance will ensure the longevity and safe operation of your Trixie dog gate.

- **Cleaning:** Wipe the gate regularly with a soft, damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaning materials, which can damage the finish.
- **Check Tension:** Periodically check the tension of the pressure mounting bolts. If the gate feels loose or the latch does not align properly, re-tighten the bolts as described in the "Setup" section.
- **Inspect Components:** Regularly inspect all parts, including the frame, door, hinges, and locking mechanism, for any signs of wear, damage, or loose components.
- **Lubrication:** If the hinges or latch mechanism become stiff, a small amount of silicone-based lubricant can be applied.

TROUBLESHOOTING

If you encounter issues with your Trixie dog gate, refer to the following common problems and solutions:

- **Gate Does Not Latch Properly:**
 - Ensure the gate is installed correctly and tensioned evenly. The gap at the latch side should be minimal.
 - Gradually tighten the pressure mounting bolts, especially the ones closest to the latch, until the latch aligns and closes securely.
 - Check for any obstructions preventing the door from closing fully.
- **Gate Feels Loose or Wobbly:**
 - The pressure mounting bolts may not be tightened enough. Re-tighten all four bolts evenly until the gate is firm.
 - Ensure the wall cups are flush against a flat, stable surface.
- **Gate is Difficult to Open/Close:**
 - The gate might be overtightened. Slightly loosen the pressure mounting bolts until the door swings freely but remains secure.
 - Check the latch mechanism for any debris or damage.

If these solutions do not resolve the issue, please contact Trixie customer support.

SPECIFICATIONS

Model Number	4011905437873
ASIN	B0057FXQOU
Brand	TRIXIE
Material	Metal
Color	White
Adjustable Width	75 cm – 85 cm
Height	76 cm
Item Weight	4.58 Kilograms
Mounting Type	Pressure Mounted (Door Frame Mounting)

Closure Type	Magnetic
Target Species	Dog (also suitable for children)
Age Range (Description)	All Ages
Country of Origin	China

WARRANTY INFORMATION

This Trixie 39451 Metal Dog Gate is covered by the manufacturer's warranty. Please refer to the warranty documentation provided with your purchase or visit the official Trixie website for detailed terms and conditions. Keep your proof of purchase for any warranty claims.

SUPPORT

For further assistance, missing parts, or technical support regarding your Trixie 39451 Metal Dog Gate, please contact Trixie customer service. Contact information can typically be found on the product packaging or the official Trixie website.

When contacting support, please have your product model number (4011905437873) and ASIN (B0057FXQOU) ready.