

[Manuals.plus](#) /

› [Mountfield](#) /

› Mountfield M4401 Lawnmower Blade Instruction Manual

Mountfield M4401

Mountfield M4401 Lawnmower Blade Instruction Manual

Genuine Replacement Blade for Mountfield Lawnmowers

PRODUCT OVERVIEW

This manual provides essential instructions for the safe and effective use, installation, and maintenance of your Mountfield M4401 replacement lawnmower blade. This is a genuine Mountfield spare part designed for durability and optimal performance.

Model: M4401

Replaces: Model 27900



Image 1: Mountfield M4401 Lawnmower Blade. This image shows the replacement blade, typically made of metal, with a central mounting hole and cutting edges. It is designed to fit specific Mountfield lawnmower models.

SAFETY INFORMATION

Always prioritize safety when handling lawnmower blades. Failure to follow these safety instructions can result in serious injury.

- **Disconnect Power:** Before attempting any installation or maintenance, ensure the lawnmower's spark plug lead is disconnected (for petrol models) or the power cord is unplugged (for electric models).
- **Wear Protective Gear:** Always wear heavy-duty gloves and eye protection when handling the blade. Blades are sharp and can cause cuts.
- **Secure the Mower:** Ensure the lawnmower is stable and cannot move or tip over during blade replacement.
- **Inspect for Damage:** Before installation, inspect the new blade for any manufacturing defects or damage.
- **Proper Disposal:** Dispose of old blades responsibly and safely, as they may still be sharp.

SETUP AND INSTALLATION

Follow these steps carefully to replace your lawnmower blade.

1. Prepare the Lawnmower:

- Ensure the fuel tank is empty or the mower is tilted so fuel does not spill (for petrol mowers).
- Disconnect the spark plug lead or unplug the power cord.
- Tilt the mower onto its side, ensuring the carburetor and air filter are facing upwards to prevent oil or fuel leakage.

2. Remove the Old Blade:

- Using a block of wood or a specialized blade removal tool, secure the blade to prevent it from turning.
- Using a wrench, loosen and remove the blade bolt(s) that hold the blade to the mower shaft. Note the direction of rotation for loosening (usually counter-clockwise).
- Carefully remove the old blade, noting any washers or spacers and their order.

3. Install the New Blade:

- Ensure the new Mountfield M4401 blade is oriented correctly. The cutting edge should face the direction of rotation.
- Place the new blade onto the mower shaft, ensuring it sits flush and any washers or spacers are correctly positioned.
- Insert and tighten the blade bolt(s) securely. Use a torque wrench if specified in your lawnmower's main manual to ensure proper tightness.
- Re-secure the blade with the block of wood or tool and tighten the bolt(s) firmly.

4. Final Check:

- Ensure the blade is securely fastened and spins freely without obstruction.
- Return the mower to its upright position.
- Reconnect the spark plug lead or plug in the power cord.

OPERATING INSTRUCTIONS (POST-INSTALLATION)

After installing the new blade, follow these general operating guidelines:

- **Test Run:** Start the lawnmower in a clear area and allow it to run for a few moments. Listen for any unusual noises or vibrations. If any are present, immediately shut off the mower and re-check the blade installation.
- **Cutting Height:** Adjust the cutting height of your lawnmower according to your lawn's needs and grass type.
- **Clear Debris:** Before mowing, clear the lawn of any stones, sticks, or other debris that could damage the blade or be thrown by it.
- **Mow Safely:** Always operate the lawnmower according to its primary instruction manual, maintaining a safe distance from the rotating blade.

MAINTENANCE

Proper maintenance extends the life of your blade and ensures optimal cutting performance.

- **Regular Inspection:** After each use, inspect the blade for damage, nicks, bends, or excessive wear.
- **Cleaning:** Clean the blade and the underside of the mower deck after each use to prevent grass buildup, which can affect cutting performance and balance. Ensure the mower is off and the spark plug lead is disconnected before cleaning.
- **Sharpening:** Blades should be sharpened regularly to maintain a clean cut. If you are not experienced in blade sharpening, it is recommended to have it done by a professional or replace the blade when it becomes dull. An unbalanced blade can cause excessive vibration and damage to the mower.
- **Replacement:** Replace the blade if it is severely bent, cracked, or excessively worn. A damaged blade can be dangerous and reduce cutting efficiency.

TROUBLESHOOTING

If you encounter issues after blade replacement, consider the following:

- **Excessive Vibration:**
 - **Cause:** Blade not properly balanced or installed, bent blade, or loose blade bolt.
 - **Solution:** Shut off the mower immediately. Disconnect power. Re-check blade installation, ensuring the bolt is tight and the blade is centered. Inspect the blade for bends or damage; replace if necessary.
- **Poor Cutting Performance:**
 - **Cause:** Dull blade, incorrect blade orientation, or grass buildup on the blade/deck.
 - **Solution:** Disconnect power. Inspect the blade for sharpness and correct orientation. Clean the blade and mower deck. Sharpen or replace the blade if dull.
- **Blade Not Spinning Freely:**
 - **Cause:** Obstruction, incorrect installation, or damaged mower shaft.
 - **Solution:** Disconnect power. Check for any obstructions. Re-check blade installation. If the shaft appears damaged, consult a professional.

SPECIFICATIONS

Mountfield M4401 Blade Specifications

Feature	Detail
Model Number	M4401
Replaces Part Number	27900
Brand	Mountfield
Product Type	Lawnmower Blade
Package Dimensions	38.6 x 15.6 x 3.4 cm
Item Weight	400 grams
Power Source Type	Electric (for compatible mowers)

WARRANTY AND SUPPORT

As this is a replacement part, its warranty is typically covered under the terms of the original purchase or by the retailer. Please retain your proof of purchase.

For specific warranty details or technical support, please refer to the official Mountfield website or contact your authorized Mountfield dealer. You may also refer to the instruction manual provided with your original Mountfield lawnmower for further guidance on blade replacement and maintenance.

Mountfield Official Website: www.mountfieldlawnmowers.co.uk (Example link, actual link may vary by region)



