

[Manuals.plus](#) /

› [RUSK](#) /

› RUSK Engineering W8less Professional 2000 Watt Dryer User Manual

RUSK IREW8LSBD

RUSK Engineering W8less Professional 2000 Watt Dryer User Manual

Model: IREW8LSBD

INTRODUCTION

The RUSK Engineering W8less Professional 2000 Watt Dryer is designed for efficient and effective hair drying. Weighing less than 1 pound, this lightweight dryer is infused with ceramic and tourmaline to emit far-infrared heat waves, which penetrate hair more deeply, resulting in faster drying times and reduced static and frizz. It is suitable for all hair lengths, styles, and textures, particularly effective on thick, coarse hair.



Image: The RUSK W8less Professional 2000 Watt Dryer, showcasing its compact and ergonomic design.

SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, do not use this appliance near water. Do not use while in the bath or near a sink full of water. If the dryer falls into water, unplug it immediately before attempting to retrieve it. Regularly check the power cord for any signs of damage. If damage is observed, discontinue use and replace the appliance.

SETUP

Unboxing and Inspection

Carefully remove the dryer and all accessories from the packaging. Inspect the dryer for any visible damage. Ensure the concentrator nozzle is included.



Image: The RUSK W8less Dryer alongside its product packaging.

Attaching the Concentrator Nozzle

The dryer comes with a concentrator nozzle. To attach, align the nozzle with the front barrel of the dryer and push firmly until it clicks into place. To remove, gently pull the nozzle off.




Image: Detailed diagram highlighting the concentrator nozzle and other features of the RUSK W8less Dryer.

OPERATING INSTRUCTIONS

Power and Settings

The RUSK W8less Dryer features intuitive controls for customized styling:

- **Speed Settings:** Use the bottom switch to select between 'LOW' and 'HIGH' airflow. The 'OFF' position powers down the dryer.
- **Heat Settings:** Use the middle switch to choose your desired temperature: 'HOT', 'COOL', or 'WARM'.
- **Cold Shot Button:** Press and hold the blue 'COLD' button for an instant blast of cool air to set your style.



Image: Close-up view of the dryer's control panel, showing the cold shot button, heat settings, and speed settings.

Drying Techniques

After shampooing and conditioning, towel-dry hair to remove excess moisture. Part hair into sections for easier drying.

- **General Drying:** Use the dryer with a styling brush, directing hot air through one section of hair at a time.
- **Straightening:** Work with hair in sections. Use a large round brush, paddle brush, or styling brush and hold hair taut in each section while drying.
- **Frizz and Static Reduction:** The ceramic and tourmaline infusion, along with the ion generator, helps to minimize frizz and static for a smoother finish.



Image: A professional stylist demonstrating the use of the RUSK W8less Dryer for styling hair.

MAINTENANCE

Cleaning the Air Filter

Regularly clean the rear air filter to maintain optimal performance and prevent overheating. The filter can be removed for cleaning. Ensure the dryer is unplugged before cleaning.



Image: Close-up of the dryer's ceramic grill, which is infused with tourmaline.

Cord Care

Avoid wrapping the power cord tightly around the dryer, as this can cause damage. Store the cord loosely to prevent kinks and fraying.

TROUBLESHOOTING

If your dryer is not functioning as expected, please check the following:

- Ensure the power cord is securely plugged into a working electrical outlet.
- Verify that the speed and heat settings are correctly selected.
- Check the air filter for any blockages and clean if necessary.

- If the dryer overheats, it may automatically shut off. Unplug it and allow it to cool down before resuming use.

SPECIFICATIONS

Feature	Detail
Model Number	IREW8LSBD
Wattage	2000 watts
Power Source	Corded Electric
Special Features	Infrared Technology, Ionic Technology, Lightweight
Hair Type Compatibility	Curly (also effective on thick, coarse hair)
Number of Speeds	7 (combining 2 speed and 3 heat settings)
Included Components	Concentrator Nozzle
Item Weight	16 ounces (1 Pound)
Product Dimensions	4.5 x 10.3 x 10.5 inches
Material Type	Ceramic, Titanium
Color	White

WARRANTY

The RUSK Engineering W8less Professional 2000 Watt Dryer comes with a **Limited Two-Year Manufacturer Warranty**. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, product information, or to inquire about service, please visit the official RUSK website or contact their customer support. Refer to the product packaging for specific contact details.

OFFICIAL PRODUCT VIDEOS

RUSK W8less Dryer Overview

Your browser does not support the video tag.

Video: An official overview of the RUSK W8less Dryer, highlighting its features and benefits.

Review: RUSK Professional Hair Dryer

Your browser does not support the video tag.

Video: A detailed review of the RUSK Professional Hair Dryer, discussing its performance and user experience.

This Hairdryer Should Be Called Old Faithful

Your browser does not support the video tag.

Video: A user review emphasizing the durability and long-term reliability of the RUSK W8less Dryer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question