

Polti Vaporettino Lux (PGGB0006)

Polti Vaporettino Lux Steam Cleaner User Manual

Model: Vaporettino Lux (PGGB0006)

1. INTRODUCTION

The Polti Vaporettino Lux is a versatile and convenient handheld steam cleaner designed for effective and hygienic cleaning throughout your home. It utilizes a powerful blast of dry steam generated under high pressure to dissolve dirt and disinfect surfaces without the need for harsh chemicals. Its compact size and ease of handling make it ideal for tackling stubborn stains and various cleaning tasks.



Figure 1: The Polti Vaporettino Lux Steam Cleaner, a compact and powerful handheld unit.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before filling, emptying, or cleaning.
- Do not direct steam at people, animals, or electrical appliances. Steam is very hot and can cause burns.
- Never open the safety cap while the appliance is under pressure or hot. Allow it to cool down completely before refilling.
- Use only distilled or demineralized water to prevent limescale build-up. For optimal performance and longevity, consider using Polti Kalstop.
- Keep the appliance out of reach of children and pets.
- Do not immerse the appliance in water or any other liquid.
- Regularly check the power cord for damage. If damaged, it must be replaced by a qualified service technician.
- This appliance is for household use only. Do not use it for commercial or industrial purposes.

3. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 × Polti Vaporettino Lux Steam Cleaner Unit
- 1 × Flex Hose
- 1 × Steam Lance
- 1 × Brass Brush
- 1 × Round Brush
- 1 × Steam Grout Tool
- 1 × Steam Nozzle
- 1 × Steam Spatula
- 1 × Steam Window Tool
- 1 × Cloth
- 1 × Water Jug



Figure 2: All included accessories for the Polti Vaporettino Lux, including various brushes, nozzles, and tools for diverse cleaning tasks.

4. SETUP

- 1. Unpack the Appliance:** Carefully remove the Polti Vaporettino Lux and all accessories from the packaging.
- 2. Fill the Water Tank:**
 - Unscrew the safety cap on top of the unit.
 - Using the provided water jug, fill the tank with up to 0.2 litres of distilled or demineralized water. Do not overfill.
 - For enhanced performance and to prevent limescale, you may add a dose of Polti Kalstop (sold separately) as per its instructions.
 - Securely screw the safety cap back on until it is tight.



Figure 3: Illustrates the process of filling the water tank of the steam cleaner, ensuring proper water level and cap closure.

- 3. Attach Desired Accessory:** Select the appropriate accessory for your cleaning task (e.g., steam lance, brush, window tool) and firmly attach it to the steam nozzle.
- 4. Connect to Power:** Plug the power cord into a suitable grounded electrical outlet. The indicator light will illuminate, signaling that the unit is heating up.

5. OPERATING INSTRUCTIONS

The Polti Vaporettino Lux heats up quickly, typically within a few minutes. The indicator light will turn off or change color when the operating pressure is reached.

- 1. Steam Activation:** Press and hold the steam activation button located on the handle to release steam. Release the button to stop the steam flow.
- 2. Steam Regulation:** The unit features a steam regulation dial (min/max) to adjust the intensity of the steam output according to the surface and cleaning requirement.

3. Cleaning Surfaces:

- **Hard Surfaces (Tiles, Grout):** Use the steam grout tool or a brush attachment. Move the tool slowly over the surface to allow the steam to penetrate and loosen dirt.



Figure 4: The steam cleaner effectively cleaning grout lines on a tiled floor using a specialized brush attachment.

- **Fabrics (Garments, Upholstery):** Use the steam lance or a cloth-covered attachment. Hold the nozzle a few inches away from the fabric and move it steadily. Test on an inconspicuous area first.



Figure 5: Demonstrates the steam cleaner being used to refresh and de-wrinkle a suit jacket, highlighting its versatility for fabric care.

- **Windows and Mirrors:** Attach the steam window tool. Apply steam to the surface, then use the squeegee blade to wipe away condensation and dirt.



Figure 6: A user cleaning a mirror with the Polti Vaporettino Lux, showcasing the effectiveness of the window tool for streak-free results.

- **Small Objects (Jewelry, Fixtures):** Use the steam nozzle directly, holding it at a safe distance.



Figure 7: The steam cleaner's focused steam jet being used to clean small, intricate items like jewelry, demonstrating its precision cleaning capability.

4. **Refilling:** If the steam output decreases significantly or stops, the water tank is empty. Unplug the unit and allow it to cool down for at least 10-15 minutes before carefully unscrewing the safety cap and refilling.
5. **Finishing:** When cleaning is complete, unplug the appliance and allow it to cool down completely before storing.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Polti Vaporettino Lux.

- **Emptying the Tank:** After each use, once the unit has cooled down completely, carefully unscrew the safety cap and empty any remaining water from the tank.
- **Cleaning the Exterior:** Wipe the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Accessory Care:** Clean all accessories after use. Brushes can be rinsed with water. Ensure they are dry before storing.
- **Descaling (Limescale Prevention):** To prevent limescale build-up in the boiler, which can affect steam flow and appliance efficiency, regularly use Polti Kalstop. Follow the instructions provided with the Kalstop product. The frequency depends on the hardness of your water and usage.
- **Storage:** Store the appliance and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or very little steam.	Water tank is empty. Appliance not heated sufficiently. Limescale build-up in boiler.	Refill water tank (after cooling). Wait for indicator light to signal readiness. Perform descaling with Polti Kalstop.

Problem	Possible Cause	Solution
Water dripping from nozzle.	Appliance not fully heated. Overfilling the tank. Holding the unit at an incorrect angle.	Wait for full heating. Do not exceed max fill line. Hold the unit level during operation.
Safety cap cannot be opened.	Appliance is still under pressure or hot.	Unplug the unit and allow it to cool down completely (at least 10-15 minutes). Press the steam button to release any residual pressure.
Power indicator light not on.	Appliance not plugged in. Power outlet issue. Appliance malfunction.	Ensure plug is fully inserted. Test outlet with another device. Contact customer support if problem persists.

If you encounter a problem not listed here, or if the suggested solutions do not resolve the issue, please contact Polti Customer Support.

8. SPECIFICATIONS

Brand	Polti
Model Name	Vaporettino Lux
Model Number	PGGB0006
Colour	White and Green
Product Dimensions	18.3 x 34.5 x 28.3 cm
Item Weight	1.8 kg
Water Tank Capacity	0.2 litres
Power / Wattage	1000 watts
Material	18/8 Stainless Steel (Boiler)
Steam Pressure	3 Bars
Special Feature	Steam Regulation
Surface Recommendation	Hard Floor (and various other surfaces with accessories)

9. WARRANTY AND SUPPORT

Polti products are manufactured to high quality standards and are guaranteed against manufacturing defects for a period specified by local consumer laws from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical assistance, spare parts, or to locate an authorized service center, please visit the official Polti website or contact their customer service department. Contact details can typically be found on the Polti website or on the product packaging.

