

Roku 3100R

Roku 2 XS 1080p Streaming Player Instruction Manual

Brand: Roku | Model: 3100R

1. OVERVIEW

The Roku 2 XS is a streaming player designed to deliver high-definition entertainment to your television. It supports 1080p HD streaming and includes features for motion-based gaming. This device provides access to a wide array of streaming channels, including popular services like Netflix, Hulu Plus, and Amazon Instant Video. It also offers a free mobile application for iOS and Android devices, enhancing control and content browsing. Connectivity options include Ethernet for wired connections and a USB port for playing local media.



Image: The Roku 2 XS 1080p Streaming Player, a compact black device with the Roku logo, shown with a purple Roku tag on its side.

2. WHAT'S INCLUDED

- Enhanced remote with motion control for games
 - Angry Birds game (pre-installed or included as a code)
 - Two AA batteries
 - A/V cable (red/white/yellow)
 - Power adapter
 - Get Started guide
-

3. WHAT YOU NEED

- A television
 - High-speed Internet service (minimum 1.2 Mbps; 5 Mbps recommended for HD video)
 - A wireless router (for Wi-Fi connectivity)
-

4. SETUP

Follow these steps to set up your Roku 2 XS streaming player:

1. **Connect to TV:** Connect the Roku 2 XS to your television using the provided A/V cable or an HDMI cable (not included). For optimal 1080p HD quality, an HDMI connection is recommended.
2. **Connect Power:** Plug the power adapter into the Roku 2 XS and then into a wall outlet.
3. **Power On:** Turn on your television and select the correct input source (HDMI or A/V) where the Roku 2 XS is connected.
4. **Initial Setup:** Follow the on-screen instructions to connect to your Wi-Fi network and link your Roku account. If you do not have a Roku account, you will be prompted to create one.
5. **Remote Pairing:** The enhanced remote should automatically pair with your device. If not, refer to the 'Remote Control' section for manual pairing instructions.

Setup Overview Video

Your browser does not support the video tag.

Video: A short overview demonstrating the setup process and features of the Roku 2 XS streaming player.

5. OPERATING INSTRUCTIONS

Remote Control

The Roku 2 XS comes with an enhanced remote featuring motion control for gaming and dedicated buttons for popular streaming services. It also includes a voice search function for easier content discovery.

- **Navigation:** Use the directional pad (up, down, left, right) and the 'OK' button to navigate menus and select items.
- **Voice Search:** Press and hold the microphone button on the remote and speak your search query. This allows for quick searching of movies, TV shows, and channels.
- **Dedicated Buttons:** Utilize the dedicated buttons for direct access to services like Netflix, Hulu Plus, and Amazon Instant Video.
- **Motion Control:** The remote's motion sensors enable interactive gameplay for compatible games.

Accessing Channels and Content

From the Roku home screen, you can browse and launch installed channels. To add new channels, navigate to the Roku Channel Store. Many channels offer free content, while others require a subscription.

6. FEATURES

- 1080p HD Streaming:** Enjoy high-definition video quality for a clear viewing experience.
- Motion-Based Gaming:** Engage in interactive games using the remote's motion control capabilities.
- Extensive Channel Selection:** Access over 600 streaming channels, including movies, TV shows, live sports, music, and news.
- One-Stop Search:** Easily find movies and TV shows across multiple top channels.
- Free Mobile App:** Control your Roku player, browse channels, and stream media from your iOS or Android device.
- Multiple Connectivity Options:** Includes Ethernet for a stable wired connection and a USB port for playing local media files (MP4 video, AAC/MP3 audio, JPEG/PNG images).
- Compact Design:** Small footprint, silent operation, and low power consumption.

7. SPECIFICATIONS

| | |
|------------------------------------|--|
| Brand | Roku |
| Model Name | 3100R |
| Item Weight | 0.3 ounces |
| Product Dimensions | 3.3 x 3.3 x 0.9 inches |
| Color | Black |
| Resolution | 1080p |
| Connectivity Technology | HDMI |
| Connector Type | USB |
| Supported Internet Services | Amazon Instant Video, Hulu Plus, Netflix, Pandora, YouTube |

8. MAINTENANCE

The Roku 2 XS is designed for low maintenance. To ensure optimal performance and longevity:

- Keep the device in a well-ventilated area to prevent overheating.
- Clean the device and remote periodically with a soft, dry cloth.
- Avoid exposing the device to extreme temperatures or moisture.

9. TROUBLESHOOTING

If you encounter issues with your Roku 2 XS, consider the following basic troubleshooting steps:

- **No Power:** Ensure the power adapter is securely connected to both the device and a working electrical outlet.
 - **No Picture/Sound:** Verify that the Roku 2 XS is correctly connected to your TV and that your TV is set to the correct input source. Check all cable connections.
 - **Remote Not Responding:** Replace the batteries in the remote. If the issue persists, try re-pairing the remote according to the 'Get Started guide'.
 - **Buffering/Connectivity Issues:** Check your internet connection and Wi-Fi signal strength. Try restarting your wireless router and the Roku device.
 - **App Issues:** Try removing and re-adding the problematic channel from your Roku device.

For more detailed troubleshooting or persistent issues, please refer to the official Roku support website or the comprehensive 'Get Started guide' included with your product.

10. WARRANTY & SUPPORT

The Roku 2 XS 1080p Streaming Player typically comes with a **90-day manufacturer warranty**. Please retain your proof of purchase for warranty claims.

For product support, including additional guides, FAQs, and contact information, please visit the official Roku support website. You can also find helpful resources and community forums online.

Legal Disclaimer: This product is provided in excellent condition and functions perfectly. It comes in its original box with the manual and all contents.

© 2025 Roku. All rights reserved. Product specifications are subject to change without notice.

Related Documents - 3100R

| | |
|--|---|
| <p>On-screen setup and activation</p> <ol style="list-style-type: none"> View device <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click View device. Note: If the device is not in the list, click Scan for devices to search for it. Enter your Roku Express to set up and activate <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click Enter device. Note: If the device is not in the list, click Scan for devices to search for it. Enter your Roku account to set up and activate <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click Enter account. Note: If the device is not in the list, click Scan for devices to search for it. Watch a video <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click Watch a video. Note: If the device is not in the list, click Scan for devices to search for it. Update device settings <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click Update device settings. Note: If the device is not in the list, click Scan for devices to search for it. Update device software <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click Update device software. Note: If the device is not in the list, click Scan for devices to search for it. Update device settings and software <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click Update device settings and software. Note: If the device is not in the list, click Scan for devices to search for it. Watch a video and update device settings <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click Watch a video and update device settings. Note: If the device is not in the list, click Scan for devices to search for it. Watch a video and update device software <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click Watch a video and update device software. Note: If the device is not in the list, click Scan for devices to search for it. Watch a video and update device settings and software <ul style="list-style-type: none"> Do this now if you will not see the device in a channel list soon after connecting. Select the device in the list and then click Watch a video and update device settings and software. Note: If the device is not in the list, click Scan for devices to search for it. | <h2>Roku Express Setup and Activation Guide</h2> <p>Step-by-step instructions for setting up and activating your Roku Express streaming media player, including connecting to your network, downloading software, and creating a Roku account.</p> |
|  | <h2>Roku Express HD Streaming Media Player Quick Start Guide</h2> <p>Get started with your Roku Express HD streaming media player. This guide covers unboxing, setup, connection, and basic troubleshooting for a seamless streaming experience.</p> |
|  | <h2>Roku Streaming Stick 4K Quick Start Guide: Setup and Usage</h2> <p>Comprehensive guide for setting up your Roku Streaming Stick 4K. Learn how to connect, pair your remote, optimize Wi-Fi, and troubleshoot common questions. Includes product details and features.</p> |



[Roku Streaming Stick 4K Quick Start Guide - Setup and Usage](#)

A concise guide to setting up and using the Roku Streaming Stick 4K, including installation steps, what's included, Wi-Fi tips, and common questions.



[Roku Streaming Stick 4K: Quick Start Guide and Setup Instructions](#)

A comprehensive guide to setting up your Roku Streaming Stick 4K, covering device components, connection steps, Wi-Fi optimization tips, and frequently asked questions for a seamless streaming experience.



[Roku Express+ Streaming Player: Quick Start Guide and Important Information](#)

Get started with your Roku Express+ streaming player. This guide covers setup, safety precautions, warranty information, and FCC compliance for your Roku device.