Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Bravilor Bonamat /
- > Bravilor Bonamat Glass Filter Coffee Jug F640 User Manual

Bravilor Bonamat F640

Bravilor Bonamat Glass Filter Coffee Jug F640 User Manual

Model: F640 | Capacity: 1.7 Litre (3 Pint)

INTRODUCTION

This manual provides essential information for the safe and effective use, care, and maintenance of your Bravilor Bonamat Glass Filter Coffee Jug, Model F640. This jug is designed as a replacement or accessory for various Bravilor coffee machines, including Novo, Mondo, and TH models. Please read these instructions carefully before first use and retain them for future reference.



Image: Bravilor Bonamat Glass Filter Coffee Jug. This image displays the Bravilor Bonamat Glass Filter Coffee Jug. It features a clear glass body with a black plastic lid and handle. The jug is shown partially filled with coffee, and measurement markings are visible on the side.

SETUP AND FIRST USE

- 1. **Unpacking:** Carefully remove the coffee jug from its packaging. Inspect for any damage during transit. If damaged, do not use and contact your supplier.
- 2. **Initial Cleaning:** Before first use, wash the jug thoroughly with warm, soapy water. Rinse completely with clean water and dry.
- 3. **Placement:** Ensure the jug is placed securely on a flat, stable surface or within the designated area of your compatible Bravilor coffee machine.

OPERATING INSTRUCTIONS

This jug is designed to collect and serve brewed coffee from compatible Bravilor Bonamat filter coffee machines.

- **Brewing:** Place the jug directly under the coffee machine's brewing outlet. Ensure it is correctly positioned to catch all brewed coffee.
- Serving: Use the integrated handle for safe and easy pouring. The lid helps retain heat and prevent spills.
- Capacity: The jug has a capacity of 1.7 liters (approximately 3 pints). Do not overfill beyond the maximum fill line indicated on the jug.

CARE AND MAINTENANCE

Proper care will extend the life of your coffee jug and maintain its appearance.

- **Daily Cleaning:** After each use, empty any remaining coffee. Wash the jug with warm water and a mild detergent. Use a soft brush or sponge to clean the interior and exterior.
- Rinsing: Rinse thoroughly with clean water to remove all soap residue.
- Drying: Allow the jug to air dry completely or dry with a soft, lint-free cloth.
- Stain Removal: For stubborn coffee stains, a solution of warm water and a small amount of white vinegar or a specialized coffee cleaner can be used. Follow the cleaner's instructions carefully.
- Avoid Abrasives: Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch the
 glass or damage the plastic components.
- Dishwasher Use: While the glass jug may be dishwasher safe, check your specific dishwasher settings and avoid high-heat cycles that could affect plastic parts over time. Hand washing is recommended for longevity.
- **Handling:** Handle the glass jug with care to prevent breakage. Avoid sudden temperature changes, such as pouring very cold liquid into a hot jug or vice-versa.

TROUBLESHOOTING

This section addresses common issues you might encounter with your coffee jug.

- Issue: Coffee stains are difficult to remove.
 - **Solution:** Use a mixture of warm water and white vinegar, or a dedicated coffee cleaner. Let it soak for a period before scrubbing gently.
- · Issue: Jug appears cloudy.
 - **Solution:** This can be due to mineral deposits from water. Try cleaning with a descaling solution suitable for glass, or a vinegar solution.
- Issue: Jug leaks when pouring.
 - **Solution:** Ensure the lid is properly seated and aligned. Check for any cracks in the glass or damage to the lid's seal. If damaged, the jug may need replacement.
- Issue: Jug breaks easily.
 - **Solution:** Glass is fragile. Avoid dropping the jug, hitting it against hard surfaces, or exposing it to extreme temperature changes.

SPECIFICATIONS

Feature	Detail
Brand	Bravilor Bonamat

Model Number	F640
Material	Glass (Jug), Plastic (Handle/Lid)
Capacity	1.7 Liters (3 Pint)
Product Dimensions	3.15"W x 4.06"H (Approximate)
Shape	Round
Item Weight	509 Grams (1.12 pounds)

WARRANTY AND SUPPORT

For specific warranty information regarding your Bravilor Bonamat Glass Filter Coffee Jug, please refer to the documentation provided with your original coffee machine or contact your point of purchase. Bravilor Bonamat products are manufactured to high standards, and support is typically available through authorized dealers or the official Bravilor Bonamat website.

For further assistance or inquiries, please visit the official Bravilor Bonamat website or contact their customer service department.

© 2023 Bravilor Bonamat. All rights reserved.

Related Documents - F640



Bravilor Bonamat B5, B10, B20, B40 Operating Instructions Manual

Official operating instructions and user manual for Bravilor Bonamat B5, B10, B20, and B40 round-filter coffee brewers. Learn about installation, daily use, maintenance, programming, and troubleshooting.





Bravilor Bonamat Round Filter Coffee Brewer with Hot Water Tap - Operating Instructions

Operating instructions manual for the Bravilor Bonamat Round Filter Coffee Brewer with Hot Water Tap (models B5HW, B10HW, B20HW). Covers installation, daily use, maintenance, and troubleshooting for professional users.



Bravilor Bonamat B HW Series Coffee Brewer Operating Instructions

Comprehensive operating instructions for the Bravilor Bonamat B HW Series Round Filter Coffee Brewer with Hot Water Tap, covering usage, cleaning, descaling, initial setup, programming, and error codes.





Bravilor Bonamat B HW Series: Operating Instructions for Round Filter Coffee Brewer with Hot Water Tap

Comprehensive operating instructions for the Bravilor Bonamat B HW series coffee brewers, detailing installation, daily use, maintenance, programming, and troubleshooting for professional environments.



Bravilor Bonamat SPRSO-0xx Quick Start Guide and Installation

Get started quickly with your Bravilor Bonamat SPRSO-0xx coffee machine. This guide provides essential setup, operation, and maintenance information.



Bravilor Bonamat B HW-series Coffee Brewer Operating Instructions

Comprehensive operating instructions for the Bravilor Bonamat B HW-series round filter coffee brewer with hot water tap, covering usage, cleaning, descaling, programming, and error codes.