

manuals.plus /

- › [Logitech](#) /
- › [Logitech Stereo Headset H150 User Manual](#)

Logitech H150

Logitech Stereo Headset H150 User Manual

Model: H150 (981-000349)

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Logitech Stereo Headset H150. Designed for clear communication and comfortable use, this headset is ideal for voice and video calls on compatible devices.



Figure 1: Logitech Stereo Headset H150, Cloud White model.

KEY FEATURES

- **Full Stereo Sound:** Experience clear and crisp audio for internet calls and music.
- **Noise-Canceling Microphone:** Reduces background noise for clear voice transmission.
- **Adjustable Design:** Features an adjustable headband and comfortable foam ear cups for a personalized fit.
- **Versatile Microphone Placement:** The rotating microphone boom can be positioned for optimal voice pickup or moved out of the way when not in use. It can be worn on either the left or right side.
- **In-Line Controls:** Conveniently adjust volume and mute the microphone directly from the headset cable.
- **Simple Connectivity:** Connects via standard 3.5 mm audio jacks for broad compatibility.

SETUP INSTRUCTIONS

1. **Identify Audio Ports:** Locate the 3.5 mm audio input (microphone) and output (headphone) jacks on your computer or laptop. These are typically color-coded (pink for microphone, green for headphones) or marked with corresponding icons.
2. **Connect Headset:** Plug the pink 3.5 mm jack from the headset into your computer's microphone input port. Plug the green 3.5 mm jack from the headset into your computer's headphone output port.
3. **System Recognition:** Your computer should automatically detect the headset. If not, check your operating system's sound settings to ensure the Logitech H150 is selected as the default audio input and output device.
4. **Initial Volume Adjustment:** Use the in-line volume control on the headset cable to set an initial comfortable listening level.



Figure 2: The headset features standard 3.5mm audio jacks for universal connectivity.

OPERATING INSTRUCTIONS

Adjusting the Headset

- **Headband:** Gently slide the ear cups up or down along the headband to achieve a comfortable and secure fit on your head.
- **Microphone Boom:** The microphone boom can be rotated 270 degrees. Position it near your mouth for optimal voice clarity during calls. When not in use, rotate it upwards and out of the way. The microphone can be worn on either the left or right side of your head.

Using In-Line Controls

The in-line control unit on the headset cable provides quick access to audio functions:

- **Volume Control:** Use the volume dial or buttons (if present) to increase or decrease the listening volume.
- **Microphone Mute:** Press the mute button to temporarily disable the microphone. Press it again to unmute.



Figure 3: The headset features an adjustable headband and a rotating microphone for user comfort and versatility.

Official Product Video



Video 1: A seller demonstrates the features and usage of a headset with a microphone, highlighting its comfort and functionality for various applications.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the headset, including the ear cups and microphone. Avoid using harsh chemicals or abrasive materials.

- **Storage:** Store the headset in a clean, dry place away from extreme temperatures and direct sunlight. Avoid tangling the cable to prevent damage.
 - **Cable Care:** Do not pull on the cable to disconnect the headset. Always grasp the plug firmly.
-

TROUBLESHOOTING

- **No Sound:**
 - Ensure both 3.5 mm jacks are fully inserted into the correct ports on your computer.
 - Check the in-line volume control on the headset and your computer's master volume settings.
 - Verify that the headset is selected as the default playback device in your computer's sound settings.
 - **Microphone Not Working:**
 - Ensure the microphone mute button on the in-line control is not activated.
 - Verify the pink 3.5 mm jack is fully inserted into the correct microphone input port.
 - Check that the headset is selected as the default recording device in your computer's sound settings.
 - **Poor Audio Quality:**
 - Ensure all connections are secure.
 - Test the headset on another device to rule out a computer-specific issue.
 - Adjust the microphone boom position for better voice clarity.
-

SPECIFICATIONS

Model Name	H150
Item Model Number	981-000349
Brand	Logitech
Color	Cloud White
Connectivity Technology	Wired (3.5 mm Jack)
Ear Placement	On Ear
Material	Foam
Control Type	In-line Volume Control, Microphone Mute
Compatible Devices	Desktops, Laptops (Windows OS)
Item Weight	7.8 ounces (0.49 Pounds)
Product Dimensions	9.37 x 2.75 x 7.75 inches
Water Resistance Level	Not Water Resistant

WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance, please visit the official Logitech support website or refer to the user documentation included with your product.

You can also visit the [Logitech Store on Amazon](#) for more product details.
