

Eurotime 56863

EUROTIME 50 cm Radio-Controlled Wall Clock Model 56863

Instruction Manual

Brand: Eurotime | Model: 56863

1. INTRODUCTION

Thank you for choosing the EUROTIME 50 cm Radio-Controlled Wall Clock, Model 56863. This clock is designed for precise timekeeping, automatically synchronizing with a radio time signal to ensure accuracy and effortless adjustment for daylight saving time. Its robust aluminum casing and real glass dial make it suitable for various indoor environments, including large spaces, lobbies, or offices.

2. SAFETY INFORMATION

- **Battery Safety:** Use only the specified battery type (1 x AA). Do not mix old and new batteries, or different types of batteries. Remove exhausted batteries promptly. Dispose of batteries according to local regulations.
- **Mounting:** Ensure the clock is securely mounted on a stable wall surface using appropriate hardware for its weight and size. Improper mounting can lead to injury or damage.
- **Indoor Use Only:** This clock is designed for indoor use. Exposure to outdoor elements, extreme temperatures, or high humidity may damage the clock.
- **Glass Handling:** The clock features a real glass dial. Handle with care to prevent breakage and injury.

3. PACKAGE CONTENTS

- 1 x EUROTIME 50 cm Radio-Controlled Wall Clock (Model 56863)
- 1 x Instruction Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your EUROTIME wall clock.



Figure 4.1: Front View of the Clock

This image displays the clock's face, featuring a clear white dial with large, easy-to-read black Arabic numerals from 1 to 12. The hour and minute hands are black, and the second hand is red. A "RADIO CONTROLLED" symbol is located at the 6 o'clock position.



Figure 4.2: Rear View of the Clock

This image shows the back of the clock, highlighting the central mechanism housing where the battery is inserted. A keyhole-style mounting hook is visible at the top for wall installation. Three rubber feet are also present for stability when placed against a surface.




Figure 4.3: Clock Dimensions

This image illustrates the overall dimensions of the clock. It has a diameter of 50 cm and a depth of 6.5 cm, providing a clear visual reference for its size.

5. SETUP

1. **Insert Battery:** Open the battery compartment cover on the back of the clock. Insert one (1) AA battery, ensuring the polarity (+/-) matches the indicators inside the compartment. Close the cover securely.
2. **Initial Synchronization:** After inserting the battery, the clock hands will automatically move to the 12 o'clock position. The clock will then begin searching for the radio time signal (DCF77 in Europe). This process can take several minutes, or up to an hour, depending on signal strength.
3. **Signal Reception:** For optimal signal reception, place the clock near a window and away from electronic devices that may cause interference. Avoid placing it in basements or areas with heavy concrete walls.
4. **Time Setting:** Once the signal is successfully received, the clock will automatically set itself to the correct local time, including adjusting for daylight saving time (summer/winter time) changes.
5. **Mounting:** Once the time is set, securely hang the clock on a wall using the integrated mounting hook on the back. Ensure the wall plug and screw (not included) are appropriate for the clock's weight.

and your wall type.

6. OPERATING THE CLOCK

The EUROTIDE radio-controlled wall clock operates automatically once set up.

- **Automatic Time Adjustment:** The clock continuously receives the radio time signal, ensuring precise timekeeping.
- **Daylight Saving Time (DST) Adjustment:** The clock will automatically adjust for summer and winter time changes, eliminating the need for manual intervention.
- **Signal Loss:** If the radio signal is temporarily lost, the clock will continue to run on its internal quartz movement. It will attempt to resynchronize with the radio signal periodically.

7. MAINTENANCE

- **Cleaning:** To clean the clock, gently wipe the casing and glass with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or internal components.
- **Battery Replacement:** Replace the AA battery annually or when the clock hands stop moving or appear to lose accuracy. Always replace with a fresh, high-quality AA battery.
- **Environmental Conditions:** Keep the clock away from direct sunlight, extreme temperatures, and high humidity to ensure longevity and accurate operation.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock does not set time or runs incorrectly.	◦ Exhausted or incorrectly inserted battery. ◦ Poor radio signal reception. ◦ Interference from other electronic devices.	◦ Replace the AA battery with a new one, ensuring correct polarity. ◦ Move the clock to a location with better signal reception (e.g., near a window, away from metal objects). ◦ Ensure the clock is not too close to TVs, computers, or other electronic devices.
Hands are stuck or not moving.	◦ Battery is dead. ◦ Mechanical obstruction.	◦ Replace the battery. ◦ Gently check if anything is obstructing the hands. If not, contact support.

9. SPECIFICATIONS

- **Model:** 56863
- **Brand:** Eurotime
- **Type:** Radio-Controlled Wall Clock
- **Dimensions:** 50 cm (Diameter) x 6.5 cm (Depth)
- **Weight:** Approximately 9.07 g (Note: This weight appears unusually low and may be a typographical error)

error in source data. Actual weight is likely higher.)

- **Power Source:** 1 x AA Battery (not included)
- **Casing Material:** Aluminum
- **Dial Material:** Real Glass
- **Display Type:** Analog
- **Special Features:** Automatic time synchronization, automatic Daylight Saving Time (DST) adjustment.
- **Usage:** Indoor only

10. WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided by your retailer at the time of purchase. If you encounter any issues not covered in the troubleshooting section, or require further assistance, please contact your retailer or the Eurotime customer support directly.

Related Documents - 56863

	MOBATIME EuroTime Center ETC Master Clock System - Technical Overview Explore the MOBATIME EuroTime Center ETC master clock series, a versatile solution for time distribution systems. This document details its features, technical specifications, interface options, and applications for synchronized time management.
	MOBATIME EuroTime Center ETC Master Clock Series - Technical Specifications and Features Explore the MOBATIME EuroTime Center ETC, a versatile master clock for time service systems. This document details its technical specifications, interfaces, clock line outputs, time source, control capabilities, and applications for synchronized time distribution.
	EuroTime Center ETC: Reloj Maestro Versátil MOBATIME para Sistemas de Servicio de Tiempo Ficha técnica detallada del EuroTime Center ETC de MOBATIME. Características, especificaciones técnicas, interfaces y aplicaciones de este reloj maestro para sincronización horaria y automatización de edificios.

 SÉRIE D'HORLOGES MÈRES ETC Un EuroTime Center ETC est un horloge maître polyvalente pour la synchronisation des horloges secondaires. Elle permet de synchroniser les horloges secondaires à l'aide de la fonction DCF/GNSS et de gérer les fonctions du bâtiment. Spécifications techniques détaillées.	MOBATIME EuroTime Center ETC : Système d'horloge mère - Caractéristiques et Spécifications Découvrez le système d'horloge mère polyvalent MOBATIME EuroTime Center ETC. Contrôlez les horloges secondaires, synchronisez le temps via DCF/GNSS et gérez les fonctions du bâtiment. Spécifications techniques détaillées.
--	--


Documents - Eurotime – 56863



[\[pdf\]](#) User Manual

SLO NAVODILO ZA UPORABO IN MONTAŽO Št Ina Polič Buy %product title% Conrad Electronic manual 672034 br eurotimebr 56863br radiobr wall clockbr 50 cm asset conrad media10 add 160267 c1 sl 000672034ML01 Navodila za uporabo EUROTIME 56863 radijska stenska ura cmNavodila cmEUROTIME MegaShop spletna trgovina Megashop si EUROTIME siBuy Radio Wall clock ElectronicRádiójel vezérelt analóg Jumbo falióra Ø alu Eurotime vásárlása Electronicnavodila eurotime cmnavodila cmbuksanvisning dcf vaeggklocka cmmanual brmanual radio cmhasznalati utmutato radiojel vezérelt analog jumbo faliora o 56863asset navodila cmasset buksanvisning brasset hasznalati cmNAVODILA Radijsko vodena EurotimeEUROTIME siEurotime Kataloška št 67 20 34 Page 2 proizvajalec Uhrenvertriebs GmbH Schweinfurter Str 24 97337 Dettelbach Nemčija 2Buy cmupute rukovanje radijski zidni sat upute |||

SLO - NAVODILA ZA UPORABO IN MONTAZO Kat. st.: 67 20 34 www.conrad.si NAVODILA ZA UPORABO Radijsko vodena stenska ura Eurotime **56863** Kataloska st.: 67 20 34 Eurotime, proizvajalec: Eurotime Uhrenvertriebs-GmbH, Schweinfurter Str. 24, 97337 Dettelbach, Nemcija. Kazalo 1. Priprava ure na delovanj... lang:hr score:34 filesize: 182.32 K page_count: 5 document date: 2019-11-18




[pdf]

CTX Datenblatt 672034 EUROTIME 56863 Funk Wanduhr 50 cm Conrad e B2B on line SLO Trgovina za podjetja! Bedienungsanleitung datenblatt eurotime funk wanduhr asset conrad media10 add 160267 c1 de 000672034DS01 |||

Funkwanduhren Artikel-Nummer Features Farben Batterien Gre Gewicht:

Verpackung **56863** Funkwanduhr im Edelstahl-Gehuse, weies Zifferblatt schwarze Zeiger, rote Sekunde, arabische Ziffern Echtglasabdeckung, nur fr den Innenbereich vorgesehen Edelstahl 1 x AA, nicht enthalten 500 x 500 mm 3,8 kg Falts...

lang:hr **score:23** filesize: 34.56 K page_count: 1 document date: 2014-09-24




[pdf]

Microsoft Word ku672034 M 341nyi Ivett Bedienungsanleitung 672034 EUROTIME 56863 Funk Wanduhr 50 cm Conrad e B2B on line SLO Trgovina za podjetja! bedienungsanleitung eurotime funk wanduhr asset conrad media10 add 160267 c1 hu 000672034ML01 |||

Hasznlati tmutat Rend. sz.: 672034 1. Az ra zembe helyezse Tegye be az elemet 1 db 1,5 V-os LR6/AA ... eu Az R TTE kvetelmnyek a kvetkez orszgokban teljeslnek,: Az EU sszes orszgban, Svjcban s Norvgiban **56863V1021209** ...

lang:no **score:13** filesize: 75.22 K page_count: 2 document date: 2019-01-07



[pdf] User Manual

670034 56863 DE GB FR NL V1021209 F Beyer Bedienungsanleitung 672034 EUROTIME Funk Wanduhr 50 cm Conrad e B2B on line SLO Trgovina za podjetja! bedienungsanleitung eurotime funk wanduhr asset conrad media10 add 160267 c1 gl 000672034ML02 |||

Gebrauchsanleitung 1. Inbetriebnahme der Uhr Legen Sie die Batterie 1 x LR6, 1.5V, Type AA gem Abbeu Landen waarin aan de R TTE-eisen wordt voldaan: Alle landen van de EU, Zwitserland en Noorwegen **56863V1021209** ...

lang:de **score:13** filesize: 81.25 K page_count: 8 document date: 2009-12-10



[pdf]


Microsoft Word 672034 an 01 pl Zegar analogowy DCF Jumbo docx Kinga Starzyk Bedienungsanleitung

EUROTIME 56863 Funk Wanduhr 50 cm Conrad e B2B on line SLO Trgovina za podjetja!

bedienungsanleitung eurotime funk wanduhr asset conrad media10 add 160267 c1 000672034ML03 |||

www.conrad.pl ...

lang:pl score:13 filesize: 53.94 K page_count: 1 document date: 2012-06-19



[pdf]

376 377 0006 0007 0002 0000 0003 0004 000x Docekal Frantisek Bedienungsanleitung 672034

EUROTIME 56863 Funk Wanduhr 50 cm Conrad e B2B on line SLO Trgovina za podjetja!

bedienungsanleitung eurotime funk wanduhr asset conrad media10 add 160267 c1 cs 000672034ML01 |||

Analogov nstnn hodiny DCF Obj. c.: 67 20 32 40 cm Obj. c.: 67 20 34 50 cm Vzen

zkaznku, dkujeme Vm za Vasi dvru a za nkup analogovch nstnnch hodin DCF. Tento

nvod k obsluze je soust vrobku. Obsahuje dlezit pokyny k uveden vrobku do provozu

a k jeho obsluze. Jestlize vrobek pedte jinm osobm, dbejt...

lang:it score:12 filesize: 123.21 K page_count: 2 document date: 2013-12-12