

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [TOTAL](#) /

› TOTAL High Power Flashlight TWLI2023 User Manual

TOTAL TWLI2023

TOTAL High Power Flashlight

Model: TWLI2023

1. INTRODUCTION

Thank you for choosing the TOTAL High Power Flashlight, Model TWLI2023. This durable and versatile LED flashlight is designed for various tasks, offering 150 lumens of brightness and an adjustable head for optimal illumination. This manual provides essential information for the safe and effective use of your flashlight.



LINTERNA A BATERÍA MOD. TWLI2023

Image 1.1: The TOTAL High Power Flashlight, Model TWLI2023, shown with a compatible 20V battery attached. This image illustrates the overall design and form factor of the flashlight.

2. SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of injury or damage to the product:

- Read all instructions carefully before operating the flashlight.
- Use only TOTAL P20S series 20V batteries and chargers with this flashlight. Using incompatible batteries may cause fire, injury, or damage.
- Do not expose the flashlight to rain or wet conditions. Water entering the flashlight will increase the risk of electric shock.
- Do not look directly into the light beam. The high intensity light can cause temporary vision impairment or eye damage.
- Keep the flashlight out of reach of children.
- Do not attempt to disassemble or modify the flashlight. Refer all servicing to qualified personnel.
- Store the flashlight in a dry, secure location when not in use.

3. PACKAGE CONTENTS

Your TOTAL High Power Flashlight package includes the following items:

- 1 x TOTAL High Power Flashlight (Model: TWLI2023)
- 1 x Metal back hook (pre-attached or included for hanging)

Note: Battery (2Ah or 4Ah) and charger are NOT included and must be purchased separately. This flashlight is compatible with TOTALTOOLS P20S range batteries and chargers.



Image 3.1: The TOTAL High Power Flashlight in its retail packaging. The packaging highlights key features such as 150 lumens brightness and 20V compatibility, and indicates that the battery and charger are sold separately.

4. SETUP

4.1 Attaching the Battery

1. Ensure the flashlight is turned off.
2. Align the TOTAL P20S 20V battery with the battery slot at the base of the flashlight handle.
3. Slide the battery firmly into the slot until it clicks into place, indicating a secure connection.

4.2 Removing the Battery

1. Ensure the flashlight is turned off.
2. Press the battery release button (usually located on the battery itself or near the battery slot).

3. Slide the battery out of the flashlight base.

5. OPERATING INSTRUCTIONS

5.1 Turning On/Off

To turn the flashlight on, press the power button located on the handle. Press the button again to turn it off.

5.2 Adjusting the Head

The flashlight features an adjustable head that can pivot up to 90 degrees. Gently rotate the head to direct the light beam to your desired angle. This allows for versatile illumination in various working conditions.



Image 5.1: A close-up view of the TOTAL High Power Flashlight's head, demonstrating its ability to adjust up to 90 degrees for flexible lighting angles.

5.3 Using the Metal Hook

A metal hook is integrated into the design, allowing you to hang the flashlight for hands-free operation. This is particularly useful in workshops, garages, or during camping activities.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your flashlight:

- **Cleaning:** Wipe the flashlight body with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** Always remove the battery when the flashlight is not in use for extended periods. Store batteries in a cool, dry place and charge them regularly to maintain their health, even if not in use.
- **Storage:** Store the flashlight in a clean, dry environment, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is not inserted correctly.	Ensure the battery is fully seated and clicked into place.
Flashlight does not turn on.	Battery is discharged.	Recharge the battery using a compatible TOTAL P20S charger.
Light is dim or flickers.	Battery charge is low.	Recharge the battery.
Light head is stiff to adjust.	Minor debris or wear.	Gently clean around the pivot point. Do not force adjustment. If issue persists, contact support.

8. SPECIFICATIONS

Feature	Specification
Model Number	TWLI2023
Brand	TOTAL
Power Source	Battery Powered (TOTAL P20S 20V)
Voltage	20 Volts
Light Source Type	LED
Brightness	150 Lumens
Special Features	Adjustable Light (up to 90°), Portable, Rechargeable
Material	Metal
Item Weight	0.23 Kilograms
Item Dimensions (L x W x H)	6.69" x 2.36" x 10.83"
Batteries Included	No
Included Components	1 x Portable Flashlight, Metal hook for hanging

9. SUPPORT

For any questions regarding the TOTAL High Power Flashlight, including its measurements, weight, or

performance, please contact TOTAL Tools customer support. You may also use the internal messaging service of the platform where you purchased the product for assistance.