

[Manuals.plus](#) /

› [Farberware](#) /

› Farberware Can Opener (Black), 9" Instruction Manual

Farberware 5070505

Farberware Can Opener (Black), 9"

INSTRUCTION MANUAL

PRODUCT OVERVIEW

The Farberware Can Opener is a manual kitchen tool designed for opening various types of cans and bottled beverages. It features a durable, polished chrome head and an ergonomic design for comfortable use. This manual provides instructions for its proper use, care, and maintenance.



Figure 1: Farberware Manual Can Opener, showing its black handles and polished chrome head.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove the can opener from its packaging. Inspect the unit for any signs of damage.
2. **Initial Cleaning:** Before first use, hand wash the can opener with warm water and a mild detergent. Rinse thoroughly and dry immediately to prevent water spots or corrosion.
3. **Familiarization:** Observe the large, easy-to-turn knob and the cutting wheel. Note the integrated bottle opener at the top of the handle.

OPERATING INSTRUCTIONS

Opening Cans

1. **Positioning:** Place the can opener on the rim of the can, ensuring the cutting wheel is positioned just inside the can's rim and the gear is gripping the outside of the rim.
2. **Gripping:** Squeeze the handles firmly together to pierce the can lid and secure the can opener in place.
3. **Turning:** Rotate the large, easy-to-turn knob clockwise. The cutting wheel will advance around the can's rim, cutting the lid. Maintain a firm grip on the handles throughout the process.
4. **Completion:** Continue turning until the lid is fully detached. Release the handles and carefully remove the can opener

from the can.

5. **Lid Removal:** Use caution when removing the lid, as edges may be sharp.



Figure 2: Proper technique for opening a can with the Farberware Can Opener.

Opening Bottled Beverages

- Locate the built-in bottle opener at the top of the can opener's head.
- Position the bottle opener under the cap of the bottle.
- Apply upward pressure to the handle while holding the bottle firmly to pry off the cap.

FARBERWARE™

MULTIUSE

Features a built-in
bottle opener—two
tools in one



ERGONOMIC HANDLE

Designed to maximize
comfort and control

Figure 3: The Farberware Can Opener also features a built-in bottle opener for added utility.

CARE AND MAINTENANCE

- **Cleaning:** This product is not dishwasher safe. Hand wash with warm water and a mild detergent immediately after each use.
- **Rinsing:** Rinse thoroughly to remove all soap residue.
- **Drying:** Dry the can opener immediately and completely with a soft cloth to prevent water spots and rust, especially on the polished chrome head and cutting wheel.
- **Storage:** Store the can opener in a dry place, such as a kitchen drawer or utensil holder, away from excessive moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Can opener does not grip the can.	Handles not squeezed firmly enough; can opener not properly aligned.	Ensure the cutting wheel is inside the rim and the gear is on the outside. Squeeze handles firmly until the blade pierces the lid.
Can opener stops cutting mid-way.	Loss of grip; dull blade (over time).	Re-squeeze handles firmly and continue turning the knob. If the blade is dull, consider replacing the can opener.
Lid edges are jagged or rough.	Inconsistent pressure; dull blade.	Maintain consistent, firm pressure while turning the knob. A very dull blade may result in rough cuts.

PRODUCT SPECIFICATIONS

Brand	Farberware
Model Number	5070505
Color	Black
Material	Plastic (Handles), Stainless Steel (Blade), Polished Chrome (Head)
Size	9 inches (Length)
Product Dimensions	2.05"W x 7.05"H
Item Weight	0.01 Ounces
Operation Mode	Manual
Manufacturer	Lifetime Brands
UPC	086302478228, 024131126699

WARRANTY AND SUPPORT

This Farberware product is manufactured by Lifetime Brands. For specific warranty information or support inquiries, please refer to the packaging or contact Lifetime Brands directly. Keep your purchase receipt as proof of purchase. General product information can often be found on the official [Farberware website or brand store](#).