

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Acctim](#) /

› [Acctim Auric Alarm Clock 12343 User Manual](#)

## Acctim 12343

# Acctim Auric Alarm Clock 12343 User Manual

Model: 12343

## INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your Acctim Auric Alarm Clock, model 12343. Please read this manual thoroughly before use to ensure proper functionality and longevity of your device.

The Acctim Auric Alarm Clock features a large digital LCD display with a super-bright blue backlight, a crescendo alarm, and a convenient snooze function. Its compact design makes it a suitable addition to any environment.

## PRODUCT OVERVIEW



**Figure 1:** Front view of the Acctim Auric Alarm Clock. The large digital display shows the time, and an alarm icon indicates the alarm is set. The display features clear, easy-to-read digits.



**Figure 2:** Top view of the alarm clock, highlighting the control buttons. These include buttons for setting hours (HR) and minutes (MIN), time setting (T.SET), alarm setting (AL.SET), and a switch for alarm on/off (AL.ON/OFF). The large button at the top is for SNOOZE/LIGHT.

## Key Features:

- Large digit LCD display for clear visibility.
- Super-bright blue backlight for easy reading in low light conditions.
- Crescendo alarm with snooze function.
- Compact and functional design.
- Battery operated (requires 2 x AA batteries, not included).

## SETUP

### Battery Installation:

1. Locate the battery compartment on the underside of the alarm clock.
2. Open the battery compartment cover.
3. Insert 2 new AA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

*Note: For optimal performance of the backlight function, ensure batteries have sufficient power.*

### Setting the Time:

1. Slide the function switch (typically labeled T.SET/AL.SET/AL.OFF) to the "**T.SET**" position.
2. Press the "**HR**" button to adjust the hour. The hour will advance with each press.
3. Press the "**MIN**" button to adjust the minute. The minute will advance with each press.
4. Once the correct time is set, slide the function switch back to the "**AL.OFF**" or "**AL.ON**" position (depending on whether you want the alarm active).

# OPERATING INSTRUCTIONS

## Setting the Alarm:

1. Slide the function switch to the "AL.SET" position.
2. Press the "HR" button to adjust the alarm hour.
3. Press the "MIN" button to adjust the alarm minute.
4. Once the desired alarm time is set, slide the function switch to the "AL.ON" position to activate the alarm. An alarm icon (bell) will appear on the display.

## Using the Snooze/Light Function:

- When the alarm sounds, press the large "SNOOZE/LIGHT" button located on the top of the clock to temporarily silence the alarm. The alarm will sound again after approximately 5 minutes (crescendo alarm).
- To activate the blue backlight at any time, press the "SNOOZE/LIGHT" button. The backlight will illuminate for a few seconds.

## Turning Off the Alarm:

- To turn off the alarm completely, slide the function switch to the "AL.OFF" position. The alarm icon will disappear from the display.

# MAINTENANCE

## Cleaning:

- To clean the clock, gently wipe the surface with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or internal components.

## Battery Replacement:

- When the display dims or the alarm sound weakens, it is time to replace the batteries.
- Follow the battery installation steps outlined in the "Setup" section.
- Dispose of used batteries responsibly according to local regulations.

# TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is dim or blank.	Low or dead batteries. Incorrect battery polarity.	Replace batteries with new AA batteries, ensuring correct polarity.
Alarm does not sound.	Alarm not set or activated. Batteries are low.	Ensure the function switch is in the "AL.ON" position. Verify alarm time is set correctly. Replace batteries if needed.

Problem	Possible Cause	Solution
Backlight is not working or is very dim.	Insufficient battery power.	Replace batteries with new AA batteries.
Time is incorrect.	Time not set correctly.	Refer to "Setting the Time" section to reset the current time.

## SPECIFICATIONS


Model:	12343
Brand:	Acctim
Display Type:	Digital LCD
Backlight:	Super-bright blue LED
Alarm Type:	Crescendo with Snooze
Power Source:	2 x AA Batteries (not included)
Dimensions (L x W x H):	10.49 cm x 5.21 cm x 8 cm (approx. 52 x 105 x 75 mm)
Weight:	117.93 g
Material:	Synthetic
Color:	Black

## WARRANTY AND SUPPORT

The Acctim Auric Alarm Clock is backed by a 1-year manufacturer's guarantee from the date of purchase.

For any questions, troubleshooting assistance, or warranty claims, please contact Acctim customer service. Refer to the product packaging or the official Acctim website for contact details.

**Important Safety Information:** Always read all product packaging literature and product labels before use.

	<p><a href="#"><u>Acctim Juno Smartlite® Alarm Clock 14843 &amp; 14847X Operating Instructions</u></a></p> <p>Comprehensive operating instructions for the Acctim Juno Smartlite® alarm clock (models 14843 &amp; 14847X), detailing features, time and alarm setting, backlight, Smartlite® technology, battery care, maintenance, and environmental disposal guidelines.</p>
	<p><a href="#"><u>74057 Stratus Radio Controlled LCD Wall Clock Instruction Manual</u></a></p> <p>Instruction manual for the 74057 Stratus Radio Controlled LCD Wall Clock, detailing setup, alarm functions, temperature display, moon phase, and troubleshooting.</p>
	<p><a href="#"><u>Acctim Acura &amp; Cuba Series Radio Controlled Smartlite Alarm Clock Instruction Manual</u></a></p> <p>Comprehensive instruction manual for the Acctim Acura &amp; Cuba Series Radio Controlled Smartlite Alarm Clock, covering setup, features, manual time setting, troubleshooting, and maintenance.</p>
	<p><a href="#"><u>Acctim Cadiz RC Wall Clock Troubleshooting Guide</u></a></p> <p>Troubleshooting guide for the Acctim Cadiz RC Wall Clock, covering MSF signal reception issues and automatic setup procedures.</p>
	<p><a href="#"><u>Acctim Radio Controlled Talking Watch Instruction Manual</u></a></p> <p>Instruction manual for the Acctim Radio Controlled Talking Watch, detailing initial activation, radio control timekeeping, battery replacement, synchronization procedures, and warranty information.</p>
	<p><a href="#"><u>Acctim Radio Controlled Watch Quick Start Guide</u></a></p> <p>A quick start guide for Acctim radio controlled watches, covering initial setup, syncing, troubleshooting, and battery replacement. Includes detailed instructions and guarantee information.</p>

Documents - Acctim – 12343

no relevant documents