



[Manuals.plus](#) /

› [Playseat](#) /

› Playseat DiRT 3 Revolution Gaming Seat Instruction Manual

Playseat 11015

Playseat Limited Edition DiRT 3 Revolution Gaming Seat Instruction Manual

Model: 11015

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Playseat Limited Edition DiRT 3 Revolution Gaming Seat. This racing seat is designed to enhance your gaming experience by providing a realistic and comfortable setup for racing simulations. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Figure 1: Fully assembled Playseat Limited Edition DiRT 3 Revolution Gaming Seat.

2. SAFETY INFORMATION

- **Age Recommendation:** This product is recommended for users aged 14 years and older.
- **Weight Limit:** The maximum recommended user weight is 250 pounds (approximately 113 kg).
- **Length Limit:** The maximum recommended user length is 87 inches (approximately 221 cm).
- Ensure all components are securely fastened before use. Regularly check for loose connections.
- Keep hands and fingers clear of moving parts during adjustment.
- Do not stand on the seat or frame.
- Use on a flat, stable surface to prevent tipping.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The package should contain:

- Racing Seat (with DiRT 3 branding, high-density foam, synthetic leather upholstery, and integrated head protection)

- Main Frame (black powder-coated tubular steel)
- Steering Wheel Support Plate
- Pedal Support Plate
- Assembly Hardware (bolts, nuts, washers, allen wrenches, etc.)
- Removable Seat Back and Base Cushions
- Instruction Manual (this document)

Note: Specific quantities of hardware may vary. Refer to the included hardware pack for exact counts.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Playseat DiRT 3 Revolution Gaming Seat. It is recommended to have a second person assist with some steps.

4.1. Frame Assembly

1. Unpack all components and lay them out on a clean, flat surface.
2. Connect the main frame sections using the provided bolts and tools. Ensure all connections are snug but do not overtighten until the entire frame is assembled.
3. Attach the seat chassis to the main frame. The chassis is designed with extra strong, heavyweight, powder-coated steel.

4.2. Seat Installation

1. Mount the racing seat onto the assembled chassis. Secure it using the designated mounting points and hardware.
2. Ensure the seat is firmly attached and does not wobble.

4.3. Steering Wheel and Pedal Support Installation

1. Attach the steering wheel support plate to the main frame. This support features an aluminum quick-release handle for height and length adjustment.
2. Install the pedal support plate to the front section of the frame. This plate is designed to accommodate most PC and console pedal sets.



Figure 2: Side view illustrating the steering wheel and pedal support structure.



Figure 3: Detail of the universal pedal support plate.

Note: The frame includes powder-coated triangle tubing with extra space for routing all wiring, and PU protection between tubes to prevent scratching.

5. OPERATING INSTRUCTIONS

5.1. Adjusting the Seat

The Playseat DiRT 3 Revolution Gaming Seat features multiple adjustment points for optimal comfort and compatibility.

- **Steering Wheel Support:** Use the aluminum quick-release handle to adjust the height and length of the steering wheel support. Loosen the handle, position the support as desired, and then tighten the handle firmly.
- **Pedal Support:** The pedal support plate can be adjusted for distance. Utilize the aluminum quick-release pressure handles on the framework for multi-point adjustment.
- **Seat Position:** The seat itself may offer limited forward/backward adjustment on its rails, similar to a car seat. Consult the specific seat mechanism for details.

5.2. Connecting Peripherals

The gaming seat is designed for universal compatibility with most PC and console wheel and pedal sets.

- **Supported Systems:** Fully supports PlayStation 2, PlayStation 3, Xbox, Xbox 360, Wii, and PC wheel/pedal sets.
- **Mounting:** Secure your steering wheel and pedal set to their respective support plates using the mounting hardware provided with your peripherals. The plates are pre-drilled or designed for clamping mechanisms.
- **Cable Management:** Utilize the space within the powder-coated triangle tubing for routing cables to maintain a tidy setup and prevent tripping hazards.

5.3. Storage

The seat features a patented foldable system in the back for easy and fast storage when not in use. Follow the instructions for folding the seat to reduce its footprint.

6. MAINTENANCE

- **Cleaning:** Wipe down the synthetic leather upholstery with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Frame Care:** Clean the steel frame with a damp cloth. The powder coating provides durability and protection.
- **Inspections:** Periodically check all bolts and connections to ensure they remain tight. Retighten as necessary to maintain stability.
- **Cushions:** The seat back and base cushions are removable for easier cleaning or replacement.
- **Protection:** The frame includes PU protection between tubes to avoid scratching of the powder coating during adjustments or folding.

7. TROUBLESHOOTING

- **Wobbling Seat/Frame:**
Solution: Ensure all assembly bolts are fully tightened. Check that the seat is properly secured to the chassis. Verify the frame is on a flat, even surface.
- **Difficulty Adjusting Steering Wheel/Pedal Support:**
Solution: Loosen the quick-release handles sufficiently before attempting to adjust. Do not force adjustments. Ensure no cables are obstructing movement.
- **Peripherals Not Mounting Securely:**
Solution: Confirm your peripheral's mounting mechanism is compatible with the seat's plates. Use the hardware provided with your steering wheel or pedals. Some peripherals may require drilling specific holes (e.g., Fanatec wheels, as mentioned in a review, though this is user modification and not officially supported by Playseat's general instructions).
- **Squeaking Noises:**
Solution: Identify the source of the squeak. It may be a loose connection that needs tightening, or a moving part that could benefit from a small amount of silicone lubricant (avoiding contact with upholstery).

8. SPECIFICATIONS

Feature	Detail
---------	--------

Model Number	11015
Product Dimensions (L x W x H)	52 x 20 x 39 inches (132 x 51 x 99 cm)
Item Weight	54.05 Pounds (24.5 kg)
Maximum User Weight	250 Pounds (113 kg)
Maximum User Length	87 Inches (221 cm)
Recommended Age	14+ years
Frame Material	Black powder-coated tubular steel
Seat Material	High-quality synthetic leather with high-density foam
Compatibility	Universal support for most PC and console wheel & pedal sets (PS2, PS3, Xbox, Xbox 360, Wii, PC)
Special Features	Patented foldable system, integrated side head protection, reinforced high-wearing areas, cable management space

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Playseat website or contact your retailer. Keep your proof of purchase for any warranty claims.

For further assistance, visit: www.playseatstore.com