



Manuals.plus /

› V7 /

› V7 Deluxe USB Stereo Headset with Noise-Canceling Microphone (Model HU511-2NP) - User Manual

V7 HU511-2NP

V7 Deluxe USB Stereo Headset with Noise-Canceling Microphone (Model HU511-2NP) - User Manual

INTRODUCTION

Welcome to your V7 Deluxe USB Stereo Headset. This manual provides detailed instructions for setting up, operating, and maintaining your headset to ensure optimal performance for music streaming, hands-free VOIP, Skype calls, and video conferencing on tablets, PCs, and notebooks.

PRODUCT OVERVIEW

Key Features

- USB headset with omnidirectional noise-canceling microphone.
- Digital studio sound quality from 40 mm drivers with a frequency response of 20Hz - 20KHz.
- Soft foam ear-pads and an ergonomic, adjustable headband for comfort.
- In-line volume control and microphone mute function.
- Extra-long 6-foot USB cable.
- Compatible with laptops and PCs running Windows 2000/XP/Vista/7, Mac OS X, and Linux operating systems.

Package Contents

- V7 Deluxe USB Stereo Headset (Model HU511-2NP)

SETUP

Connecting Your Headset

The V7 Deluxe USB Stereo Headset is designed for plug-and-play functionality, requiring no additional software installation for basic use.

1. Locate an available USB port on your computer (PC, laptop, or notebook).
2. Insert the USB connector of the headset firmly into the USB port.

3. Your operating system (Windows, Mac OS X, Linux) should automatically detect and install the necessary drivers. This process may take a few moments.
4. Once installed, the headset will be ready for use. You may need to select it as the default audio input/output device in your system's sound settings or within your communication application (e.g., Skype, VOIP software).



Image: V7 Deluxe USB Stereo Headset connected via USB.

Product Overview Video

Your browser does not support the video tag.

Video: An overview of the V7 Deluxe USB Headset, demonstrating its features and use. This video highlights the plug-and-play USB connectivity, noise-canceling microphone, and comfortable design.

OPERATING INSTRUCTIONS

Adjusting the Headset

The headset features an adjustable headband and soft foam ear-pads for a comfortable fit during extended use.

1. Adjust the headband by sliding the earcups up or down until the headset rests comfortably on your head.
2. Position the soft foam ear-pads over your ears.
3. The omnidirectional microphone is flexible and can be folded away when not in use. For voice communication, gently bend the microphone boom to position the microphone near your mouth for optimal voice pickup.



Image: Adjustable headband and microphone positioning on the V7 Deluxe USB Stereo Headset.

Using In-Line Controls

The extra-long 6-foot USB cable includes convenient in-line controls for easy management of audio and microphone functions.

- **Volume Up/Down:** Use the '+' and '-' buttons on the in-line control unit to adjust the listening volume of the headset.
- **Mute Microphone:** Press the dedicated mute button on the in-line control unit to quickly mute or unmute your microphone. An indicator light on the control unit may show the microphone's active or muted status.



Image: Close-up of the in-line volume and mute controls on the headset cable.

-
- Keep the headset clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
 - Avoid exposing the headset to extreme temperatures, direct sunlight, or high humidity.
 - Do not attempt to disassemble or modify the headset, as this will void the warranty and may cause damage.
 - Store the headset in a safe place when not in use to prevent damage to the cable, microphone, or earcups.

TROUBLESHOOTING

No Sound or Microphone Not Working

- Ensure the USB connector is fully and securely inserted into the USB port on your computer.
- Check your computer's sound settings (e.g., Windows Sound Control Panel, macOS Sound Preferences) to confirm that the V7 headset is selected as the default playback (output) and recording (input) device.
- Verify that the volume is not muted on the in-line controls or in your computer's system volume settings. Increase the volume if it is too low.
- Try connecting the headset to a different USB port on your computer or to another computer to rule out a faulty USB port.
- Restart your computer. Sometimes a simple restart can resolve driver or software conflicts.

Poor Sound Quality

- Ensure the ear-pads are properly positioned over your ears to create a good seal for optimal sound.
- Check for any software conflicts or background applications that might be consuming system resources and affecting audio performance.
- Adjust the volume levels to an appropriate setting. Excessive volume can sometimes lead to distortion.

Headset is Uncomfortable

- Adjust the headband for a looser or tighter fit. The headband is designed to be flexible.
- While the ear-pads are designed for comfort, extended use may require short breaks to alleviate pressure.

SPECIFICATIONS

Feature	Detail
Brand	V7
Model Number	HU511-2NP
Connectivity Technology	Wired (USB)
Form Factor	Over Ear
Noise Control	Sound Isolation
Frequency Response	20Hz - 20KHz
Microphone Type	Noise-canceling, Omnidirectional
Cable Length	6 feet (approx. 1.8 meters)
Controls	In-line volume control, microphone mute
Compatibility	Windows 2000/XP/Vista/7, Mac OS X, Linux
Item Weight	0.37 Pounds (approx. 0.17 kg)

WARRANTY AND SUPPORT

This V7 product comes with a 2-year warranty. For technical support, warranty claims, or additional product information, please visit the official V7 website or contact their customer service department.

Official V7 Website: www.v7world.com